


Service Manual



PDP-5080HD

ORDER NO.
ARP3443

PLASMA DISPLAY SYSTEM

PDP-5080HD

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
PDP-5080HD	KUCXC	AC 120 V	



For details, refer to "Important Check Points for good servicing".

SAFETY INFORMATION



This service manual is intended for qualified service technicians ; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual.

Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely, you should not risk trying to do so and refer the repair to a qualified service technician.



WARNING

This product contains lead in solder and certain electrical parts contain chemicals which are known to the state of California to cause cancer, birth defects or other reproductive harm.

Health & Safety Code Section 25249.6 - Proposition 65



NOTICE

(FOR CANADIAN MODEL ONLY)

Fuse symbols  (fast operating fuse) and/or  (slow operating fuse) on PCB indicate that replacement parts must be of identical designation.

REMARQUE

(POUR MODÈLE CANADIEN SEULEMENT)

Les symboles de fusible  (fusible de type rapide) et/ou  (fusible de type lent) sur CCI indiquent que les pièces de remplacement doivent avoir la même désignation.

SAFETY PRECAUTIONS

NOTICE : Comply with all cautions and safety related notes located on or inside the cabinet and on the chassis.

The following precautions should be observed :

1. When service is required, even though the PDP UNIT an isolation transformer should be inserted between the power line and the set in safety before any service is performed.
2. When replacing a chassis in the set, all the protective devices must be put back in place, such as barriers, nonmetallic knobs, adjustment and compartment covershields, isolation resistor-capacitor, etc.
3. When service is required, observe the original lead dress. Extra precaution should be taken to assure correct lead dress in the high voltage circuitry area.
4. Always use the manufacture's replacement components. Especially critical components as indicated on the circuit diagram should not be replaced by other manufacture's. Furthermore where a short circuit has occurred, replace those components that indicate evidence of overheating.
5. Before returning a serviced set to the customer, the service technician must thoroughly test the unit to be certain that it is completely safe to operate without danger of electrical shock, and be sure that no protective device built into the set by the manufacture has become defective, or inadvertently defeated during servicing. Therefore, the following checks should be performed for the continued protection of the customer and servicetechnician.

6. Perform the following precautions against unwanted radiation and rise in internal temperature.

- Always return the internal wiring to the original styling.
 - Attach parts (Gasket, Ferrite Core, Ground, Rear Cover, Shield Case etc.) surely after disassembly.
7. Perform the following precautions for the PDP panel.
- When the front case is removed, make sure nothing hits the panel face, panel corner, and panel edge (so that the glass does not break).
 - Make sure that the panel vent does not break. (Check that the cover is attached.)
 - Handle the FPC connected to the panel carefully. Twisting or pulling the FPC when connecting it to the connector will cause it to peel off from the panel.
8. Pay attention to the following.
- Pay extreme caution when the front case and rear panel are removed because this may cause a high risk of disturbance to TVs and radios in the surrounding.

Leakage Current Cold Check

With the AC plug removed from an AC power source, place a jumper across the two plug prongs. Turn the AC power switch on. Using an insulation tester (DC 500V), connect one lead to the jumpered AC plug and touch the other lead to each exposed metal part (input/output terminals, screwheads, metal overlays, control shafts, etc.), particularly any exposed metal part having a return path to the chassis. Exposed metal parts having a return path to the chassis should have a minimum resistor reading of 4 M Ω .


The below 4 M Ω resistor value indicate an abnormality which require corrective action. Exposed metal parts not having a return path to the chassis will indicate an open circuit.

Leakage Current Hot Check

Plug the AC line cord directly into an AC power source (do not use an isolation transformer for this check).

Turn the AC power switch on.

Using a "Leakage Current Tester (Simpson Model 229 equivalent)", measure for current from all exposed metal parts of the cabinet (input/output terminals, screwheads, metal overlays, control shaft, etc.), particularly any exposed metal part having a return path to the chassis, to a known earth ground (water pipe, conduit, etc.). Any current measured must not exceed 1 mA.



AC Leakage Test

ANY MEASUREMENTS NOT WITHIN THE LIMITS OUTLINED ABOVE ARE INDICATIVE OF A POTENTIAL SHOCK HAZARD AND MUST BE CORRECTED BEFORE RETURNING THE SET TO THE CUSTOMER.

PRODUCT SAFETY NOTICE

Many electrical and mechanical parts in PIONEER set have special safety related characteristics. These are often not evident from visual inspection nor the protection afforded by them necessarily can be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual.

Electrical components having such features are identified by marking with a \triangle on the schematics and on the parts list in this Service Manual.

The use of a substitute replacement component which dose not have the same safety characteristics as the PIONEER recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire or other hazards.

Product Safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current PIONEER Service Manual. A subscription to, or additional copies of, PIONEER Service Manual may be obtained at a nominal charge from PIONEER.

[Important Check Points for Good Servicing]

In this manual, procedures that must be performed during repairs are marked with the below symbol.
Please be sure to confirm and follow these procedures.

1. Product safety



Please conform to product regulations (such as safety and radiation regulations), and maintain a safe servicing environment by following the safety instructions described in this manual.

- ① Use specified parts for repair.

Use genuine parts. Be sure to use important parts for safety.

- ② Do not perform modifications without proper instructions.

Please follow the specified safety methods when modification (addition/change of parts) is required due to interferences such as radio/TV interference and foreign noise.

- ③ Make sure the soldering of repaired locations is properly performed.

When you solder while repairing, please be sure that there are no cold solder and other debris.
Soldering should be finished with the proper quantity. (Refer to the example)

- ④ Make sure the screws are tightly fastened.

Please be sure that all screws are fastened, and that there are no loose screws.

- ⑤ Make sure each connectors are correctly inserted.

Please be sure that all connectors are inserted, and that there are no imperfect insertion.

- ⑥ Make sure the wiring cables are set to their original state.

Please replace the wiring and cables to the original state after repairs.
In addition, be sure that there are no pinched wires, etc.

- ⑦ Make sure screws and soldering scraps do not remain inside the product.

Please check that neither solder debris nor screws remain inside the product.

- ⑧ There should be no semi-broken wires, scratches, melting, etc. on the coating of the power cord.

Damaged power cords may lead to fire accidents, so please be sure that there are no damages.
If you find a damaged power cord, please exchange it with a suitable one.

- ⑨ There should be no spark traces or similar marks on the power plug.

When spark traces or similar marks are found on the power supply plug, please check the connection and advise on secure connections and suitable usage. Please exchange the power cord if necessary.

- ⑩ Safe environment should be secured during servicing.

When you perform repairs, please pay attention to static electricity, furniture, household articles, etc. in order to prevent injuries.
Please pay attention to your surroundings and repair safely.

2. Adjustments



To keep the original performance of the products, optimum adjustments and confirmation of characteristics within specification.
Adjustments should be performed in accordance with the procedures/instructions described in this manual.

3. Lubricants, Glues, and Replacement parts



Use grease and adhesives that are equal to the specified substance.
Make sure the proper amount is applied.

4. Cleaning



For parts that require cleaning, such as optical pickups, tape deck heads, lenses and mirrors used in projection monitors, proper cleaning should be performed to restore their performances.

5. Shipping mode and Shipping screws



To protect products from damages or failures during transit, the shipping mode should be set or the shipping screws should be installed before shipment. Please be sure to follow this method especially if it is specified in this manual.

CONTENTS

SAFETY INFORMATION	2
1. SERVICE PRECAUTIONS.....	7
1.1 NOTES ON SOLDERING	7
1.2 CHARGED SECTION AND HIGH VOLTAGE GENERATING POINT	8
2. SPECIFICATIONS.....	9
2.1 ACCESSORIES.....	9
2.2 SPECIFICATIONS	10
2.3 PANEL FACILITIES.....	11
3. BASIC ITEMS FOR SERVICE	14
3.1 CHECK POINTS AFTER SERVICING	14
3.2 QUICK REFERENCE	15
3.3 PCB LOCATION	17
3.4 JIGS LIST	18
3.5 CLEANING	18
4. BLOCK DIAGRAM	20
4.1 OVERALL WIRING DIAGRAM (1/2).....	20
4.2 OVERALL WIRING DIAGRAM (2/2).....	22
4.3 OVERALL BLOCK DIAGRAM (1/2)	24
4.4 OVERALL BLOCK DIAGRAM (2/2)	26
4.5 POWER SUPPLY UNIT	28
4.6 50 X DRIVE ASSY.....	29
4.7 50 Y DRIVE, 50 SCAN A and B ASSYS.....	30
4.8 POWER SUPPLY BLOCK of 50 X, Y DRIVE and 50 SCAN A, B ASSYS.....	31
4.9 50 ADDRESS L and S ASSYS	32
4.10 50 DIGITAL and SENSOR ASSYS.....	33
4.11 MAIN ASSY (DTV BLOCK DIAGRAM).....	34
4.12 POWER SUPPLY BLOCK of MAIN ASSY	36
4.13 TANSHI ASSY	38
4.14 50XGA LED and 50LED&IR ASSYS	39
4.15 POWER SUPPLY BLOCK of 50LED&IR and SIDE KEY ASSYS.....	40
5. DIAGNOSIS	41
5.1 POWER SUPPLY OPERATION.....	41
5.1.1 LED DISPLAY INFORMATION.....	41
5.1.2 POWER ON SEQUENCE	42
5.1.3 DETAILS OF POWER ON SEQUENCE.....	43
5.2 DIAGNOSIS FLOWCHART OF FAILURE ANALYSIS	45
5.2.1 WHOLE UNIT.....	45
5.2.2 POWER SUPPLY UNIT.....	47
5.2.3 DRIVE ASSY	48
5.2.4 DIGITAL ASSY	52
5.2.5 MAIN ASSY.....	53
5.2.6 VIDEO SYSTEM	54
5.2.7 AUDIO SYSTEM	60
5.3 DIAGNOSIS OF PD (POWER-DOWN)	63
5.3.1 BLOCK DIAGRAM OF THE POWER-DOWN SIGNAL	63
5.3.2 PD (POWER-DOWN) DIAGNOSIS OF FAILURE ANALYSIS	64
5.4 DIAGNOSIS OF SD (SHUTDOWN)	67
5.4.1 BLOCK DIAGRAM OF THE SHUTDOWN SIGNAL	67
5.4.2 SD (SHUTDOWN) DIAGNOSIS	68
5.5 NON-FAILURE INFORMATION.....	70
5.5.1 INFORMATION ON SYMPTOMS THAT DO NOT CONSTITUTE FAILURE	70
5.5.2 FUNCTION OF DECREASING THE BRIGHTNESS LEVEL	73
5.6 OUTLINE OF THE OPERATION	74
5.6.1 PANEL DRIVE-POWER ON / OFF FUNCTION	74
5.6.2 SPECIFICATION OF THE FAN CONTROL.....	75
5.6.3 PROCESSING IN ABNORMALITY	76
5.6.4 TRAP SWITCH.....	79

	6. SERVICE FACTORY MODE	80
	6.1 OUTLINE OF THE SERVICE FACTORY MODE	80
A	6.1.1 SERVICE FACTORY MODE TRANSITION CHART	80
	6.1.2 HOW TO ENTER/EXIT SERVICE FACTORY MODE	80
	6.1.3 FUNCTIONS WHEN ENTERING THE SERVICE FACTORY MODE	81
	6.1.4 REMOTE CONTROL CODE IN SERVICE FACTORY MODE	82
	6.1.5 PDP SERVICE REMOTE CONTROL	83
	6.1.6 FACTORY HIERARCHICAL TABLE	84
	6.1.7 INDICATIONS IN SERVICE FACTORY MODE	86
	6.2 DETAILS OF FACTORY MENU	88
	6.2.1 INFORMATION	88
	6.2.2 PANEL FACTORY (+)	98
	6.2.3 OPTION	108
	6.2.4 INITIALIZE	109
B	7. DISASSEMBLY	112
	7.1 CHART OF REMOVAL ORDER FOR THE MAIN PARTS AND BOARDS	112
	7.2 DISASSEMBLY	113
	7.3 DISASSEMBLY AND REASSEMBLY PRECAUTIONS FOR SPEAKER SYSTEM	119
	8. EACH SETTING AND ADJUSTMENT	120
	8.1 ADJUSTMENT REQUIRED WHEN THE UNIT IS REPAIRED OR REPLACED	120
	8.2 BACKUP OF THE EEPROM (DIGITAL ASSY)	122
	8.3 HOW TO CLEAR HISTORY DATA	125
	8.4 ADJUSTMENT WHEN THE SERVICE PANEL ASSY IS REPLACED	126
	8.5 ADJUSTMENT WHEN THE DRIVE ASSYS ARE REPLACED	135
	8.6 PRECAUTION ON REPLACEMENT OF THE POWER SUPPLY UNIT	138
C	9. RS-232C	139
	9.1 OUTLINE OF RS-232C COMMAND	139
	9.1.1 PREPARED TOOLS	139
	9.1.2 USING RS-232C COMMANDS	139
	9.2 LIST OF RS-232C COMMANDS	140
	9.3 DETAILS OF EACH COMMANDS	147
	9.3.1 QS1 (PANEL STATUS)	147
	9.3.2 QS2 (PANEL OPERATION DATA)	148
	9.3.3 QS3 (OTHER DATA ON THE PANEL)	149
	9.3.4 QAJ (PANEL ADJUSTMENT DATA)	150
	9.3.5 QPW (VIDEO ADJUSTMENT DATA OF THE PANEL)	151
	9.3.6 QPM (PULSE METER VALUE)	151
D	9.3.7 QPD (PD LOGS)	152
	9.3.8 QSD (SD LOGS)	153
	9.3.9 QSE (DESTINATION PECULIAR INFORMATION)	154
	9.3.10 QMT (TEMPERATURE / FAN ROTATION / ROOM LIGHT SENSOR)	154
	9.3.11 QNG (SHUTDOWN INFORMATION OF MTB)	155
	9.3.12 QSI (INPUT SIGNAL DATA)	157
	9.3.13 DRV (PANEL DRIVE-POWER ON / OFF)	157
	9.3.14 FAY / FAN (ADJ. COMMANDS PERMISSION / PROHIBITION)	158
	9.3.15 FAJ / UAJ / CBU / BCP (BACKUP FUNCTION FOR ADJUSTMENT VALUE)	158
	10. EXPLODED VIEWS AND PARTS LIST	160
	10.1 PACKING SECTION	160
	10.2 REAR SECTION	162
E	10.3 FRONT SECTION	164
	10.4 CHASSIS SECTION (1/2)	166
	10.5 CHASSIS SECTION (2/2)	168
	10.6 PANEL CHASSIS SECTION	170
	10.7 MULTI BASE SECTION	172
	10.8 PDP SERVICE ASSY 508	174
	10.9 TABLE TOP STAND	176
	10.10 SPEAKER SYSTEM (PACKING)	177
	10.11 CS ASSY	178

1. SERVICE PRECAUTIONS

1.1 NOTES ON SOLDERING

- For environmental protection, lead-free solder is used on the printed circuit boards mounted in this unit.
Be sure to use lead-free solder and a soldering iron that can meet specifications for use with lead-free solders for repairs accompanied by reworking of soldering.
- Compared with conventional eutectic solders, lead-free solders have higher melting points, by approximately 40 °C.
Therefore, for lead-free soldering, the tip temperature of a soldering iron must be set to around 373 °C in general, although the temperature depends on the heat capacity of the PC board on which reworking is required and the weight of the tip of the soldering iron.

Compared with eutectic solders, lead-free solders have higher bond strengths but slower wetting times and higher melting temperatures (hard to melt/easy to harden).

The following lead-free solders are available as service parts:

- Parts numbers of lead-free solder:
GYP1006 1.0 in dia.
GYP1007 0.6 in dia.
GYP1008 0.3 in dia.

1.2 CHARGED SECTION AND HIGH VOLTAGE GENERATING POINT

■ Charged Section

The places where the commercial AC power is used without passing through the power supply transformer.

If the places are touched, there is a risk of electric shock. In addition, the measuring equipment can be damaged if it is connected to the GND of the charged section and the GND of the non-charged section while connecting the set directly to the commercial AC power supply. Therefore, be sure to connect the set via an insulated transformer and supply the current.

■ High Voltage Generating Point

The places where voltage is 100 V or more except for the charged places described above. If the places are touched, there is a risk of electric shock.

The VSUS voltage remains for several minutes after the power to the unit is turned off. These places must not be touched until about 10 minutes after the power is turned off, or it is confirmed with a tester that there is no residual VSUS voltage.

If the procedures described in “5.6.1 PANEL DRIVE-POWER ON/OFF FUNCTION” are performed before the power is turned off, the voltage will be discharged in about 30 seconds.

POWER SUPPLY UNIT	(205 V)
50 X DRIVE Assy.....	(205 V)
50 Y DRIVE Assy.....	(-230 V to 500 V)
50 SCAN A Assy.....	(-230 V to 500 V)
50 SCAN B Assy.....	(-230 V to 500 V)

■ : Part is Charged Section.

■ : Part is the High Voltage Generating Points other than the Charged Section.




Fig. High Voltage Generating Point (Rear view)

PDP-5080HD


2. SPECIFICATIONS

2.1 ACCESSORIES


- Remote control unit (AXD1550)



- Alkaline dry cell battery (LR6, AA)



- Binder Assy (AEC1908)




- Cleaning cloth (AED1285)



- Warranty card




- Operating instructions (ARE1471)




- Band assy (AXY1192)

- Screw: ×2
- Plastic band: ×2




- Power cord (2 m/6.6 feet) (ADG1215)




Speaker accessories

- Speaker cable: ×2 (SDS1202)




- Bracket Assy (S): ×2 (SXG1125)



Brackets for side: ×2

- Bracket Assy (C) (SXG1126)



Brackets for center

- Screw (M5 x 10 mm: Black): ×9 (BMZ50P100FTB)



2.2 SPECIFICATIONS

A

Item	50" plasma display model: PDP-5080HD	
Number of pixels	1365 × 768 pixels	
Audio Amplifier	17 W + 17 W (1 kHz, 10 %, 6 Ω)	
Speakers	Woofer: 4.8 cm x 13 cm cone type Tweeter: 2.5 cm semidome type	
Surround System	SRS FOCUS/SRS/SRS TruBass	
Power Requirement	120 V AC, 60 Hz, 371 W (23 W Standby)	
Weight	Main unit: 34.8 kg (76.7 lbs.) Stand: 2.2 kg (4.9 lbs.) (including bolts) Speaker system: 3.3 kg (7.28 lbs.) (including cables, mounting fittings and screws) Total: 40.3 kg (88.8 lbs.)	

B

Reception System (Digital)	ATSC Digital TV system
Circuit type	8VSB/64QAM/256QAM/QPSK demodulation
Tuner	VHF/UHF
CATV	Ch. 2 to 135
Audio format	Dolby Digital

C


Reception System (Analog)	American TV standard NTSC system
Circuit type	Video signal detection PLL full synchronous detection, PLL digital Synthesizer system
Tuner	VHF/UHF
CATV	ANT/CABLE A IN Ch. 1 to 135 ANT B IN Ch. 1 to 125
Audio multiplex	BTSC system

D

Terminals	Rear	ANT/CABLE A IN	75 Ω UNBAL, F Type for DTV/VHF/UHF/CATV in
		ANT B IN	75 Ω UNBAL, F Type for VHF/UHF/CATV in
		INPUT 1	S-VIDEO in, VIDEO in, AUDIO in
		INPUT 2	COMPONENT VIDEO in, VIDEO in, AUDIO in
		INPUT 4	HDMI in*, AUDIO in
		PC INPUT	Analog RGB in, AUDIO in
		INPUT 5	HDMI in*, AUDIO in
		INPUT 6	HDMI in*
		INPUT 7	HDMI in*
		AUDIO OUT	AUDIO out (Fixed)
		DIGITAL OUT	Optical
		CONTROL OUT	1
		SPEAKERS	6 Ω to 16 Ω
		SUB WOOFER	Variable
		CableCARD	Point of Deployment
	Side	INPUT 3	COMPONENT VIDEO in, VIDEO in, AUDIO in
		PHONES	16 Ω to 32 Ω recommended
		USB	USB in**
	On-screen display languages		English/French/Spanish

* This conforms to HDMI1.3 and HDCP1.1.
HDMI (High Definition Multimedia Interface) is a digital interface that handles both video and audio using a single cable.
HDCP (High-bandwidth Digital Content Protection) is a technology used to protect copyrighted digital contents that use the Digital Visual Interface (DVI).
** This conforms to USB 1.1 and 2.0 .
• Design and specifications are subject to change without notice.


Dimensions



PDP-5080HD

2.3 PANEL FACILITIES

■ Front Section




- | | | | |
|---|--|----|--|
| 1 | ⏻ button | 10 | CHANNEL UP/DOWN buttons (LEFT/RIGHT buttons*) |
| 2 | POWER ON indicator | 11 | TV GUIDE button* |
| 3 | STANDBY indicator | 12 | USB port |
| 4 | SLEEP indicator | 13 | PHONES output terminal |
| 5 | Room Light Sensor | 14 | INPUT 3 terminals (COMPONENT VIDEO: Y, PB, PR) |
| 6 | Remote control sensor | 15 | INPUT 3 terminal (VIDEO) |
| 7 | STANDBY/ON button | 16 | INPUT 3 terminals (AUDIO) |
| 8 | INPUT button (ENTER button*) | | |
| 9 | VOLUME UP/DOWN buttons (UP/DOWN buttons*) | | |

The buttons with asterisks (*) can operate the TV Guide On Screen™ system.

A

■ Rear Section



C

D


E

F

- | | | | |
|----|---|----|--|
| 1 | CableCARD™ slot | 15 | AUDIO OUT terminals (AUDIO) |
| 2 | ANT/CABLE A IN terminal | 16 | INPUT 1 terminals (AUDIO) |
| 3 | AC IN terminal | 17 | INPUT 2 terminals (AUDIO) |
| 4 | INPUT 4 terminal (HDMI) | 18 | INPUT 4 terminals (AUDIO) |
| 5 | INPUT 5 terminal (HDMI) | 19 | INPUT 5 terminals (AUDIO) |
| 6 | INPUT 6 terminal (HDMI) | 20 | INPUT 2 terminal (VIDEO) |
| 7 | INPUT 7 terminal (HDMI) | 21 | DIGITAL OUT terminal (OPTICAL) |
| 8 | PC INPUT terminal (ANALOG RGB) | 22 | PC INPUT terminal (AUDIO) |
| 9 | CONTROL OUT terminal | 23 | INPUT 2 terminals (COMPONENT VIDEO: Y, Pb, Pr) |
| 10 | RS-232C terminal (used for factory setup) | 24 | SPEAKERS (R/L) terminals |
| 11 | ANT B IN terminal | 25 | SPEAKERS (R) terminal (Speaker side) |
| 12 | INPUT 1 terminal (S-VIDEO) | 26 | SPEAKERS (L) terminal (Speaker side) |
| 13 | INPUT 1 terminal (VIDEO) | | |
| 14 | SUB WOOFER terminal | | |

■ Remote Control Unit

This section describes the functions of the buttons available when the mode switch has been set to TV.



- 1 **TV** : Turns on the power to the plasma display or places it into standby mode.
- 2 **Transmission confirmation LED**
- 3 **INPUT**: Selects an input source of the plasma display. ("INPUT 1", "INPUT 2", "INPUT 3", "INPUT 4", "INPUT 5", "INPUT 6" and "INPUT 7")
- 4 **SCREEN SIZE**: Selects the screen size.
- 5 **AV SELECTION**: Selects audio and video settings. (AV source: OPTIMUM, STANDARD, DYNAMIC, MOVIE, GAME, USER. PC source: STANDARD, USER.)
- 6 **INFO**: Displays a channel banner when a TV program is being watched.
When the TV Guide On Screen™ system is in operation, displays information about the currently highlighted channel (if available).
- 7 **HOME MENU**: Displays the HOME MENU screen.
MENU: Displays a panel menu when the TV Guide On Screen™ system is in operation.
- 8 **DAY +/-**: Jumps to the next or previous day of program listings in the TV Guide On Screen™ Listing service.
- 9 **↑/↓/←/→**: Selects a desired item on the menu screen.
- 10 **HDMI CONTROL**: Displays the HDMI Control menu.
- 11 **FAVORITE CH (A, B, C, D)**:
Selects any of the four preset channels.

While watching, you can toggle the set channels by pressing **A**, **B**, **C** and **D**.

- 12 **0 to 9**: Selects the channel.
- 13 **•(dot)**: Enters a dot.
- 14 **CH +/-**: Selects the channel.
- 15 **SPLIT**: Switches the screen mode among 2-screen, picture-in-picture, and single-screen.
- 16 **FREEZE**: Freezes a frame from a moving image. Press again to cancel the function.
- 17 **MTS**: Selects MTS/SAP or language depending on the program being watched.
- 18 **ANT**: Selects the antenna (A, B).
- 19 **PC**: Selects the PC terminal as an input source.
- 20 **DISPLAY**: Displays the channel information.
- 21 **TV GUIDE**: Displays the TV Guide On Screen™ system.
- 22 **ENTER**: Executes a command.
- 23 **PAGE +/-** (for the TV Guide On Screen™ system): Scrolls the program listing screen vertically.
- 24 **RETURN**: Returns to the previous menu screen.
- 25 **CH ENTER**: Executes a channel number.
- 26 **CH RETURN**: Returns to the previous channel. This button is disabled while the TV Guide On Screen™ system is displayed.
- 27 **VOL +/-**: Sets the volume.
- 28 **MUTING**: Mutes the sound.
- 29 **SHIFT**: Moves the location of the small screen when in the picture-in-picture mode.
- 30 **SWAP**: Switches between the two screens when in the 2-screen or picture-in-picture mode.

Luminous remote control buttons (main unit only)

All buttons on the remote control unit are luminous and gather and store light. This enables quick access to the desired function when performing operations in dark places.

Note

- When using the remote control unit, point it at the plasma display.

1234

3. BASIC ITEMS FOR SERVICE

3.1 CHECK POINTS AFTER SERVICING

A

Items to be checked after repair (PDP)

To ensure the quality of the product after repair, check the recommended items shown below:

No.	Procedures	Item to be checked
1	Check if all the symptoms pointed out by the customer have been addressed.	The symptoms in question must not be reproduced.
2	Connect the peripheral equipment.	Connect all external peripheral equipment as originally connected and check if the connections are correct.
3	Check the video and audio.	Tune in to the stations that the customer would normally receive and check if video and audio are normal.
4	Check the buttons and controls.	Use the buttons and controls on the remote control unit and main unit and check if they operate properly.
5	Check the cabinet.	Check for any scratches or dirt that have been made or attached on the cabinet after receiving the product for repair.

See the table below for the items to be checked regarding video and audio:

Item to be checked regarding video	Item to be checked regarding audio
Block noise	Distortion
Horizontal noise	Noise
Dot noise	Volume too low
Disturbed image (video jumpiness)	Volume too high
Too dark	Volume fluctuating
Too bright	Sound interrupted
Mottled color	

3.2 QUICK REFERENCE

Quick Reference upon Service Visit ① Notes, PD/SD diagnosis, and methods for various settings

Notes when visiting for service

1. Notes when disassembling/reassembling

① Rear case

When reassembling the rear case, the screws must be tightened in a specific order. Be careful not to tighten them in the wrong order forcibly. For details, see "Rear Case" in "7. DISASSEMBLY".

② Attaching screws for the HDMI connector

When attaching the HDMI connector after replacing the Main Assy, secure the HDMI connector manually with a screwdriver, but not with an electric screwdriver. If you tighten the screws too tightly with an electric screwdriver, the screw heads may be damaged, in which case the screws cannot be untightened/tightened any more.

2. On parts replacement

① How to discharge before replacing the Assys

A charge of significant voltage remains in the Plasma Panel even after the power is turned off. Safely discharge the panel before replacement of parts, in either manner indicated below:

A: Let the panel sit at least for 3 minutes after the power is turned off.
B: Turn the Large Signal System off before the power is turned off then, after 1 minute, turn the power off.

For details, see "5.6.1 PANEL DRIVE-POWER ON/OFF FUNCTION".

② On the settings after replacement of the Assys






Some boards need settings made after replacement of the Assys. For details, see "8. EACH SETTING AND ADJUSTMENT".

3. On various settings

① Setting in Factory mode

After a Mask indication into the panel is performed, be sure to set the Mask setting to "OFF" then exit Factory mode.

PD/SD			
Item		No. of LEDs flashing	
		Red	Blue
Panel section	SQ_LSI		Blue 1
	Communication with the module IIC		Blue 2
	DIGITAL-RST2		Blue 3
	Panel high temperature		Blue 4
MTB section	Audio/ Short-circuit SP terminal		Blue 5
	Communication with the Module UCOM		Blue 6
	Main 3-wire serial communication		Blue 7
	Main IIC communication		Blue 8
	Communication with the Main UCOM		Blue 9
	FAN		Blue 10
	Unit high temperature		Blue 11
	Digital Tuner communication		Blue 12
	MTB-RST2/RST4		Blue 13
	Home Media Gallery		Blue 14
	Main EEPROM		Blue 15
POWER		Red 2	
SCAN		Red 3	
SCN-5V		Red 4	
Y-DRIVE		Red 5	
Y-DCDC		Red 6	
Y-SUS		Red 7	
ADRS		Red 8	
X-DRIVE		Red 9	
X-DCDC		Red 10	
X-SUS		Red 11	
DIG-DCDC		Red 12	
UNKNOWN		Red 15	

LED Display Information	
① TRAP SW	
② Rewriting software	
③ PD (2-15)	
④ SD (1-15)	
⑤ No backup	
This indication does not display all LED patterns. For details, please refer to 5.1.1 LED DISPLAY INFORMATION.	

How to locate several items on the Factory menu

{ } : Item on the Factory menu
[] : Key on the remote control unit
" " : Screen indication

1. Confirmation of accumulated power-on time and power-on count

Select {INFORMATION} then {HOUR METER}.
(After entering Factory mode, press [↓] five times.)

2. Confirmation of the Power-down and Shutdown histories

① Panel system

PD: Select {PANEL FACTORY} then {POWER DOWN}.
(After entering Factory mode, press [MUTING] once, press [ENTER/SET], then press [↓] three times.)

SD: Select {PANEL FACTORY} then {SHUT DOWN}.
(After entering Factory mode, press [MUTING] once, press [ENTER/SET], then press [↓] four times.)

② MTB section

Select {INFORMATION} then {MAIN NG}.
(After entering Factory mode, press [↓] three times.)

3. How to display the Mask indication

① Mask indication in the panel side

- Select {PANEL FACTORY} then {RASTER MASK SETUP}.
(After entering Factory mode, press [MUTING] once, press [ENTER/SET], then press [↓] 8 times.)
- Press [ENTER/SET], then select a Mask indication, using [↑] or [↓].

Adjustments and Settings after replacement of the Assys (Procedures in Factory mode)

1. Digital Video Assy: Transfer of backup data

- Select {PANEL FACTORY}, {ETC}, then {BACKUP DATA}. (After entering Factory mode, press [MUTING] once, press [ENTER/SET], press [↓] seven times, then press [ENTER/SET].)
- Select {TRANSFER}, using [→], then hold [ENTER/SET] pressed for at least 5 seconds.
- After transfer of backup data is completed, {ETC} is automatically selected, and the LED on the front panel returns to normal lighting.

2. MAIN Assy: Execution of FINAL SETUP.

- Select {INITIALIZE} then {FINAL SETUP}, then press [ENTER/SET]. (After entering Factory mode, press [MUTING] three times, then press [↓] four times.)
- Select "YES", using [→]. Then hold [ENTER/SET] pressed for at least 5 seconds.
- After "FINAL SETUP IS COMPLETE" is displayed on the screen, turn the POWER switch of the main unit off.

3. POWER SUPPLY Unit: Clearance of the accumulated power-on count and maximum temperature value

- Select {PANEL FACTORY}, {ETC}, then {P COUNT INFO}. (After entering Factory mode, press [MUTING] once, press [ENTER/SET], press [↓] seven times, press [ENTER/SET], then press [↓] six times.)
- Press [→] to select "CLEAR". Hold [ENTER/SET] pressed for at least 5 seconds. After clearance is completed, "ETC" is automatically selected. Clear the maximum temperature value (MAX TEMP) in the same manner.


4. Other Assys: Clearance of the maximum temperature value

- Select {PANEL FACTORY}, {ETC}, then {MAX TEMP}. (After entering Factory mode, press [MUTING] once, press [ENTER], press [↓] seven times, press [ENTER/SET], then press [↓] seven times.)
- Press [→] to select "CLEAR". Hold [ENTER/SET] pressed for at least 5 seconds. After clearance is completed, "ETC" is automatically selected.

Quick Reference upon Service Visit ②

Mode transition and structure of layers in Service Factory mode

Mode transition in Service Factory mode



Structure of Layers in Service Factory Mode

INFORMATION mode	
1. VERSION (1)	The software versions for each microcomputer
2. VERSION (2)	The Flash memory versions for each device
3. VERSION (3)	The Flash memory versions for each device
4. MAIN NG	The shutdown message ID/event times (Going Clear mode by [ENTER/SET] key)
4-1. CLEAR	Select Yes by [→] key → pushing and hold [ENTER/SET] key
5. TEMPERATURE	The temperature/FAN rotating status/Room Light Sensor
6. HOUR METER	The HOUR METER/P-COUNT information
6-1. CLEAR	Select Yes by [→] key → pushing and hold [ENTER/SET] key
7. HDMI SIGNAL INFO 1	The information of HDMI information files
8. HDMI SIGNAL INFO 2	The information of HDMI information files
9. VDEC SIGNAL INFO 1	The signal information of VDEC
10. VDEC SIGNAL INFO 2	The signal information of VDEC
11. DTV TUNING STATUS 1	Detail information for DTV
12. DTV TUNING STATUS 2	Detail information for DTV
13. DTV TUNING STATUS 3	Detail information for DTV
14. DTV TV-GUIDE BER	For production line use
15. DEBUG INFO	For factory use
PANEL FACTORY mode	Refer to [PANEL FACTORY MODE]
OPTION mode	
1. EDID WRITE MODE	For factory use
2. ANTENNA MODE	For production line use
3. AFT	For production line use
4. SYNC DET	For technical analysis
INITIALIZE mode	
1. SIDE MASK LEVEL	For factory use
1-1. SIDE MASK LEVEL	
2. FINAL SETUP	Set to Factory default settings (it should perform after replacing a MAIN Assy)
2-1. DATA RESET	
3. HMG/HG SERVICE MODE	Information for a USB device is displayed
3-1. MODE SHIFT	
4. Wide XGA AUTO	For technical analysis

Structure of Layers in Panel Factory Mode 1


1. PANEL INFORMATION	Version indication of the panel
2. PANEL WORKS	Indications of the accumulated power-on time, pulse-meter count, and power-on count of the panel
3. POWER DOWN	Indication of the Power-down history
4. SHUT DOWN	Indication of the Shutdown history
5. PANEL-1 ADJ (+)	
1. VOL SUS	Settings required after replacement of the panel
2. VOL OFFSET	
...	
8. VOL YNOFS4	
9. RESET1ST_KSB	Modification not required because these items are basically for factory presetting
10. RESET2ND_KSB	
...	
23. YSTL_FMR_HZ	
24. SUS FREQ	For AM noise prevention (Depending on the mode, brightness of the screen changes.) For confirmation of the result of the setting change, the unit must be turned off then back on again.
6. PANEL-2 ADJ (+)	
1. R-HIGH	Parameters for the WB adjustment of the panel, which are required during adjustment after panel replacement
2. G-HIGH	
3. B-HIGH	
4. R-LOW	
5. G-LOW	Setting of the power consumption. A setting table is available for each vertical signal.
6. B-LOW	
7. ABL	

To "Structure of Layers in Panel Factory Mode 2"

Structure of Layers in Panel Factory Mode 2

7. PANEL FUNCTION (+)	
1. R-LEVEL	Items for use by engineers
2. G-LEVEL	
3. B-LEVEL	
4. ADDRESS L1	
5. ADDRESS L2	
...	
11. ADDRESS U4	
12. STK MODE	
8. ETC (+)	
1. BACKUP DATA	For transferring backup data (after replacement of the DIGITAL Assy)
2. DIGITAL EEPROM	To clear data of the digital video
3. PD INFO.	For clearance of data for the corresponding items. The clearing method is the same: Select "CLEAR", using [→], then hold [ENTER/SET] pressed for at least 5 seconds. After clearance is completed, (ETC) is automatically selected.
4. SD INFO.	
5. HR-MTR INFO.	
6. PM/B1-B5	
7. P COUNT INFO.	
8. MAX TEMP.	
9. RASTER MASK SETUP (+)	
1. MASK OFF	For use while Raster Mask (full mask) is displayed. Use [↑] or [↓] to select the type of mask.
2. RST MASK 01	
...	
26. RST MASK 25	
10. PATTEN MASK SETUP (+)	
1. MASK OFF	For use while Pattern Mask is displayed. Use [↑] or [↓] to select the type of mask.
2. PTN MASK 01	
...	
50. PTN MASK 49	
11. COMBI MASK SETUP (+)	
1. MASK OFF	For use while Combination Mask is displayed. Use [↑] or [↓] to select the type of mask.
2. CMB MASK 01	
...	
18. CMB MASK 17	

3.3 PCB LOCATION



Note:
The wiring shown in the photo is different from the actual wiring, because the product in the photo is a prototype. Upon servicing, be sure to restore the original wiring of the unit after repair work.

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
LIST OF ASSEMBLIES							
NSP	50 ADDRESS L ASSY		AWW1264		TANSI ASSY		AWW1279
NSP	50 ADDRESS S ASSY		AWW1265		SIDE IO ASSY		AWW1274
NSP	50 SCAN A ASSY		AWW1268		50XGA LED ASSY		AWW1280
	└ IC2801 - IC2806		SN755875PZT-P		50LED&IR ASSY		AWW1281
NSP	50 SCAN B ASSY		AWW1269		SIDE KEY ASSY		AWW1275
	└ IC2901 - IC2906		SN755875PZT-P				
	50 X DRIVE ASSY		AWV2447		POD ASSY		AWW1295
	50 Y DRIVE ASSY		AWW1260	⚠	POWER SUPPLY UNIT		AXY1157
	XGA POWER SW ASSY		AWW1261		PDP SERVICE ASSY 508		AWU1277
	50 DIGITAL ASSY		AWW1270				
	SENSOR ASSY		AWW1272				
⚠	MAIN ASSY		AWV2455				

1

A

5

E

■

5

■

6

■

7

■

8

■

A

■

B

■

C

■

D

■

E

■

F

■

5

■

6

■

7


■

8

■

4. BLOCK DIAGRAM

4.1 OVERALL WIRING DIAGRAM (1/2)



CONNECTOR PIN ASSIGN

CN3501	D15	→	CN1602	AD1
CN3502	D16	→	CN1802	AD1
CN3503	D17	→	CN1802	AD1
CN3504	D18	→	CN1602	AD1

1-40. NC	21-20. CP	1. VH	15. IC5V
2-39. ADR_PD	22-19. NC	2. VH	16. IC5V
3-38. PSIZE	23-18. GND	3. NC	
4-37. GND	24-17. NC	4. NC	
5-36. V+8V	25-16. CLK_N	5. GNDH	
6-35. V+8V	26-15. CLK_P	6. S1_R	
7-34. GND	27-14. NC	7. S1_L	
8-33. GND	28-13. GND	8. OC2	
9-32. NC	29-12. NC	9. OC2	
10-31. AN	30-11. DN	10. OC1	
11-30. AP	31-10. DP	11. CLK	
12-29. NC	32-9. NC	12. CLK	
13-28. GND	33-8. GND	13. GNDH	
14-27. NC	34-7. GND	14. GNDH_R	
15-26. BN	35-6. V+3.3V_D	15. IC5V	
16-25. BP	36-5. V+3.3V_D		
17-24. NC	37-4. GND		
18-23. GND	38-3. NC		
19-22. NC	39-2. LS2		
20-21. CN	40-1. GND		

CN2502	Y3	↓	CN2801	SA1
--------	----	---	--------	-----

1. VH	15. IC5V
2. VH	
3. NC	
4. NC	
5. GNDH	
6. S1_R	
7. S1_L	
8. OC2	
9. OC2	
10. OC1	
11. CLK	
12. CLK	
13. GNDH	
14. GNDH_R	
15. IC5V	

CN2501	Y2	↓	CN2901	SB1
--------	----	---	--------	-----

1. VH	15. IC5V
2. VH	
3. NC	
4. NC	
5. GNDH	
6. S1_R	
7. S1_L	
8. OC2	
9. OC2	
10. OC1	
11. CLK	
12. CLK	
13. GNDH	
14. GNDH_R	
15. IC5V	

CN3505	D19	→	CN1001	X1
--------	-----	---	--------	----

1-40. XCN_PD	21-20. GND	1. VH	15. IC5V
2-39. NC	22-19. XKOF51_ADJ	2. VH	
3-38. S1	23-18. XKOF52_ADJ	3. NC	
4-37. XSUS_B	24-17. GND	4. NC	
5-36. GND	25-16. XDRV_PD	5. GNDH	
6-35. XSUS_U	26-15. XDD_PD	6. S1_R	
7-34. GND	27-14. PSW2	7. S1_L	
8-33. XSUS_D	28-13. GND	8. OC2	
9-32. GND	29-12. NC	9. OC2	
10-31. XSUS_G	30-11. NC	10. OC1	
11-30. GND	31-10. NC	11. CLK	
12-29. XPRST	32-9. NC	12. CLK	
13-28. GND	33-8. NC	13. GNDH	
14-27. XKOF51	34-7. NC	14. GNDH_R	
15-26. GND	35-6. NC	15. IC5V	
16-25. XKOF52	36-5. NC		
17-24. GND	37-4. NC		
18-23. XSOF2_D	38-3. NC		
19-22. GND	39-2. NC		
20-21. XSUS_MUTE	40-1. XSUS_PD		

CN3506	D20	→	CN2001	Y1
--------	-----	---	--------	----

1-50. YCN_PD	26-25. YKNOF53	1. VH	15. IC5V
2-49. SCNV_PD	27-24. YKNOF54	2. VH	
3-48. S1	28-23. GND	3. NC	
4-47. GND	29-22. YNOFS	4. NC	
5-46. CLR	30-21. VRST_D	5. GNDH	
6-45. CLK	31-20. YSOF2_D	6. S1_R	
7-44. GND	32-19. YSOF2_D	7. S1_L	
8-43. E	33-18. GND	8. OC2	
9-42. OC2	34-17. VOFS_ADJ	9. OC2	
10-41. OC1	35-16. VYPRST_ADJ	10. OC1	
11-40. GND	36-15. GND	11. CLK	
12-39. XSUS_B	37-14. NC	12. CLK	
13-38. XSUS_U	38-13. YKNOF51_2_ADJ	13. GNDH	
14-37. GND	39-12. YKNOF53_ADJ	14. GNDH_R	
15-36. XSUS_D	40-11. YKNOF54_ADJ	15. IC5V	
16-35. XSUS_G	41-10. GND		
17-34. GND	42-9. YRSv1		
18-33. VPR_U	43-8. YRSv2		
19-32. XSUS_MUTE	44-7. YRSv3		
20-31. GND	45-6. GND		
21-30. XSUS_MSK_H	46-5. YDD_PD		
22-29. XSUS_MSK_L	47-4. VSUS_PD		
23-28. GND	48-3. SCAN_PD		
24-27. YKNOF51	49-2. YDRV_PD		
25-26. YKNOF52	50-1. PSW2		

CN3507	D21	→	CN3508	D22
--------	-----	---	--------	-----

1. VH	15. IC5V
2. VH	
3. NC	
4. NC	
5. GNDH	
6. S1_R	
7. S1_L	
8. OC2	
9. OC2	
10. OC1	
11. CLK	
12. CLK	
13. GNDH	
14. GNDH_R	
15. IC5V	

CN3509	D23	→	CN3510	D24
--------	-----	---	--------	-----


1. VH	15. IC5V
2. VH	
3. NC	
4. NC	
5. GNDH	
6. S1_R	
7. S1_L	
8. OC2	
9. OC2	
10. OC1	
11. CLK	
12. CLK	
13. GNDH	
14. GNDH_R	
15. IC5V	

CN3511	D25	→	CN3512	D26
--------	-----	---	--------	-----

1. VH	15. IC5V
2. VH	
3. NC	
4. NC	
5. GNDH	
6. S1_R	
7. S1_L	
8. OC2	
9. OC2	
10. OC1	
11. CLK	
12. CLK	
13. GNDH	
14. GNDH_R	
15. IC5V	

CN3513	D27	→	CN3514	D28
--------	-----	---	--------	-----

1. VH	15. IC5V
2. VH	
3. NC	
4. NC	
5. GNDH	
6. S1_R	
7. S1_L	
8. OC2	
9. OC2	
10. OC1	
11. CLK	
12. CLK	
13. GNDH	
14. GNDH_R	
15. IC5V	



4.2 OVERALL WIRING DIAGRAM (2/2)

A


B

C


D

E

F



UNIT



CONNECTOR PIN ASSIGN

CN4004 M6 → CN8804 IO4

1-50. GND	26-25. GND
2-49. TEMP2	27-24. INPUT2_V
3-48. NC	28-23. GND
4-47. V+3_3V_UCOM	29-22. INPUT1_V
5-46. NC	30-21. GND
6-45. GND	31-20. INPUT1_SY
7-44. GND	32-19. GND
8-43. GND	33-18. INPUT1_S2
9-42. GND	34-17. GND
10-41. GND	35-16. INPUT1_SC
11-40. GND	36-15. GND
12-39. GND	37-14. INPUT1_SPLUG
13-38. INPUT3_PLUG	38-13. GND
14-37. GND	39-12. INPUT2_PLUG
15-36. INPUT3_Y	40-11. GND
16-35. GND	41-10. INPUT2_Y
17-34. INPUT3_PB	42-9. GND
18-33. GND	43-8. INPUT2_PB
19-32. INPUT3_PR	44-7. GND
20-31. GND	45-6. INPUT2_PR
21-30. AIR_R	46-5. GND
22-29. GND	47-4. GND
23-28. AIR_L	48-3. GND
24-27. GND	49-2. GND
25-26. INPUT3_V	50-1. GND

CN4001 M8 → CN8803 IO3

1-40. V+5V_A	21-20. I2S_SDATA_HNM
2-39. NC	22-19. I2S_BCLK_HNM
3-38. V+3_3V_STB	23-18. I2S_LRCLK_HNM
4-37. NC	24-17. GND
5-36. GND	25-16. I2S_SDATA_HDMI
6-35. GND	26-15. I2S_BCLK_HDMI
7-34. GND	27-14. I2S_LRCLK_HDMI
8-33. GND	28-13. GND
9-32. IR_OUT	29-12. I2S_SDATA_DTV
10-31. GND	30-11. I2S_BCLK_DTV
11-30. GND	31-10. I2S_LRCLK_DTV
12-29. AC_AM_MUTE	32-9. GND
13-28. GND	33-8. SCL_AV
14-27. AC_HP_MUTE	34-7. SDA_AV
15-26. HP_PLUG	35-6. AC_A_MUTE
16-25. GND	36-5. RST_MSP
17-24. SPDIF_HNM	37-4. OTW
18-23. GND	38-3. A_NG_B
19-22. SPDIF_DTV	39-2. IO_DET
20-21. GND	40-1. GND

CN4005 M33 → CN9402 C1

1-40. GND	21-20. IORD
2-39. POD_VCC	22-19. MA11
3-38. POD_VCC	23-18. POD_VS1
4-37. POD_VCC	24-17. OE
5-36. MDIA5	25-16. CE2A
6-35. RDY/IRQA	26-15. MA10
7-34. MDIA2	27-14. MDOA7
8-33. WE	28-13. CE1A
9-32. MDIA1	29-12. MDOA6
10-31. GND	30-11. MD7
11-30. MOCCLKA/MA14	31-10. MDOA5
12-29. GND	32-9. MD5
13-28. MDIA0	33-8. MDOA4
14-27. MA13	34-7. MD5
15-26. M1STRTA	35-6. MDOA3
16-25. GND	36-5. MDOA2
17-24. POD_CLK/MA8	37-4. CD1A
18-23. GND	38-3. MD3
19-22. LOWR	39-2. GND
20-21. POD_DATA/MA9	40-1. GND

CN4006 M34 → CN9401 C2

1-40. GND	21-20. WAITA
2-39. PTXDB	22-19. OOB_EN/MA4
3-38. GND	23-18. RSTA
4-37. PRXDB	24-17. TX
5-36. GND	25-16. POD_VS2
6-35. CDA2	26-15. TX_EN
7-34. MDOA2	27-14. MDTA7
8-33. MD2	28-13. TX_O
9-32. MDOA1	29-12. MDTA6
10-31. MD1	30-11. MA12
11-30. MDOA0	31-10. MDIA5
12-29. MD0	32-9. GND
13-28. M1STRTA	33-8. MICLKA
14-27. MA0	34-7. GND
15-26. MDOA1A	35-6. MDIA4
16-25. MA1	36-5. MIVALA
17-24. REG	37-4. POD_VPP
18-23. MA2	38-3. POD_VPP
19-22. GND	39-2. GND
20-21. MA3	40-1. GND

CN4002 M35 → CN7851 HN1


1. TXD_HNM	11. HNM_V
2. RXD_HNM	12. GND
3. RST_HNM	13. I2S_SDATA_HNM
4. GND	14. NC
5. HNM_SPDIF	15. GND
6. GND	16. HNM_Y
7. I2S_BCLK_HNM	17. GND
8. HNM_L	18. HNM_PB
9. I2S_LRCLK_HNM	19. GND
10. GND	20. HNM_PR

×1	PDP-5080HD	AWV2469-
----	------------	----------

The \triangle mark found on some component parts should be replaced with same parts (safety regulation authorized) of identical designation.


OVERALL DIAGRAM
PDP-5080HD


4.3 OVERALL BLOCK DIAGRAM (1/2)





4.4 OVERALL BLOCK DIAGRAM (2/2)






4

A





4.6 50 X DRIVE ASSY

50 X DRIVE ASSY




4.7 50 Y DRIVE, 50 SCAN A and B ASSYS

50 SCAN B ASSY
(HIGH SIDE)




50 SCAN A ASSY
(LOW SIDE)

50 Y DRIVE ASSY




4.8 POWER SUPPLY BLOCK of 50 X, Y DRIVE and 50 SCAN A, B ASSYS




4.9 50 ADDRESS L and S ASSYS

50 ADDRESS S ASSY




50 ADDRESS L ASSY



4.10 50 DIGITAL and SENSOR ASSYS

50 DIGITAL ASSY



4.11 MAIN ASSY (DTV BLOCK DIAGRAM)

A


B

C

D

E

F



■

5

■

6

■

7

■

8

■

A

■

B

■

C

■

D

■

E

■

F

■

5

■

6

■

7

■

8

■

PDP-5080HD

4.12 POWER SUPPLY BLOCK of MAIN ASSY

A


B


C

D

E


F






4.13 TANSHI ASSY

TANSHI ASSY




4.14 50XGA LED and 50LED&IR ASSYS



1 2 3 4

4.15 POWER SUPPLY BLOCK of 50LED&IR and SIDE KEY ASSYS



5. DIAGNOSIS

5.1 POWER SUPPLY OPERATION


5.1.1 LED DISPLAY INFORMATION

■ LED Pattern

			POWER	ON	STANDBY	SLEEP
				●	●	●
State	LED Pattern					Remarks
AC OFF or Main power switch OFF	B R OG					
Standby power management	B R OG					
Power ON (Screen ON)	B R OG					
Power-down	B R OG					
Shutdown	B R OG					
No digital adjustment data copied for backup	B R OG					The LEDs flash only while the panel is turned on.
In the process of rewriting the program of the microcomputer	B R OG					
During factory operation	B R OG					
Trap switch	B R OG					
During DTV Module software downloading	B R OG					
Downloading of DTV Module software is finished normally.	B R OG					
Downloading of DTV Module software is abnormally finished.	B R OG					
Sleep timer	B R OG					

1 2 3 4

5.1.2 POWER ON SEQUENCE



- E
- F
- ① : The remote control (or KEY) signal is input to the IF microcomputer.
 - ② : The IF microcomputer sends the operation data of the remote control unit (or KEY) to the main microcomputer.
 - ③ : The main microcomputer issues a startup command (PON) to the MOD microcomputer.
 - ④ : The relay is controlled with logical OR interpretation of control signals by the main microcomputer and module (MOD) microcomputer.

5.1.3 DETAILS OF POWER ON SEQUENCE


Power supply status - AC off

Microcomputer
output port state

IF: ACTIVE	OFF
Main: PSW1	OFF
Module: RELAY	OFF
Module: DRF_B	OFF

Microcomputer
input port state

Main: RST4	OFF
Main: RST2	OFF
Module: RST2	OFF



The state of AC cord is pulled out.


Power supply status - Main switch off

Microcomputer
output port state

IF: ACTIVE	ON
Main: PSW1	OFF
Module: RELAY	OFF
Module: DRF_B	OFF

Microcomputer
input port state

Main: RST4	ON
Main: RST2	OFF
Module: RST2	OFF



The user operation with the remote control unit is invalid. (All LED: OFF)

Standby power device and some Vcc power devices operate.

RGB-SW/AD/D-AMP/MAP are electrified, but uses the power-saving mode function of the IC.

A

Power supply status - Standby

Microcomputer
output port state


IF: ACTIVE	ON
Main: PSW1	OFF
Module: RELAY	OFF
Module: DRF_B	OFF

Microcomputer
input port state

Main: RST4	ON
Main: RST2	OFF
Module: RST2	OFF

B

C



Remote control unit waiting state. (Red LED: ON)

Standby power device and some Vcc power devices operate.

RGB-SW/AD/D-AMP/MAP are electrified, but uses the power-saving mode function of the IC.

Power supply status - ON

D

Microcomputer
output port state


IF: ACTIVE	ON
Main: PSW1	ON
Module: RELAY	ON
Module: DRF_B	ON

Microcomputer
input port state

Main: RST4	ON
Main: RST2	ON
Module: RST2	ON

E

F




A state when it displays a picture on the PDP. (Blue LED: ON)

All devices are electrified.

5.2 DIAGNOSIS FLOWCHART OF FAILURE ANALYSIS

5.2.1 WHOLE UNIT

Flowchart of Failure Analysis for The Whole Unit



A

A

In the subsequent diagnostic steps, it is most likely that the multi base section is in failure.

Problems concerning video display

Is the panel mask properly displayed?

No

Is it return to properly indication when a command (PMTS00) is issued?

No

Failure analysis for the drive system => DR2

Yes

No

Failure analysis for the MAIN Assy => MA4

A main microcomputer may stop in the state that it hung a panel mute due to something.

Check with the animated slanting ramp mask.

Is the on-screen display (OSD) properly displayed?

No

Failure analysis for the DIGITAL Assy => DG1

Yes

Check on the Factory menu.

Is an external video signal displayed properly?

No

Failure analysis for the MAIN Assy => MA3

Yes

Problems concerning the audio output

Is the audio signal output?

No

Failure analysis for the audio system => AU1

Yes

Specific failure whose cause is difficult to identify in the initial stage

B

C




D

E


F

5.2.2 POWER SUPPLY UNIT

Flowchart of Failure Analysis for The POWER SUPPLY Unit



Flowchart of Failure Analysis for The Drive Assy



Failure analysis for the drive system => DR2

Abnormality across the whole screen, such as luminescent spots

Because it is difficult to identify which drive is in failure, follow the flowchart below to check each Assy.

Y DRIVE Assy / SCAN A, B Assy

X DRIVE Assy

ADDRESS Assy

Y DRIVE Assy

Ⓑ

Ⓒ

Are all the connectors properly connected?

No

Reconnect the connectors.

NG

Is the VH set voltage (130 V) correctly set?

No

Set the VH voltage correctly.

NG

Is the VSNOFS set voltage correctly set (set value: designated for each panel)?

No

Set the VSNOFS voltage correctly.

NG

Is the VYRST set voltage correctly set (set value: designated for each panel)?

No

Set the VYRST voltage correctly.

NG

Is the VKNOFS1, 2 set voltage correctly set?

No

Set the VKNOFS1, 2 voltage correctly.

NG

Is the VKNOFS3 set voltage correctly set (set value: designated for each panel)?

No

Set the VKNOFS3 voltage correctly.

NG

Is the VKNOFS4 set voltage correctly set (set value: designated for each panel)?

No

Set the VKNOFS 4voltage correctly.

NG

Another Assy may be in failure.

Yes

Is the waveform normal when the voltage is applied to the panel?
(See the oscilloscope photos.)

No

Is the input signal normal?
(See the oscilloscope photos.)

No

Replace the FFC cables.

NG

Replace the DIGITAL Assy.

Is the waveform of the control signal from the SCAN Assy normal?
(See the oscilloscope photos.)

No

Replace the Y DRIVE Assy.

Yes

Replace the SCAN IC.

Ⓓ

A



B



C

D

E


F






A

Flowchart of Failure Analysis for The DIGITAL Assy




5.2.5 MAIN ASSY

Flowchart of Failure Analysis for The MAIN Assy




5.2.6 VIDEO SYSTEM

Flowchart of Failure Analysis for The Video System




Flowchart of Failure Analysis for The Video System

No video from Composite or S-VIDEO




● Waveforms

Input signal: Color-bar



A

No video from TV signal


D


● Waveforms

Input signal: Color-bar

E


F






● Waveforms

Input signal: Color-bar




A




D

● Waveforms


Input signal: Color-bar



F





No video from USB input



5.2.7 AUDIO SYSTEM


Flowchart of Failure Analysis for The Audio System






• Waveforms


Input signal: L/R 1 kHz, 0.5 Vrms (VOL 30)




A




B




C



D




E



Waveforms

Input signal: L/R 1 kHz, 0.5 Vrms (VOL 30)




F

5.3 DIAGNOSIS OF PD (POWER-DOWN)

5.3.1 BLOCK DIAGRAM OF THE POWER-DOWN SIGNAL

■ Block Diagram of the Power-Down Signal



5.3.2 PD (POWER-DOWN) DIAGNOSIS OF FAILURE ANALYSIS

Prediction of failure symptoms when a PD (power-down) is generated


Red LED Flashing Count	Operating PD	Defective Assy	PD Outline	Checkpoint	Possible Defective Part	Remarks
2	POWER	POWER SUPPLY Unit	Failure in the POWER SUPPLY Unit			
		X DRIVE Assy	VSUS UVP	X SUS BLOCK	Q1219,Q1220,Q1221, Q1222,Q1223,Q1224,Q1201	VSUS-PSUS and SUSOUT-SUSGND are short-circuited.
		Y DRIVE Assy		Y SUS BLOCK	Q2217,Q2218,Q2219, Q2221,Q2222,Q2223	VSUS-SUSOUT and SUSOUT-SUSGND are short-circuited.
3	SCAN	SCAN Assy	VH UVP	SCAN IC	SCAN IC	
		X DRIVE Assy		X SUS BLOCK	Q1219,Q1220,Q1221, Q1222,Q1223,Q1224,Q1201	VSUS-PSUS and SUSOUT-SUSGND are short-circuited.
		Y DRIVE Assy		Y SUS BLOCK	Q2217, Q2218,Q2219, Q2221,Q2222,Q2223	VSUS-SUSOUT and SUSOUT-SUSGND are short-circuited.
				VH DC/DC converter	IC2601,D2604	
		DIGITAL Assy	Connectors disconnection detection	CN2001,CN2301 CN3506		
4	SCN-5V	SCAN Assy	IC5V UVP	SCAN IC		
		Y DRIVE Assy	Connectors disconnection detection	IC5V DC/DC CN2501,CN2502	Q2554,D2558	
5	Y-DCDC	Y DRIVE Assy	Connectors disconnection detection	CN2001		
		DIGITAL Assy		CN3506		
6	Y-DCDC	Y DRIVE Assy	VNOFS UVP	Y MSK BLOCK	Q2320, Q2321, Q2322, Q2323, Q2324, Q2325, Q2330, Q2332, Q2334	LMSK is short-circuited.
				VNOFS DC/DC	D2606, Q2710, Q2711	
			Vprst UVP	YPRST Regulator	D2602, Q2604, R2610	
			15VDD UVP	15VDC/DC	Q2572	
				VKOFS1_2 UVP	Y MSK BLOCK	Q2320, Q2321, Q2322, Q2323, Q2324, Q2325, Q2330, Q2332, Q2334
			VKOFS1_2 Regulator		Q2705, Q2702	
			VKOFS3 UVP	Y MSK BLOCK	Q2320, Q2321, Q2322, Q2323, Q2324, Q2325, Q2330, Q2332, Q2334	LMSK is short-circuited.
				VKOFS3 Regulator	Q2706, Q2703	
			VKOFS4 UVP	Y MSK BLOCK	Q2320, Q2321, Q2322, Q2323, Q2324, Q2325, Q2330, Q2332, Q2334	LMSK is short-circuited.
				VKOFS4 Regulator	Q2707, Q2704	
7	Y-SUS	Y DRIVE Assy	Center electric potential detection PD	Y RESONANCE BLOCK	Q2106,Q2107,Q2108,Q2110,Q2112, D2104,D2105,D2108,D2109	
8	ADRS	ADDRESS Assy	Vadr LVP	ADDRESS RESONACE BLOCK	IC1651 to IC1656, IC1851 to IC1855	Vadr is short-circuited (TCP,etc.). Each TCP unit.
					Q1731,Q1741,Q1751,Q1761,Q1771,Q1781,Q1931,Q1941,Q1951, Q1961,Q1971,D1731,D1741,D1751,D1761,D1771,D1781,D1931, D1941,D1951,D1961,D1971,R1714 to R1719,R1914 to R1918)	Between ADR_B and Vadr is short- circuited. Each resonance block unit.
					C1711,C1911,(R1714 to R1719,R1914 to R1918,R1735,R1745,R1755, R1765,R1775,R1785,R1935,R1945,R1955,R1965,R1975,D1731,D1741, D1751,D1761,D1771,D1781,D1931,D1941,D1951,D1961,D1971)	ADR_B capacitor is short-circuited.
		DIGITAL Assy	Connectors disconnection detection	CN1601, CN1602, CN1801, CN1802		
				CN3501 to CN3504		
				CN1202,CN1203 CN2302,CN2303,CN2304		
9	XDRIVE	X DRIVE Assy	Connectors disconnection detection	CN1001		
		DIGITAL Assy		CN3505		
10	X-DCDC	X DRIVE Assy	Connectors disconnection detection	CN1201		
			15VDD UVP	X SUS BLOCK	L1201,R1217	
				15VDC/DC	Q1402	
			VXKOFs1 UVP	VXKOFs1 Regulator	Q1403,Q1404,IC1401	
				X OFFSET BLOCK	Q1301,Q1303	
			VXKOFs2 UVP	VXKOFs2 Regulator	Q1405,Q1406,IC1402	
X OFFSET BLOCK	Q1302,Q1304					
11	X-SUS	X DRIVE Assy	Center electric potential detection PD	X RESONANCE BLOCK	Q1108,Q1109,Q1110,Q1112, D1106,D1107,D1110,D1111	

UVP: Under Voltage Protect , OVP: Over Voltage Protect


■ How to distinguish which connector is disconnected

Assy	Connector	To which Assy the Connector is Connected	LED Flashing Count	Screen Display
X DRIVE Assy	CN1001	DIGITAL Assy	5 (XDRIVE)	
	CN1201	POWER SUPPLY Unit (drive system power)	11 (X-SUS)	
	CN1202	POWER SUPPLY Unit (ADR system power)	8 (ADRS)	
	CN1203	ADDRESS Assy	8 (ADRS)	
Y DRIVE Assy	CN2001	DIGITAL Assy	3 (SCAN)	
	CN2301	POWER SUPPLY Unit (drive system power)	3 (SCAN)	
	CN2302	POWER SUPPLY Unit (ADR system power)	8 (ADR)	
	CN2303, CN2304	ADDRESS Assy	8 (ADR)	
	CN2501, CN2502	SCAN A, B Assy	4 (SCN-5V)	
SCAN A, B Assy	CN2801, CN2901	Y DRIVE Assy	4 (SCN-5V)	
ADDRESS Assy	CN1602, CN1802	DIGITAL Assy	8 (ADRS)	
	CN1601, CN1801	X DRIVE Assy, Y DRIVE Assy	8 (ADRS)	


A

X Drive PD system

B




C


Y Drive PD system

D

E



F




5.4 DIAGNOSIS OF SD (SHUTDOWN)

5.4.1 BLOCK DIAGRAM OF THE SHUTDOWN SIGNAL

■ Block Diagram of the Shutdown Signal

Note : The figures ① to ⑮ indicate the number of times the LED flashes when shut-down occurs in the corresponding route.



5.4.2 SD (SHUTDOWN) DIAGNOSIS

Frequency of LED Flashing	Major Type	Detailed Type	Log Indication in Factory Mode		Checkpoint	Possible Defective Part	Remarks
			MAIN	SUB			
Blue 1	Abnormality in the Sequence LSI	Communication error		RTRY	CLK_SO/TXD_SO, etc.	IC3401, IC3151	SQ_IC communication not established. IC3401 may not have properly started up.
		Drive stop	SQ-LSI	SONO	Check if the video sync signal is input to IC3401.	CN3001, IC3001, IC3401	A shutdown occurs if IC3401 has not properly started up (a communication failure between IC3401 and IC3306 [FLASH]).
		Busy		BUSY	BUSY_SO	IC3401, IC3151	IFBUSY_SO remains high, a shutdown is generated.
		Incoherent version (hardware, software)		VER-HS	Check the model number of the DIGITAL Assy and the destination of the sequence LSI.	IC3306, IC3151	The written SQ_PROG is incoherent with data on the DIGITAL Assy.
Blue 2	Failure in IIC communication with the module microcomputer	Incoherent version (memory, software)		VER-MS	Check the model number of the sequence LSI.	IC3306, IC3151	A shutdown occurs if the SEQ-PROG that has been stored in backup memory does not coincide with the actual SEQ-PROG.
		DIGITAL Assy EEPROM		EEPROM	IIC communication line of IC3156	IC3156, IC3151	Check the pull-up resistor of the IIC control line and the power to the corresponding IC.
		SENSOR Assy EEPROM	MD-IIC	BACKUP	IIC communication line of IC3662	IC3662, IC3151	Check the pull-up resistor of the IIC control line and the power to the corresponding IC.
		DAC1		DAC1	IIC communication line of IC3157	IC3157, IC3151	Check the pull-up resistor of the IIC control line and the power to the corresponding IC.
Blue 3	Abnormality in RST2 power decrease			DAC2	IIC communication line of IC3158	IC3158, IC3151	Check the pull-up resistor of the IIC control line and the power to the corresponding IC.
			RST2		Is the output voltage of the DC-DC converter low?	IC3602(BD9302FFP)	If RST2 does not become high after the unit is turned on, a shutdown will be generated in several seconds.
Blue 4	Abnormality in panel temperature				The 12 V power is not output.	POWER SUPPLY Unit FU3801	Check if V + 12 V is started. Also check if the FU3801 on the DIGITAL Assy has been melted.
			TMP-NG	TMP-H	High temperature abnormality in the panel temperature sensor	SENSOR Assy (IC3851)	If TEMP1 that is read by the module microcomputer is 75 °C or higher, a shutdown will be generated.
Blue 5	Short-circuiting of the speakers / D-AMP temperature abnormality			TMP-L	Low temperature abnormality in the panel temperature sensor	SENSOR Assy (IC3851)	A shutdown occurs if the reading of TEMP1 detected by the module microcomputer is -20 °C or less. Also check the connection with the SENSOR Assy.
			AUDIO		Speaker terminals	JA9301	Check if any speaker cable is in contact with the chassis.
Blue 6	Failure in communication with the module microcomputer				AUDIO AMP	IC9201, IC9101	Check if the AMP output is short-circuited.
					Periphery of the cable between IO3 and M8, and D6 and P5	CN8803, CN4001, CN8806, P5	Check if cables are firmly connected.
Blue 7	Failure in main microcomputer 3-wire serial communication		MODULE		Communication line between MAIN and MOD	IC3151, IC8401	Check the communication lines (TXD_MOD/RXD_MOD/REQ_MOD).
			MA-3L	IF	Periphery of the cable between D11 and M1	CN3001, CN4101	Check if cables are firmly connected.
Blue 8	Failure in IIC communication with the main microcomputer				Communication line between IF and MAIN	IC8301, IC8401	Check the communication lines (TXD_IF/RXD_IF/CLK_IF/BUSY_IF/CE_IF/REQ_IF).
				MULTI	Communication line between MULTI and MAIN	IC8001, IC8401	Check the communication lines (TXD_IC3/RXD_IC3).
		Tuner 1		FE1	IIC communication line between Tuner (ANT-A) and MAIN	U6101, IC8401	Check the communication lines (SCL_TU/SDA_TU or SCL_AV5/SDA_AV5).
		MSP/MP		MSP/MP	IIC communication line between MSP/MP and MAIN	IC9101, IC8401	Check the communication lines (SCL_AV/SDA_AV).
Blue 9	Failure in communication with the main microcomputer	AV switch		AV-SW	IIC communication line between AV-SW and MAIN	IC4601, IC8401	Check the communication lines (SCL_AV5/SDA_AV5).
		RGB switch		RGB-SW	IIC communication line between RGB-SW and MAIN	IC4701, IC8401	Check the communication lines (SCL_AV5/SDA_AV5).
		VDEC	MA-IIC	VDEC	IIC communication line between M-VDEC and MAIN	IC4801, IC8401	Check the communication lines (SCL_MB/SDA_MB).
		SDRAM		SDRAM	IIC communication line between VDEC and SDRAM	IC4801, IC4802	Check the communication lines (SDRAM). Defective SDRAM
Blue 10	Failure in communication with the main microcomputer	AD/PLL		ADC	IIC communication line between ADC and MAIN	IC5001, IC8401	Check the communication lines (SCL_AV/SDA_AV).
		HDMI		HDMI	IIC communication line between HDMI_RX and MAIN	IC5201, IC8401	Check the communication lines (SCL_MB/SDA_MB).
		Tuner 2		FE2	IIC communication line between Tuner (ANT-B) and MAIN	U6001, IC8401	Check the communication lines (SCL_AV5/SDA_AV5).
		US-MSP		US-MSP	IIC communication line between US_MSP and MAIN	IC6001, IC8401	Check the communication lines (SCL_AV5/SDA_AV5).
Blue 10	FAN NG		MAIN		Communication line between IF and MAIN	IC8301, IC8401	Check the communication lines (TXD_IF/RXD_IF/CLK_IF/BUSY_IF/CE_IF/REQ_IF).
					Dirt attached to the fan motor	—	Check the fan.
		FAN1	FAN	FAN1	Periphery of the FAN CONNECT	AWW1290, AWW1329	FAN NG
					Periphery of the cable between FA1 and M5, FAN and M4, and FA2 and FA5	CN6551 to CN6555, CN4103, CN4113	Check if cables are firmly connected.
					Periphery of the fan control regulator	IC4310, IC4303	—

Frequency of LED Flashing	Major Type	Detailed Type	Log Indication in Factory Mode		Checkpoint	Possible Defective Part	Remarks
			MAIN	SUB			
Blue 11	High temperature of the unit	–	TEMP2	–	Temperature sensor or its periphery	–	TEMP2 A shutdown occurs because of high temperature.
				Periphery of the temperature sensor	TH9091	TEMP2	
				Periphery of the cable between IO4 and M6	CN8804, CN4004	Check if cables are firmly connected.	
				Startup of BCM7038	IC6401	Check the startup of the BCM7038 and the communication line with MAIN.	
Blue 12	Digital Tuner	DTV startup error	DTUNER	PS/RST	Communication line between BCM7038 and MAIN	IC6401	Check the startup of the BCM7038 and the communication line with MAIN.
		DTV communication error		DE-BCM	Periphery of BCM7038	IC6401	
		BCM7038 is abnormal		DE-FE	Front-end block (ANT-A)	IC6401, U6101	Check the BCM7038 and its periphery device
		Tuner1 or Tuner2		DE-CAS		IC7302, IC6401, AWV2496	Check the BCM7038 and its periphery device
		Card I/F IC		DE-VBI	Periphery of VBI slicer	IC7001	Check the BCM7038 and its periphery device
		VBI Slicer	DE-EP1		IC6903, IC6401	Check the BCM7038 and its periphery device	
		EEPROM	TV-G	TV-GUIDE function (Data from broadcast wave)	–	(No LED will blink if a shutdown is generated during power standby.)	
		TV Guide					
		Home Gallery	HOME-G	HNM circuit	IC6401, AWV2497	Check the BCM7038 and its periphery device	
		Middleware	DTVMID	DTV middleware	–		
Blue 13	Failure in the power supply	Application	DTVAPP	DTV application			
		DC-DC Converter power decrease	M-DCDC	DC-DC converter or its periphery, RST2	IC4403, Q4404	Check if V + 3.3 V_D4 is started.	
			RST-MA	EMG_USB	The 12 V power is not output, RST4	IC4309, Q4304	Check if the voltage at a waveform check point is 5 V.
				POWER SUPPLY	RELAY	The 6.5 V power is not output	POWER SUPPLY Unit
		POWER SUPPLY		The 5.1 V power is not output	POWER SUPPLY Unit	Check if V + 6.5 V is started.	
				EMG_DDC	The 5.1 V power is not output	POWER SUPPLY Unit	Check if V + 5.1 V is started.
						DCDC converter	Check if the DCDC converter is overloaded.
Blue 14	Home Media Gallery	HMG startup error	HMG	START	Periphery of the cable between P8 and M3	CN4105	Check if cables are firmly connected.
					Periphery of connector	CN4111	Check if cables are firmly connected.
					HNM power supply	IC4309, Q4304	Check if cables are firmly connected.
Blue 15	Main EEPROM	Main EEPROM communication error	MA-EEP	–	IIC communication line between EEPROM and MAIN	IC8404, IC8401	Check the communication lines (SCL_EP/SDA_EP).

5.5 NON-FAILURE INFORMATION

5.5.1 INFORMATION ON SYMPTOMS THAT DO NOT CONSTITUTE FAILURE

Information on symptoms that do not constitute failure

Symptom	Cause, item to check, information
HDMI: Symptoms concerning the input format and settings	
The picture color for an INPUT 4 to 7 signal is not correct.	The color setting for INPUT 4 to 7 is not compatible with that of the output equipment. Check whether the color setting is YPbPr or RGB.
The video signal to INPUT 4 to 7 is not displayed, and a message is displayed.	A unsupported video signal is input.
The audio signal input to the INPUT 4 to 5 is not output. No HDMI signal is input.	The audio setting for INPUT 4 to 5 is "AUTO," and a video signal is not input. If the audio setting is "AUTO," to output an analog audio signal, the HDMI signal must be input. (If a DVI device is to be connected, use a DVI-HDMI conversion cable.) If the HDMI video signal is not input, the analog audio signal is not output. When the DVI equipment is connected, the analog signals are selected with the setting "AUTO."
No sound of signals to INPUT 4 to 7 is output.	The setting on the side of the HDMI output equipment is wrong. Example: Dolby Digital
The 1080p input signal is not displayed properly or at all, although the 1080i input signal is displayed properly.	Check that the connected cable supports HDMI Category 2. (As the clock frequency for the 1080p signal is triple that for the 1080i signal, signal degradation caused by a cable must not be neglected. A cable supporting HDMI Category 2 can be used for the 1080p signal. Although some conventional cables can support the 1080p signal, some others cannot.)
DIGITAL OUT	
Playback of the signal from the DIGITAL audio output connector is possible, but recording is not possible.	The video signal output from the DIGITAL connector is copy-protected.
Miscellaneous	
The no-signal off function is not activated.	The no-signal off and no-operation off functions are effective only if video (composite, S video, component, HDMI [excluding PC]) input or TV input is selected.
The no-operation off function is not activated.	
Power management does not function.	Power Management is effective only while an analog PC signal is being input. It is not effective with HDMI-PC signal input.
The AUTO SETUP function is not activated.	The Auto Setup function is effective only while an analog PC signal is being input. This function does not work if an analog PC signal is not input, even if the INPUT PC is selected.
Control via the SR connector is not possible.	Wrong connection of the cable to the PC INPUT (AUDIO) connector is suspected.
The audio signal from the PC is not output.	Wrong connection of the cable to the SR connector is suspected.
The picture-quality setting (AV Selection) is not stored.	The picture-quality setting is stored for each input. As the setting is changed when another input is selected, the user may have a false idea that the setting is not stored.
The picture size changes arbitrary.	The Auto Size setting is set to ON.
The display position of the screen changes slightly while the screen is on.	The orbiter function for minimizing the effects of phosphor burn is activated. Although the setting for this function can be changed on the Home menu, retaining the factory setting is strongly recommended.
The video signal to the S video connector is not displayed.	The component video cable is connected to the same input function as for the S video (even if no signal is input to the component video connector, merely having something plugged in to the connector will result in judgment that a signal is being fed in and the component video connector takes priority). (Priority of connectors: component video > S video > composite video)
The video signal to the composite video connector is not displayed.	The S Video or component video cable is connected to the same input function as for the composite video. (Priority of connectors: component video > S video > composite video)

SUPPLEMENT: On the video setting for HDMI

There are three types of HDMI output formats: color difference 4:4:4, color difference 4:2:2, and RGB4:4:4.

(The proportions, such as 4:4:4 and 4:2:2, represent those of the amount of data for video signal components. For example, as for color difference 4:4:4, the proportion of the amount of data as for Y, Cb, and Cr is 4:4:4.)

It is required to make the settings of the PDP according to the settings of the output equipment. For usual operation, however, set them to AUTO. If the color is inappropriate, make the settings manually.

In the HDMI system, video signals are coded at 24 bits per pixel and transmitted as a series of 24-bit pixels. In a case of color difference 4:4:4, Y, Cb, and Cr use 8 bits each. In a case of color difference 4:2:2, Y, Cb, and Cr use 12 bits each, but Cb and Cr are transmitted at a half sampling rate of Y. This unit is capable of processing the upper 10 bits out of 12 bits of video data. Recent high-end DVD players, such as Pioneer DV-79AVi, are capable of outputting 10-bit color-difference signals. In general, it is said that picture quality for color difference 4:2:2 format is assumed to be higher, because human eyes are more sensitive to luminance than to colors. In the case of RGB4:4:4, R, G, and B use 8 bits each.

5.5.1.1 CONFIRMATION ON THE HDMI CONTROL FUNCTION

When you use the HDMI Control (HDMI-CEC) function, if the unit does not function properly, such as not being able to control or recognize connected equipment, check the following:


- **Confirmation of the manufacturer of the connected equipment**

Check if the connected equipment was manufactured by Pioneer and if it supports the HDMI Control function. If its manufacturer is not Pioneer, proper operations are not guaranteed.


- **Confirmation of connections**

Check if the unit is connected properly, as shown in the figures below:


(For details, refer to "Making the HDMI Control connections" in the Operating instructions.)



Example 1: When an AV amplifier that supports HDMI Control is connected



Example 2: When an AV amplifier that does not support HDMI Control is connected



Example 3: When an AV amplifier is not connected

Check that the following conditions are met:

- The connected equipment must support the HDMI Control function.
- The equipment must be connected to the INPUT connector that has been selected in "Input Setting" on the HDMI Control Setting menu.
- The connections must be made properly, as shown in the above figures (in a case where an AV device, such as an AV amplifier, and a DVD recorder/BD player are connected, in a case where only a DVD recorder/BD player is connected, and in a case where an AV device, such as an AV amplifier, which does not support HDMI-CEC, is connected).
- When an AV device that supports the HDMI Control function is connected, it must be connected between the PDP and a DVD recorder/BD player.
- The HDMI Control function must be activated on the connected equipment (DVD recorder, BD player, AV device [AV amplifier, etc.]). (Refer to the Operating instructions of the connected equipment.)

A

• Confirmation of the number of connected devices

Check that the number of connected devices does not exceed the maximum number for guaranteed operations.

Equipment	Maximum Number
DVD recorder	2
BD player	2
AV System	1

B

• Confirmation of settings

Check that the settings for the HDMI Control function are properly made. (For details, refer to "Setting the HDMI Control" in the Operating instructions.)

Check that the following conditions are met:

- "Input Setting" on the HDMI Control Setting menu must be set to the same input as that to which the equipment that supports the HDMI Control function is connected.
- When Power Off Control, Power-On Ready, or Hold Sound Status are to be used, their settings must be On.

C

• Confirmation of operations

Check that the HDMI Control function works properly.

- (1) Connect a device that supports the HDMI Control function.
- (2) Perform the procedures that are required after changing connections, which are described in "Making the HDMI Control connections" in the Operating instructions.
 - 1 Turn on the plasma television and all the connected devices.
 - 2 Confirm that the setting in "Input Setting" for "HDMI Control Setting" is properly entered according to the connected devices. Also confirm the HDMI Control related settings in the connected devices.
 - 3 Switch to the HDMI input terminals to which the devices are connected to check if audio and video images are properly output and displayed.
 - 4 Try turning off the plasma television, then turn the power back on to the plasma television.
- (3) Perform "Power On Test" or "Power Off Test" on the HDMI Control Setting menu. (For details, refer to "Power On/Off Test" in the Operating instructions.)

E

If the following occurs even if the operation check is performed properly, a failure, such as breakage of the HDMI cable, problems on the side of the connected device, and problems with the MAIN Assy, may be suspected:

- "Power On Test" or "Power Off Test" cannot be selected (the items are grayed)
- The connected device cannot be turned on/off.

In some cases, an operation check using another HDMI input connector may be required in order to narrow down the cause.

F

5.5.2 FUNCTION OF DECREASING THE BRIGHTNESS LEVEL

■ High-temperature protection function 1

If the panel temperature (TEMP1) reaches 70 °C, the limit for the maximum count of plasma discharge will be gradually decreased to lower the temperature of the panel.

- This function is activated based on the TEMP1 temperature.
- The limit for the maximum count of plasma discharge will be decreased 8 per 5 seconds.
- The lowest limit for the maximum count of plasma discharge is about 700.
- The maximum count of plasma discharge will begin to increase gradually if the panel temperature falls to the specified temperature.

■ High-temperature protection function 2

If the panel temperature (TEMP1) reaches 65 °C, the plasma-discharge count that is determined based on the input APL will be decreased. In actual operation, the ABL adjustment value will be offset.

- This function is activated based on the TEMP1 temperature.
- The ABL adjustment value will be decreased by one step per 30 seconds.
- The ABL adjustment value will begin to increase gradually if the panel temperature falls to the specified temperature.

■ Panel protection function 1 (protection against still picture)

If a still picture is displayed for 3 minutes or more, the limit for the maximum count of plasma discharge will be gradually decreased to minimize the effects of phosphor burn.

- This function is activated after detection if the displayed picture is still (the picture will be considered to be still if only the mouse cursor is moved).
- The limit for the maximum count of plasma discharge will be decreased 8 per 5 seconds.
- The lowest limit for the maximum count of plasma discharge is about 700 (it takes about 15 minutes to reach the lowest limit, although the required time varies depending on the displayed picture).
- The maximum count of plasma discharge will begin to increase gradually if the displayed picture is changed to animated picture.

Note: How to decrease the brightness level in this function is the same as in high-temperature protection function 1.

■ Panel protection function 2 (SCAN IC protection)


If a particular load is applied to the SCAN IC, the limit for the maximum count of plasma discharge will be gradually decreased.

Note: How to decrease the brightness level in this function is the same as in high-temperature protection function 1.

■ Panel protection function 3 (protection against panel cracking)

A bright window, as shown in the figure on the right, on the screen increases the heat of the panel. If such a pattern is recognized on the screen, the limit for the maximum count of plasma discharge will be gradually decreased.


Note: How to decrease the brightness level in this function is the same as in high-temperature protection function 1.



Detection example: SCAN IC protection



Detection example: Protection against panel cracking



5.6 OUTLINE OF THE OPERATION

5.6.1 PANEL DRIVE-POWER ON / OFF FUNCTION

Function:

It is an operational mode where the digital signal processing performs circuit operation but the power is not supplied to the panel driving system (Vsus, VAddress) in order to avoid a power down (PD).

Application:

1. When it is necessary to check whether the signal output is correctly reaching the drive system in a repairing activity etc.
2. In the case of a PD, to determine whether the problem is with the panel drive-power supply or with the other system power supply.


Method:

1. Short-circuit between the specified location of the POWER SUPPLY Unit and GND (Multi base section recommended), using a jumper with alligator clips (refer to the photos below).
2. Execute [DRV S00] by RS-232C command. ([DRV S01] for release)


Supplemental explanation:

- When the panel drive-power is in OFF state, there will be no PD, except PS_PD, as the PD signal has been muted.
- If the clip is removed in the OFF state of the panel drive-power, PD will take place at the instance of clip removal. Therefore, be sure to remove the clip after turning the power OFF.
- Under RS-232C command control, [DRV S01] (release) is possible during power ON. However, there is a possibility of damaging the set. Therefore, make this operation only after turning the power OFF.
- Command [DRV S00/S01] is effective even during standby.
- When the main power switch is set to OFF, no command is accepted.
- When the AC power cord is unplugged, the panel drive-power OFF state established by the [DRV S00] command is canceled. (The panel drive-power OFF state remains in effect even if the main power switch is set to OFF after that command is sent.)

When the panel drive-power is ON




When the panel drive-power is OFF




5.6.2 SPECIFICATION OF THE FAN CONTROL

■ Block diagram

The internal fan cools down the MTB and Power blocks.



■ Operation specifications




Notes:

- The operating temperature of the fan is higher than the ambient temperature, because the sensor temperature is read by the microcomputer.
- If the critical values for signals are displayed in the address circuit, the fan may be activated or be rotated at higher speed in response to values lower than the set temperature values shown above.

5.6.3 PROCESSING IN ABNORMALITY

Protection of the Power Amplifier

● Circuit configuration



● Specifications for port monitoring

Port Name	SD/PD Indication	Active	Monitoring conditions	Operation
A_NG_B	AUDIO	Shutdown occurs when the signal is "L." 30 mS * 3 times	RST4 = "H" (always) (Monitoring starts 2 sec after the above conditions are established.)	The main CPU operations described below will be performed when either "A_NG_B = L" or "OTW = L" is detected (established) under the monitoring conditions.
OTW	AUDIO	Shutdown occurs when the signal is "L." 130 mS * 3 times		

● Operation specifications of the main CPU

- (1) When a shutdown decision is made by the main CPU
 - After a warning indication is displayed for 5 sec, a shutdown is generated (the blue LED flashes 5 times).
 - A warning indication is displayed for all input-signal types.
 - Example of a warning indication: "The speaker terminals are short-circuited. After reconnection, turn the unit on again." (For 50-inch models) (For 42-inch models, an indication declaring a forced power-off is displayed.)

- (2) Display conditions
 - When the panel is on: A warning indication is displayed immediately.
 - When the panel is off: A warning indication is not displayed immediately but is displayed when the panel is turned on.


Note: A warning indication is displayed each time the panel is turned on if the conditions for a shutdown persist.

● Conditions for resetting the circuits

The circuits will be reset upon Standby ON/OFF.

Power supply and DC-DC converter

● Circuit configuration




● Specifications for port monitoring

Port Name	SD/PD Indication	Active	Monitoring conditions	Operation
RST2	ASIC power (M-DCDC)	Shutdown occurs when the signal is "L." for 5 sec after PSW1 is ON. or for 2 sec while the unit is ON.	<ul style="list-style-type: none"> Panel ON (RST4 = H and PSW1 = L) While awaiting restoration of RST2 (RST2 = L) 	<p>The SD timer starts when "RST2 = L" is detected under monitoring conditions. If "RST3 = H," "M_SW_DET_B = H," or "RST4 = L" is detected, or if a power-down or shutdown in the module microcomputer system is not generated, the unit waits for 30 mS. Then, if the SD timer continues to count for 2 sec or more, a shutdown is determined, and a shutdown process starts. A specific LED flash pattern (blue LED, 13 times) starts. The next PON operation is valid, and the flag is cleared upon the next power-on.</p> <p>If RST2 is H, a restoration process starts according to the latest power-on/off status.</p>
RST3	AC power	AC_OFF when the signal is "H."	<ul style="list-style-type: none"> Active STB (including SD/PD statuses) Functional STB Panel ON (Areas other than North America) While the main power switch is set to OFF (M_SW_DET_B = H) (North America) While the main power switch is set to OFF (M_SW_DET_B = H) While awaiting restoration of AC power (RST3 = H) While awaiting restoration of RST2 (RST2 = L) While awaiting restoration of RST4 (RST4 = L) 	<p>If "RST3 = H" (AC_OFF) is detected under the monitoring conditions, a power-off process starts. Monitoring of the RST3 port is continued, while monitoring of other ports is interrupted. Communication is controlled only by the IF microcomputer. The port outputs are set as specified. If the signal at the RST3 port continues to be H after 30 mS of waiting, monitoring is continued. If RST3 is L, a restoration process starts according to the latest power-on/off status.</p>
RST4	MAIN power (RELAY)	Shutdown occurs if the signal is "L." for 5 sec after RELAY is ON. or for 2 sec while the unit is ON or in Functional STB.	<ul style="list-style-type: none"> Functional STB Panel ON (Areas other than North America) While the main power switch is set to OFF (M_SW_DET_B = H) While awaiting restoration of RST2 (RST2 = L) While awaiting restoration of RST4 (RST4 = L) 	<p>The SD timer starts when "RST4 = L" (power-off of devices in the functional STB system) is detected under monitoring conditions. The RST4 initialization process starts, and input monitoring, communication setting, and output-terminal setting are performed. The RST4-SD timer starts. If either "RST3 = H" or "M_SW_DET_B = H" is detected, or if a power-down or shutdown in the module microcomputer system is not generated, the unit waits for 30 mS. Then, if the SD timer continues to count for 2 sec or more, a shutdown is determined, and a shutdown process starts. A specific LED flash pattern (blue LED, 13 times) starts. The next PON operation is valid, and the flag is cleared upon the next power-on. If RST4 is H, a restoration process starts according to the latest power-on/off status.</p>

Fan and temperature sensor

● Circuit configuration



● Specifications for port monitoring

Port Name	SD/PD Indication	Active	Monitoring conditions	Operation
FAN_NG1	FAN1	Shutdown occurs when the signal is "H." 1 S * 3 times	RST4 = H and FAN_ON1 = H (Monitoring starts 3 sec after the above conditions are established.)	If FAN_NG1 (for details on detection logic, see "File of fan-control specifications") is detected (established) under the monitoring conditions, a shutdown process starts. A specific LED flash pattern (blue LED, 10 times) starts. The next PON operation is valid, and the flag is cleared upon the next power-on.
TEMP2	High temperature at MTB	Shutdown occurs if any values equal to or greater than minimum to require a shutdown are detected. 1 S * 3 times	RST4 = H (Monitoring starts 1 sec after the above conditions are established.)	If any values equal to or greater than minimum to require a shutdown are detected (established) under the monitoring conditions, a warning indication will be displayed for 30 sec, after which a shutdown process starts. A specific LED flash pattern (blue LED, 11 times) starts. The next PON operation is valid, and the flag is cleared upon the next power-on.
TMP_NG	High temperature in the drive circuits	Shutdown occurs if any values equal to or greater than minimum to require a shutdown are detected. 200 mS * 5 times (average)	Digital video RST2 = H	If any values equal to or greater than minimum to require a shutdown is detected (established) under the monitoring conditions, those changes in status will be transmitted to the main microcomputer via the UART. Upon receiving the data, a warning indication will be displayed for 30 sec, after which a shutdown process starts. The main microcomputer orders a specific LED flash pattern (blue LED, 4 times). The next PON operation is valid, and the flag is cleared upon the next power-on.
	Low temperature in the drive circuits			If any values equal to or greater than minimum to require a shutdown is detected (established) under the monitoring conditions, those changes in status will be transmitted to the main microcomputer via the UART. Upon receiving the data, the main microcomputer orders a specific LED flash pattern (blue LED, 4 times). The next PON operation is valid, and the flag is cleared upon the next power-on.


5.6.4 TRAP SWITCH

● Outline and Notes

For video data transmission inside this Plasma Display, digital signals are used. Therefore, this unit adopts the HDCP (High-bandwidth Digital Content Protection) system for copyright protection. This unit is also provided with a detection switch (TRAP switch) that will prohibit the unit from being turned on again "if the rear case of the unit is accidentally opened," in order to prevent the panel technology from being leaked out.

The TRAP switch is disabled while the unit is turned off.

When performing internal diagnosis of the PDP, fix the switch to the OFF position using adhesive tape before turning on the unit. After servicing, be sure to remove the adhesive tape.



WHEN THE TRAP SWITCH IS ACTIVATED

When the TRAP switch is activated, the red and blue LEDs will light.

In order to deactivate the TRAP switch, close the upper plate of the unit or fix the TRAP switch to the OFF position in the manner described above.

Then, follow procedures (1) or (2) below:

(1) Deactivating with the remote control unit

- Enter Factory mode.
- Proceed to the INITIALIZE layer of Factory mode. Hold the DISPLAY key pressed for more than 5 seconds.

(2) Deactivating with the RS-232C command


- Send the CTM (cancel) command.

6. SERVICE FACTORY MODE

6.1 OUTLINE OF THE SERVICE FACTORY MODE

Operations during Service Factory mode are described here.

6.1.1 SERVICE FACTORY MODE TRANSITION CHART



6.1.2 HOW TO ENTER/EXIT SERVICE FACTORY MODE

■ How to enter Service Factory Mode

By using a PDP service remote control)

- PDP service remote control : Press [FACTORY] key.

By issuing RS-232C commands)

- During normal Standby mode : Issue [PON] then [FAY].
- During normal operation mode : Issue [FAY].

■ How to exit Service Factory Mode

By using a PDP service remote control)

- PDP service remote control : press [FACTORY] key.
- Supplied remote control unit : press [HOME MENU] key.

By issuing RS-232C commands)

- Issue [FAN].

■ How to enter Service Factory Mode by Using the supplied Remote Control Unit

- Same as previous model. Please refer to the technical document (Service Know-how).

6.1.3 FUNCTIONS WHEN ENTERING THE SERVICE FACTORY MODE

■ Functions whose setting are set to OFF

The settings for the following functions are set to OFF when Service Factory mode is entered (including when the “FAY” command is received) :

Function	Remarks
2-Screen Operation	Input function set on the main side is selected.
FREEZE	
Auto size, Side Mask	It is not performed during Factory mode.
ORBITER, Mask control	Central value operation (ORBITER)
Sleep Timer	Cancel the operation.
Room light sensor	Turn off the detecting operation (Setting data will be retained.)
Blue LED dimmer	Turn off the operation (Setting data will be retained.)
Detection of the TRAP switch	The detection operation is stopped.
TRAP history	To a possible turning on though the memory is maintained.
Display of TV guide	Finish the TV-GUIDE function.
Setting of Parental Control	When this is turned off, the block of the screen is released.
Power Control	Turn off the operation (However, the setting maintains it.)
Image Position	Central value operation

Note: Enter the factory after cancelling ACI because the ACI operation setting OFF and not done.

■ User data

User data will be treated as follows :

- User data on picture-quality and audio-quality adjustments are not reflected, and factory-preset data are output (user data will be retained in memory). When the unit enters Service Factory mode, the current audio-quality adjustment data will be still be retained in memory.
- User-setting data will be applied to the various settings (items on the menus), signal formats, and the items that are associated with path change (HDMI settings, etc.).
- Data on screen (i.e., screen position; meaning clock dividers, and not including data on screen size). Are reset to the default values (data stored in memory will be retained).
Screen size will be retained.

1 2 3 4

6.1.4 REMOTE CONTROL CODE IN SERVICE FACTORY MODE

Remote Control Keys	Basic Functions	Remarks
MUTING	Switching the main items.	Shifting to the next main item (top).
↓ (DOWN)	Switching the subtitled items.	Shifting downward to the next subtitled item.
↑ (UP)	Switching the subtitled items.	Shifting upward to the next upper layer.
← (LEFT)	Decreasing the adjustment value.	Decreasing the adjustment value.
→ (RIGHT)	Increasing the adjustment value.	Increasing the adjustment value.
ENTER/SET	Switching the layers.	Shifting downward or upward to the next lower or upper layer.
INPUT	Selecting INPUT.	Shifting the INPUT to the next function.
INPUTxx	Selecting INPUT.	Switching the INPUT to xx. (xx=1 to 7 etc)
CH+/P+	Increasing the channel number.	
CH-/P-	Decreasing the channel number.	
Numeric Keys	Function: TV	Function: TV (previously selected channel number is selected)
POWER	Power OFF.	Turning the power off.
FACTORY	Factory OFF (Factory mode)	In Factory mode, turning Factory mode off.
	Factory ON (Non-Factory mode).	In Non-Factory mode, turn Factory mode on.
HOME MENU	Menu ON.	In Factory mode, turn Factory mode off.
VOLUME+	Volume UP.	Increasing 10 the adjustment value. (PANEL FACTORY)
VOLUME-	Volume DOWN.	Decreasing 10 the adjustment value. (PANEL FACTORY)
DRIVE OFF (Note1)	Drive Mode OFF.	Turning Drive mode off.
INTEGRATOR	INTEGRATOR MENU ON.	Enter INTEGRATOR MODE.

(Note 1) When ten seconds have passed since the [DRIVE OFF] key was pressed at the standby, it becomes invalid.
Please press [POWER] key from the [DRIVE OFF] key pressing within ten seconds when you do power supply ON while driven OFF.



PDP service
remote control




PDP-4280HD
PDP-5080HD



6.1.5 PDP SERVICE REMOTE CONTROL

- The keys labeled with the same names on the service remote control unit have the same functions as those of the supplied remote control unit. (See "2.3 PANEL FACILITIES.")
- For the keys not provided on the supplied remote control unit, see the explanations below:




6.1.6 FACTORY HIERARCHICAL TABLE

Large Item	Middle Item		Variable / Adjustment Range	Remarks
		Small Item		
6.2.1 INFORMATION				
	6.2.1.1	VERSION (1)		
	6.2.1.2	VERSION (2)		
	6.2.1.3	VERSION (3)		
	6.2.1.4	MAIN NG	CLEAR <=>	NO <=> YES
	6.2.1.5	TEMPERATURE		
	6.2.1.6	HOUR METER	MTB HOUR METER CLEAR	NO <=> YES
	6.2.1.7	HDMI SIGNAL INFO 1		
	6.2.1.8	HDMI SIGNAL INFO 2		
	6.2.1.9	VDEC SIGNAL INFO 1		
	6.2.1.10	VDEC SIGNAL INFO 2		
	6.2.1.11	DTV TUNING STATUS 1		
	6.2.1.12	DTV TUNING STATUS 2		
	6.2.1.13	DTV TUNING STATUS 3		
	6.2.1.14	DTV TV-GUIDE BER		for the technical analysis
	6.2.1.15	DEBUG INFO		for the technical analysis
6.2.2 PANEL FACTORY (+)				
	6.2.2.1	PANEL INFORMATION		
	6.2.2.2	PANEL WORKS		
	6.2.2.3	POWER DOWN		
	6.2.2.4	SHUT DOWN		
	6.2.2.5	PANEL-1 ADJ (+)	VOL SUS <=>	000 to 255 Equivalent to VSU (Setting value: Factory adjustment value)
		VOL OFFSET <=>	000 to 255 Equivalent to VOF (Setting value: Factory adjustment value)	
		VOL RST P <=>	000 to 255 Equivalent to VRP (Setting value: Factory adjustment value)	
		VOL XPOFS1 <=>	000 to 255 Equivalent to VX1 (Setting value: Factory adjustment value)	
		VOL XPOFS2 <=>	000 to 255 Equivalent to VX2 (Setting value: Factory adjustment value)	
		VOL YNOFS1 <=>	000 to 255 Equivalent to VY1 (Setting value: Factory adjustment value)	
		VOL YNOFS3 <=>	000 to 255 Equivalent to VY3 (Setting value: Factory adjustment value)	
		VOL YNOFS4 <=>	000 to 255 Equivalent to VY4 (Setting value: Factory adjustment value)	
		RESET1ST_KSB <=>	112 to 144 Equivalent to R1K (Setting value: 125 fixed)	
		RESET2ND_KSB <=>	112 to 144 Equivalent to R2K (Setting value: 128 fixed)	
		YSTL_1SF_KSB <=>	112 to 144 Equivalent to Y1K (Setting value: 128 fixed)	
		YSTL_1SF_HZ <=>	112 to 144 Equivalent to Y1Z (Setting value: 128 fixed)	
		XSUS_1ST_B <=>	112 to 144 Equivalent to X1B (Setting value: 128 fixed)	
		YSUS_2ND_B <=>	112 to 144 Equivalent to Y2B (Setting value: 128 fixed)	
		XSUS_3RD_B <=>	112 to 144 Equivalent to X3B (Setting value: 128 fixed)	
		YSUS_B <=>	112 to 144 Equivalent to YSB (Setting value: 128 fixed)	
		XSUS_B <=>	112 to 144 Equivalent to XSB (Setting value: 128 fixed)	
		YSTL_KSB <=>	112 to 144 Equivalent to YTK (Setting value: 128 fixed)	
		YSTL_HZ <=>	112 to 144 Equivalent to YTZ (Setting value: 128 fixed)	
		YSTL_2SF_KSB <=>	112 to 144 Equivalent to Y2K (Setting value: 128 fixed)	
		YSTL_2SF_HZ <=>	112 to 144 Equivalent to Y2Z (Setting value: 128 fixed)	
		YSTL_FMR_KSB <=>	112 to 144 Equivalent to YNK (Setting value: 128 fixed)	
		YSTL_FMR_HZ <=>	112 to 144 Equivalent to YNZ (Setting value: 128 fixed)	
		SUS FREQ. <=>	MODE 1 to MODE 8 Equivalent to SFR (Setting value: MODE1)	
	6.2.2.6	PANEL-2 ADJ (+)	R-HIGH <=>	000 to 511 Equivalent to PRH (Setting value: Factory adjustment value)
		G-HIGH <=>	000 to 511 Equivalent to PGH (Setting value: Factory adjustment value)	
		B-HIGH <=>	000 to 511 Equivalent to PBH (Setting value: Factory adjustment value)	
		R-LOW <=>	000 to 999 Equivalent to PRL (Setting value: 512 fixed)	
		G-LOW <=>	000 to 999 Equivalent to PGL (Setting value: 512 fixed)	
		B-LOW <=>	000 to 999 Equivalent to PBL (Setting value: 512 fixed)	
		ABL <=>	000 to 255 Equivalent to ABL (Setting value: Factory adjustment value)	
	6.2.2.7	PANEL FUNCTION (+)	R-LEVEL <=>	LV-0 to LV-7 Equivalent to RRL (Setting value: Lv-2)
		G-LEVEL <=>	LV-0 to LV-7 Equivalent to RGL (Setting value: Lv-1)	
		B-LEVEL <=>	LV-0 to LV-7 Equivalent to RBL (Setting value: Lv-0)	
		ADDRESS L1 <=>	PH0 to PH9 Equivalent to AP0S* (Setting value: PH1)	
		ADDRESS L2 <=>	PH0 to PH9 Equivalent to AP0S* (Setting value: PH2)	
		ADDRESS L3 <=>	PH0 to PH9 Equivalent to AP1S* (Setting value: PH0)	
		ADDRESS L4 <=>	PH0 to PH9 Equivalent to AP1S* (Setting value: PH1)	
		ADDRESS U1 <=>	PH0 to PH9 Equivalent to AP2S* (Setting value: PH0)	
		ADDRESS U2 <=>	PH0 to PH9 Equivalent to AP2S* (Setting value: PH0)	
		ADDRESS U3 <=>	PH0 to PH9 Equivalent to AP3S* (Setting value: PH0)	
		ADDRESS U4 <=>	PH0 to PH9 Equivalent to AP3S* (Setting value: PH0)	
		STK MODE <=>	OFF <=> MODE1 to MODE8 <=>	Equivalent to SMK (Setting value: MODE1)


*: Setting value

Large Item			Variable / Adjustment Range	Remarks
Middle Item				
	Small Item			
6.2.2 PANEL FACTORY (+)				
6.2.2.8 ETC. (+)	BACKUP DATA <=>	NO OPRT <=> TRANSFER or ERR	Equivalent to BCP	
		DIGITAL EEPROM <=>	Equivalent to FAJ/UAJ	
		PD INFO. <=>	Equivalent to CPD	
		SD INFO. <=>	Equivalent to CSD	
		HR-MTR INFO. <=>	Equivalent to CHM	
		PM/B1-B5 <=>	Equivalent to CPM	
		P COUNT INFO. <=>	Equivalent to CPC	
		MAX TEMP. <=>	Equivalent to CMT	
	6.2.2.9 RASTER MASK SETUP (+)	MASK OFF	<=> 48V <=> 50V <=> 60V <=> 60P <=> 72V <=> 75V <=>	Equivalent to MKS+S00
		RST MASK 01 <=>		Equivalent to MKS+S51
	
		RST MASK 25 <=>		Equivalent to MKS+S75
	6.2.2.10 PATTERN MASK SETUP (+)	MASK OFF	<=> 48V <=> 50V <=> 60V <=> 60P <=> 72V <=> 75V <=>	Equivalent to MKS+S00
		PTN MASK 01 <=>		Equivalent to MKS+S01
	
		PTN MASK 49 <=>		Equivalent to MKS+S49
	6.2.2.11 COMBI MASK SETUP (+)	MASK OFF	<=> 48V <=> 50V <=> 60V <=> 60P <=> 72V <=> 75V <=>	Equivalent to MKC+S00
		CMB MASK 01 <=>		Equivalent to MKC+S01
	
		CMB MASK 17 <=>		Equivalent to MKC+S17
6.2.3 OPTION				
6.2.3.1 EDID WRITE MODE <=>		DISABLE <=> ENABLE	Exclusively used for production line	
6.2.3.2 ANTENNA MODE <=>		CABLE <=> AIR		
6.2.3.3 AFT <=>		DISABLE <=> ENABLE		
6.2.3.4 SYNC DET (+)			for the technical analysis	
6.2.3.5 CC (+)			for the technical analysis	
6.2.4 INITIALIZE				
6.2.4.1 SIDE MASK LEVEL (+)	SIDE MASK LEVEL <=>			
6.2.4.2 FINAL SETUP	DATA RESET <=>	NO <=> YES		
6.2.4.3 HMG/HG SERVICE MODE	MODE SHIFT <=>	NO <=> YES		
6.2.4.4 Wide XGA AUTO <=>		DISABLE <=> ENABLE	Exclusively used for technical analysis (details omitted)	

6.1.7 INDICATIONS IN SERVICE FACTORY MODE



Main-item indications



- ①
- ②
- ③
- ④

① Input function

Input Functions		OSD
VIDEO 1 to 7		VD 1 to 7
Terrestrial Wave A		ARA
Terrestrial Wave B		ARB
Cable A		CBA
Cable B		CBB
Home Gallery (Regular model only)		HG
Home Media Gallery (ELITE model only)		HMG
PC		PC

② SIG mode and Screen size

Note: See SIG-Mode Tables. (See next page.)

③ Color system and Signal type

Color System and Signal Type		OSD
NTSC	Composite input	NTV
	S-connector input	NTS
Y/CB/CR		CBR
Y/PB/PR		PBR
RGB		RGB
Digital Video signal		DIG

④ Option (Destination, Panel Generation, etc.)

Options	OSD
Regular model	ATB
ELITE model	AHB

② SIG Mode and Screen size (by User is displayed)

1st and 2nd characters : Resolution of the input signal

3rd and 4th characters : Refresh rate of the input signal

5th character : Selection of the screen size

■ Input signal mode table for video signals (resolutions and V frequencies)

1st to 4th Character		Signal Type	Fv (Hz)	Fh (kHz)
10	60	SDTV*525i	60.000	15.750
20	60	SDTV*525p	60.000	31.500
30	60	HDTV*1125i	60.000	33.750
40	60	HDTV*750p	60.000	45.000
50	24	HDTV*1125p	24.000	27.000
50	60	HDTV*1125p	60.000	67.500

Fv: Vertical Frequency, Fh: Horizontal Frequency

■ Input signal mode table for PC signals (resolutions and V frequencies)

1st to 4th Character		Signal Type	Fv (Hz)	Fh (kHz)
C1	70	720 x 400	70.087	31.469
C2	60	640 x 480	59.940	31.469
C4	60	800 x 600	60.317	37.879
C6	60	1280 x 720	60.000	44.800
C7	60	1024 x 768	60.004	48.363
C9	60	1360 x 768	60.015	47.712
D6	60	1280 x 1024	60.000	64.000

Fv: Vertical Frequency, Fh: Horizontal Frequency

■ Current selection of the screen size

5th Character	GUI Notation	VIDEO	PC	Remarks
0	DOT BY DOT	● (*)	—	
1	4:3	●	●	
2	FULL	●	●	
3	ZOOM	●	—	
4	CINEMA	●	—	
5	WIDE	●	—	

●: supported, —: unsupported

Note (*): It is effective only with models having the Full HD panel.

1 2 3 4

6.2 DETAILS OF FACTORY MENU

6.2.1 INFORMATION

A

■ Operation items

No.	Function/Display	Context	RS-232C Command
6.2.1.1	VERSION (1)	The Flash memory versions for each device are displayed. (Common part)	QS1
6.2.1.2	VERSION (2)	The Flash memory versions for each device are displayed. (Individual part)	QSE
6.2.1.3	VERSION (3)		
6.2.1.4	MAIN NG	The Shutdown Message ID/Event Times in Main Microcomputer are displayed.	QNG
6.2.1.5	TEMPERATURE	The Temperature/FAN rotating status in Main Microcomputer are displayed.	QMT
6.2.1.6	HOURL METER	The HOURL METER/P-COUNT information are displayed.	QS3
6.2.1.7	HDMI SIGNAL INFO 1	The Information of HDMI information files are displayed.	-
6.2.1.8	HDMI SIGNAL INFO 2		
6.2.1.9	VDEC SIGNAL INFO 1	Display the Signal Information on VDEC.	-
6.2.1.10	VDEC SIGNAL INFO 2		
6.2.1.11	DTV TUNING STATUS 1	Digital broadcast information and status is displayed upon receiving digital broadcast signal.	-
6.2.1.12	DTV TUNING STATUS 2		
6.2.1.13	DTV TUNING STATUS 3		
6.2.1.14	DTV TV-GUIDE BER	TV-Guide Bit Error Rate information	-
6.2.1.15	DEBUG INFO	Debug information	-

C

6.2.1.1 VERSION (1)

D

1	5	10	15	20	25	30	35	40
1								
5								
10								
15								
16								

E

Microcomputer	Item Name	Display Example (Execution program block)	Display Example (Boot block)
I/F microcomputer	I/F	-07A	01A
Main microcomputer	MAIN	-02K2	01K
Multi processor	MULTI PRS	-02K	01A
Multi processor	MULTI PIC	-02K	
Module microcomputer	MODULE	-06A	01A
Sequence processor	SEQ PRS	-03W_A	01A

Note: In the 29-32 rows, the Boot version information on each device is displayed.
In the 19-24 rows, the version of the execution program is displayed.

• **PANEL INFO:** It displays the generation of the panel, inchage and the type of the panel. For details on display values and settings, see "10: Panel Information" in "9.3.1. QS1 (PANEL STATUS)."

F

6.2.1.2 VERSION (2)

	1	5	10	15	20	25	30	35	40
1									
5									
10									
15									
16									

Meaning	Item Name	Display Example
DTV Hardware Version	HARDWARE	XXXXXXXXX
DTV Hardware Serial	SERIAL	01234567
DTV Runtime Version	RUNTIME	HHHHHHHHH
CFE Version	CFE	HHHHHHHHH
KERNEL Version	KERNEL	HHHHHHHHH
ROOTS Version	ROOTS	HHHHHHHHH
FLAGS	FLAGS	H/W (Y)
		DVR (Y) FONTS(Y)
		DFAST(Y) PLOG (Y)

6.2.1.3 VERSION (3)

	1	5	10	15	20	25	30	35	40
1									
5									
10									
15									
16									

Meaning	Item Name	Display Example
HMG/HG module Version	HMG/HG	01234567
User Password	PASSWORD	1234

6.2.1.4 MAIN NG

	1	5	10	15	20	25	30	35	40		
1			INFORMATION				VD1-30601-NTV-AHB				
		MAIN NG									
		MAIN			SUB			00151H21M			
5											
		1	MA-IIC		FE1		00031H50M				
		2	MA-IIC		AV-SW		00013H03M				
		3	MA-3L		IF		00002H52M				
		4	MAIN		-----		00001H58M				
10		5	TEMP2		-----		00000H07M				
		6									
		7									
		8									
15											
16											

MTB side's Shutdown NG information

OSD: MAIN	OSD: SUB	Cause of Shutdown
AUDIO	----	Short-circuit of the speaker terminal or failure of audio amplifier.
MODULE	----	Failure of communication to Module microcomputer.
MA-3L		3-wire Serial Communication of Main microcomputer.
	IF	Communication failure of IF microcomputer
	MULTI	Multi Processor communication failure
MA-IIC		IIC Communication failure of Main microcomputer
	FE1	Analog Tuner 1
	FE2	Analog Tuner 2
	MSPMAP	MSP/MAP
	AV-SW	AV Switch
	RGB-SW	RGB Switch
	VDEC	VDEC
	SDRAM	VDEC - SDRAM
	ADC	AD/PLL
	HDMI	HDMI
	US-MSP	MSP
MAIN		Communication failure of Main microcomputer
FAN	FAN1	Fan stopped
	FAN2	Fan stopped (Only with models having the Full HD panel)
TEMP2		Abnormally high temperature at MTB.
DTUNER		Failure of Digital Tuner
	PS/RST	Failure to DTV Starting
	RETRY	DTV communication error
	DE-BCM	Abnormally in BCM7038
	DE-FE	Tuner 1 or 2
	DE-CAS	Card I/F IC
	DE-VBI	VBI Slicer
	DE-EPI	EEPROM
	TV-G	TV-Guide Error
	HOME-G	Failure at Home Gallery
	DTVMID	Middleware
	DTVAPP	Application
RST-MA	M-DCDC	Abnormally in RST2 of MAIN Assy. (power decrease of DC-DC converter)
	RELAY	Abnormally in RST4 of MAIN Assy. (power decrease of Relay power)
HMG		Failure at Home Media Gallery
	HMG	Home Media Gallery startup error
MA-EEP		IIC communication line between EEPROM and MAIN.

	1	5	10	15	20	25	30	35	40	
1										
5										
10										
15										
16										

Operation:

Even if [←] key or [→] key is pressed, {CLEAR <=> :YES} ⇔ {CLEAR <=> :NO} is repeated.
 If the [ENTER/SET] key is kept on pressing for 5 second when the status of this menu is <YES>, clear process will begin.

6.2.1.5 TEMPERATURE

A present temperature and the FAN rotation are displayed.

If either [←] key or [→] key is pressed, the display data is refreshed.

	1	5	10	15	20	25	30	35	40
1									
5									
10									
15									
16									

• Display/Meaning

TEMP1 : The temperature of the sensor on the panel side is displayed by the Fahrenheit (F).

TEMP2 : The temperature conversion display is done with 10 bit the A/D input value of IF uCOM 90 pin (AN4). It is displayed by both the Fahrenheit (F) and 8 bit A/D value.

(Remark: When temperature (F) of the sensor becomes more than a specified temperature, the shutdown start of processing.)

FAN1 : The value of the FAN rotating state is displayed.

STOP: stopped, LOW: slow speed, HIGH: high speed.

FAN2 : The value of the rotation state of FAN is displayed.

During a rotation of FAN, 8bit D/A value output from 2 pin (DA0) of IF uCOM is displayed.

It is displayed with OFF during a stop (only for the FHD model).

B-SENSOR : The value that indicated the degree of brightness input into an Room light sensor is displayed.

AD value when the output of the Room light sensor was input into 89 pin (AN5) of IF uCOM is displayed.

6.2.1.6 HOUR METER

	1	5	10	15	20	25	30	35	40
1									
5									
10									
15									
16									

• Display/Meaning

Meaning	Item Name	Display Example	Corresponding RS-232C Command
HOUR METER (PANEL)	PANEL	00151H 21M	QS3
HOUR METER (MTB)	MTB	00151H 21M	QS3
POWER ON COUNTER	P-COUNT	00000095 TIMES	QS3
SYSTEM SERIAL	SERIAL		QS3

Note: The PANEL-side's HOUR METER/P-COUNT acquires information from the PANEL-side.

• MTB HOUR METER

In HOUR METER screen on Factory Menu, press the [ENTER] key, and then it moves to the screen to clear MTB HOUR METER. (MTB HOUR METER is cleared only.)


	1	5	10	15	20	25	30	35	40
1									
5									
10									
15									
16									

Operation:

Even if [←] key or [→] key is pressed, {CLEAR <=> :YES} ⇔ {CLEAR <=> :NO} is repeated.
 If the [ENTER/SET] key is kept on pressing for 5 second when the status of this menu is <YES>, clear process will begin.
 MTB HOUR METER is cleared only. PANEL HOUR METER is not cleared.

6.2.1.7 HDMI SIGNAL INFO 1

A



B

Displays the input signal information of HDMI terminal

Item	Meaning
PWR5V	+5 V power detection (18 pin of HDMI terminal)
VSYNC	VSYNC detection
CKDT	Clock detection
SCDT	SYNC detection
DCRPT	HDCP decryption status
AUTHEN	HDCP authentication status
MODE	HDMI mode status
BIST	----
NVAL	N value
CTSVAL	CTS value
AKSV	Shadow AKSV value
BKSV	Shadow BKSV value
IT CNT	IT content (AVI info)
EXTCOL	Extension calorimetry (AVI info)
RGV QR	RGB range (AVI info)
PIXDEP	Number of pixel/bit

C

D

E

F

6.2.1.8 HDMI SIGNAL INFO 2

	1	5	10	15	20	25	30	35	40
1									
5									
10									
15									
16									

Displays input signal status of HDMI terminal

Display Item	Meaning
H RES	Number of horizontal pixels (decimal)
V RES	Number of vertical lines (decimal)
H DE	Number of effectively horizontal pixels (decimal)
V DE	Number of effectively vertical lines (decimal)
INTRL	Interlace (=INT) or progressive (=PRG)
V POL	VSYSN polarity
H POL	HSYSN polarity
AUDIO (first line)	Sampling frequency. (ex. DVD: 48kHz, CD: 44.1kHz) *1
AUDIO (second line)	PCM (PCM) or No PCM (=no PCM)
AUDIO (third line)	Quantization bit
COL SP	Color space (AVI Info) (422 or 444 or RGB) *2
COLMET	Calorimetry (AVI Info) (SD: 601, HD:709) *2
ASPECT	Aspect (AVI Info)
ACTIVE	Video active format (AVI Info)
V FMT	Video identification code (AVI Info)
PIX RP	Pixel repeat value for 2880 dot
SOURCE (first line)	Vendor name of the emission device
SOURCE (second line)	Model name of the emission device

*1: Confirm if this item is displayed when the audio is not outputted.

*2: If may not match to the state of source devices when the color is abnormal.

Display of HDMI FACTORY and correspondence of resolution

Please confirm the following 5 items when the picture doesn't come out.

Input Signal	FACTORY Display				
	H RES	V RES	H DE	V DE	V FMT
480i (525i) @ 60	858	262 or 263	720	240	720x480i @ 60
480p (525p) @ 60	858	525	720	480	720x480p @ 60
1080i (1125i) @ 60	2200	562 or 563	1920	540	1920x1080i @ 60
720p (750p) @ 60	1650	750	1280	720	1280x720p @ 60
1080p (1125p) @ 60	2200	1125	1920	1080	1920x1080p @ 60
1080p (1125p) @ 24	2750	1125	1920	1080	1920x1080p @ 24

6.2.1.9 VDEC SIGNAL INFO 1

A

	1	5	10	15	20	25	30	35	40															
1			I N F O R M A T I O N											V D 1 - 3 0 6 0 1 - N T V - A H B										
			V D E C S I G N A L I N F O 1																					
5			M V D E C - 0 0 0 : 0 0											S V D E C - 4 0 0 : 0 0										
			- 0 0 1 : 0 0											- 4 0 1 : 0 0										
			- 0 9 4 : 0 0											- 4 9 4 : 0 0										
			- 0 9 5 : 0 0											- 4 9 5 : 0 0										
			- 0 9 6 : 0 0											- 4 9 6 : 0 0										
10			- 0 9 8 : 0 0											- - - : - -										
			- 1 B 5 : 0 0											- 5 B 5 : 0 0										
			- 1 B 6 : 0 0											- 5 B 6 : 0 0										
			- 1 B 7 : 0 0											- 5 B 7 : 0 0										
15																								
16																								

B

Displays signal status that is input to VDEC.

Device	Sub Address (Main screen)	Sub Address (Sub screen)	Meaning
VDEC	000h	400h	Line system distinction result
	001h	401h	VTR distinction result
	094h	494h	Slot number
	095h	495h	Color system distinction result
	096h	496h	ACC coefficient
	098h	---	3D YC flag
	1B5h	5B5h	MV detection 1
	1B6h	5B6h	MV detection 2
	1B7h	5B7h	MV detection 3

6.2.1.10 VDEC SIGNAL INFO 2

D

	1			5				10				15				20				25				30				35				40	
1																																	

Displays signal status that is input to VDEC.

Device	Sub Address (Main screen)	Sub Address (Sub screen)	Meaning
VDEC	205h	605h	CC detection 1
	208h	608h	CC detection 2
	20Bh	60Bh	CC-CRI detection
	20Ch	60Ch	XDS content advisor 0
	20Dh	60Dh	XDS content advisor 1

6.2.1.11 DTV TUNING STATUS 1

Displays digital broadcast signal information and status upon receiving digital signal.

1	5	10	15	20	25	30	35	40
1			INFORMATION		CBA-30601-DIG-AHB			
			DTV TUNING STATUS 1					
5			INBAND FREQUENCY	:	675MHz			
			MODULATION	:	QAM 256			
			STATUS	:	LOCK			
			AGC	:	85%			
10			CORRECTED ERROR	:	12345			
			UNCORRECTED ERROR	:	678			
			TIME	:	45sec			
15								
16								

6.2.1.12 DTV TUNING STATUS 2

Displays digital broadcast signal information and status upon receiving digital signal.

[illegible]

6.2.1.13 DTV TUNING STATUS 3

Displays digital broadcast signal information and status upon receiving digital signal.

1	5	10	15	20	25	30	35	40
1				INFORMATION			CBA-30601-DIG-AHB	
				DTV TUNING STATUS	3			
5				OOB FREQUENCY			70MHz	
				STATUS			UNLOCK	
				AGC			72%	
				CORRECTED ERROR			12345	
10				UNCORRECTED ERROR			678	
				TIME			45 sec	
15								
16								

6.2.1.14 DTV TV-GUIDE BER

Exclusively used for production line. TV-Guide error bit ratio information is displayed.

6.2.1.15 DEBUG INFO

Exclusively used for technical analysis. Debug information for development use is displayed.

1234

6.2.2 PANEL FACTORY (+)

■ Operation Items

A

This is the menu screen for the adjustment of the panel. Data acquisition and value adjustment can be performed for the following items:

No.	Indication	Description of functions
6.2.2.1	PANEL INFORMATION	Data, such as the version of the microcomputer of the panel, product serial number, and statuses of memories for adjustment values for the main unit and for backup, are displayed.
6.2.2.2	PANEL WORKS	Operation data, such as accumulated pulse-meter count, accumulated hour-meter count, accumulated power-on count, and the temperature detected by the sensor, are displayed.
6.2.2.3	POWER DOWN	The power-down history is displayed, with the hour-meter values that indicate the hour values when power-downs occurred.
6.2.2.4	SHUT DOWN	The shutdown history is displayed, with the hour-meter values that indicate the hour values when shutdowns occurred.
6.2.2.5	PANEL-1 ADJ (+)	Settings of the driving pulse timing and driving voltage can be performed.
6.2.2.6	PANEL-2 ADJ (+)	White balance and ABL (power consumption) for the panel can be set.
6.2.2.7	PANEL FUNCTION (+)	Perform panel-degradation correction-level setting, phase adjustment of the address, and the streaking-correction setting.
6.2.2.8	ETC. (+)	Copying of backup data and clearance of various data can be performed.
6.2.2.9	RASTER MASK SETUP (+)	The mask indication (RASTER) can be set and indicated.
6.2.2.10	PATTERN MASK SETUP (+)	The mask indication (PATTERN) can be set and indicated.
6.2.2.11	COMBI MASK SETUP (+)	The mask indication (COMBI) can be set and indicated.

C

■ Details of indications in each layer

- In the following examples, GUI images for a 50-inch model are indicated. Although the display areas for the menu for 42-inch and 50-inch models are different, the items to be displayed are the same.

6.2.2.1 PANEL INFORMATION

- Data, such as the version of the microcomputer of the panel, product serial number, and statuses of memories for adjustment values for the main unit and for backup, are displayed. No other layers are nested below this layer, and there are no adjustment items.

		1	5	10	15	20	25	30	32
1			PANEL	FACT.		IN1-30602-RGB-JHB			
	AREA 1		PANEL	INFORMATION					
2			MODULE	-01A		01A			
3			-PRG	-01A					
4			-DAT	-01A					
5			SEQ PRS	-01Y		02A			
6			-PRQ	-01Y					
7			-PIC	-01Y					
8			-SEQ	520Y					
9									
A			SERIAL						
B			DIG.EEP	ADJUSTED					
C			BACKUP	NO DATA!					
D									
E									

Display area for 42-inch model

Display area for 50-inch model

■ Key operation

- <DOWN> : Shifting to PANEL WORKS
- <UP> : Shifting to COMBI MASK SETUP (+)
- <L/R> : Updating displayed information

■ Display items:

- MODULE : The version of data written in the Module microcomputer (IC3151) is indicated.
- PRG : The program version of the Module microcomputer is indicated.
- DAT : The data version of the Module microcomputer is indicated.
- SEQ-PRG : The version of data written in the Sequence LSI (IC3401) is indicated.
- PRG : The program version of the Sequence LSI is indicated.
- PIC : The Picture-data version of the Sequence LSI is indicated.
- SEQ : The sequence-data version of the Sequence LSI is indicated.
- SERIAL : The serial number of the module is indicated.
- DIG.EEP : The adjusted status of the EEPROM that is mounted on the DIGITAL Assy is indicated.
- BACKUP : The adjusted status of the EEPROM for backup that is mounted on the SENSOR Assy is indicated.

6.2.2.2 PANEL WORKS

- Data on operations, such as the accumulated pulse-meter counts, hour-meter count, power-on count, and temperature detected by the sensor, are sent back. No other layers are nested below this layer, and there are no adjustment items.

		1	5	10	15	20	25	30	32
1			PANEL	FACT.		IN1-30602-RGB-JHB			
	AREA 1		PANEL	WORKS					
2									
3			PM-B1		00000715	M			
4			PM-B2		00000607	M			
5			PM-B3		00000852	M			
6			PM-B4		00000668	M			
7			PM-B5		00000733	M			
8									
9			HR-MTR		000025H	20M			
A			P-COUNT		00000095	TIMES			
B			TEMP1		+27.4	/	+70.8		
C									
D									
E									

■ Key operation

- <DOWN> : Shifting to POWER DOWN
- <UP> : Shifting to PANEL INFORMATION
- <L/R> : Updating displayed information

← Temperature unit is " °C (Centigrade) ".

■ Contents of the Display item

- PM-B1 to B5: The accumulated pulse-meter counts for the 5 blocks on the screen are indicated. (the lowest-order digit represents millions of pulses.)
- HR-MTR: The hour-meter value (accumulated power-on hours) is indicated.
- P-COUNT: The accumulated power-on count is indicated.
- TEMP1: The current panel temperature and the historical maximum temperature recorded in memory are indicated. The range of temperature indication is from -50.0 to +99.9. (The temperature unit is " °C (Centigrade) ".)

6.2.2.3 POWER DOWN

- The power-down history is displayed. The last most 8 power-down histories are displayed with the hour-meter values that indicate the hours when power-downs occurred. No other layers are nested below this layer, and there are no adjustment items.

		1	5	10	15	20	25	30	32
1		PANEL	FACT.			IN1-30602-RGB-JHB			
	AREA 1	POWER	DOWN						
2		1ST		2ND		000124H	23M		
3									
4	1	X-DRV				000124H	21M		
5	2	Y-SUS		SCAN		000115H	05M		
6	3	SCAN				000107H	53M		
7	4	POWER		SCAN		000098H	47M		
8	5	ADRS				000051H	30M		
9	6	SCN5V		X-DCDC		000022H	21M		
A	7	Y-DCDC				000000H	57M		
B	8							H	M
C									
D									
E									

■ Key operation

- <DOWN> : Shifting to SHUT DOWN
- <UP> : Shifting to PANEL WORKS
- <L/R> : Updating displayed information

<Causes of power-down and corresponding OSD indications>

Cause of power-down	OSD Indication	Cause of power-down	OSD Indication
POWER SUPPLY Unit	P-PWR	ADDRESS Assy	ADRS
SCAN Assy	SCAN	X DRIVE Assy	X-DRV
5 V power for SCAN Assy	SCN5V	DC/DC converter for X drive	X-DCDC
Y DRIVE Assy	Y-DRV	X-drive SUS circuit	X-SUS
DC/DC converter for Y drive	Y-DCDC	Unknown	UNKNOW
Y-drive SUS circuit	Y-SUS		

- * When power-down is confirmed, the factor is displayed as "1st", "2nd", according to the accuracy order.
- * The power-down history is not recorded when the power-down occurred at the same place and same time.

6.2.2.4 SHUT DOWN

- The shutdown history is displayed. The last most 8 shutdown histories are displayed with the hour-meter values that indicate the hours when shutdowns occurred. No other layers are nested below this layer, and there are no adjustment items.

		1	5	10	15	20	25	30	32
1		PANEL	FACT.			IN1-30602-RGB-JHB			
	AREA 1	SHUT	DOWN						
2		MAIN		SUB		000124H	23M		
3									
4	1	TMP-NG		TEMP-H		000124H	21M		
5	2	SQ-LSI		RTRY		000115H	05M		
6	3	MD-IIC		DAC2		000107H	53M		
7	4	SQ-LSI		VER-HS		000098H	47M		
8	5	MD-IIC		BACKUP		000051H	30M		
9	6	SQ-LSI		BUSY		000012H	07M		
A	7							H	M
B	8							H	M
C									
D									
E									

■ Key operation

- <DOWN> : Shifting to PANEL-1 ADJ (+)
- <UP> : Shifting to POWER DOWN
- <L/R> : Updating displayed information

- * When there is detail information when shutdown occurred, the possible defective part is displayed as Sub information.

<Cause of shut-down and corresponding OSD Indication >

Cause of shut-down (MAIN)		Cause of shut-down (SUB)	
Item	OSD Indication	Item	OSD Indication
Drive Processing IC	SQ_LSI	Communication Error	RTRY
		Drive Stop	SQNO
		Communication Busy	BUSY
		Version mismatching (H/S) (M/S)	VER-HS, VER-MS
MDU-IIC	MD-IIC	MAIN EEPROM Communication Error	EEPROM
		BACKUP EEPROM Communication Error	BACKUP
		DAC1 Communication Error	DAC1
		DAC2 Communication Error	DAC2
Abnormally in RST2 power supply	RST2	-	-
Panel temperature	TMP-NG	High temperature of the panel	TEMP-H
		Low temperature of the panel	TEMP-L

6.2.2.5 PANEL-1 ADJ (+)

- Timing and voltage for the driving pulse are set. At third line of the screen, the WB (White Balance) table and frequency table indicating operation status are displayed, and at fifteenth line of the screen, the item for the upper nested layer (PANEL-1 ADJ [+]) is displayed. Pressing the SET key shifts the screen to the next nested layer below for item selection.

		1	5	10	15	20	25	30	32
1		PANEL	FACT.			IN1-30602-RGB-JHB			
	AREA 1								
2									
3									
4									
5									
6									
7									
8									
9									
A									
B									
C									
15	D	PANEL-1	ADJ (+)						
16	E								

Key operation

- <DOWN> : Shifting to PANEL-2 ADJ (+)
- <UP> : Shifting to POWER DOWN
- <SET> : Shifting to the next nested layer

- When the screen is shifted to the next nested layer below, the item of the layer above is indicated at third line of the screen, and the item of the layer below is indicated at fifteenth line.
- The configuration of the menu screen is the same for any adjustment item that has lower layers.
- To confirm that the change in the SUS FREQ. setting has resulted in diminishing of AM radio interference in this layer, after changing the setting, turn the unit off then back on.

		1	5	10	15	20	25	30	32
1		PANEL	FACT.			IN1-30602-RGB-JHB			
	AREA 1	PANEL-1	ADJ						
2									
3									
4									
5									
6									
7									
8									
9									
A									
B									
C									
15	D	VOL OFFSET	<=>						
16	E								

Key operation

- <DOWN> : Shifting to the next item
- <UP> : Shifting to the previous item
- <RIGHT> : Adding by one to the adjustment/setting value
- <LEFT> : Subtracting by one from the adjustment/setting value
- <VOL+> : Adding by 10 to the adjustment/setting value
- <VOL-> : Subtracting by 10 from the adjustment/setting value
- <SET> : Determining the adjustment/setting value and shifting to the upper layer

6.2.2.6 PANEL-2 ADJ (+)

- White balance can be adjusted by adjusting R, G, and B gain. Pressing the SET key shifts the screen to the next nested layer below for item selection.

		1	5	10	15	20	25	30	32
1		PANEL	FACT.			IN1-30602-RGB-JHB			
	AREA 1					[TBL1 / 60VS]			
	2								
5	3								
	4								
	5								
	6								
	7								
10	8								
	9								
B	A								
	B								
	C								
15	D	PANEL-2	ADJ (+)						
16	E								

Key operation

- <DOWN> : Shifting to PANEL FUNCTION (+)
- <UP> : Shifting to PANEL-1 ADJ (+)
- <SET> : Shifting to the next nested layer

		1	5	10	15	20	25	30	32
1		PANEL	FACT.			IN1-30602-RGB-JHB			
	AREA 1	PANEL-2	ADJ			[TBL1 / 60VS]			
	2								
5	3								
	4								
	5								
	6								
	7								
10	8								
	9								
	A								
	B								
	C								
15	D	R-HIGH	<=>			: 2 5 6			
16	E								

Key operation

- <DOWN> : Shifting to the next item
- <UP> : Shifting to the previous item
- <RIGHT> : Adding by one to the adjustment/setting value
- <LEFT> : Subtracting by one from the adjustment/setting value
- <VOL+> : Adding by 10 to the adjustment/setting value
- <VOL-> : Subtracting by 10 from the adjustment/setting value
- <SET> : Determining the adjustment/setting value and shifting to the upper layer

The ABL/WB adjustment values are grouped into up to four tables, depending on the drive sequences. The adjustment value for the actually driven table is displayed. The number of the adjustment table and the drive sequence currently selected are displayed on the right side of the third line as the On-Screen display.

Drive sequence and adjustment table

Sequence Name	Video50	Video60	Video72	Video75	PC60
Adjustment Value Table	TBL2	TBL1	TBL1	TBL3	TBL4

6.2.2.7 PANEL FUNCTION (+)

- A setting for panel degradation correction can be made. Pressing the SET key shifts the screen to the next nested layer below for item selection.

[illegible]

■ Key operation

<DOWN> : Shifting to ETC.(+)

<UP> : Shifting to PANEL-2 ADJ (+)

<SET> : Shifting to the next nested layer

[illegible]

■ Key operation

<DOWN> : Shifting to the next item

<UP> : Shifting to the previous item

<RIGHT> : Adding by one to the adjustment/
setting value

<LEFT> : Subtracting by one from the adjustment/setting value

<SET> : Determining the adjustment/setting value and shifting to the upper layer

6.2.2.8 ETC. (+)

- The setting about the backup of panel adjusting value and various data on panel operational information can be cleared. Pressing the SET key shifts the screen to the next nested layer below for item selection.

■ Key operation

- <DOWN> : Shifting to RASTER MASK SETUP (+)
 <UP> : Shifting to PANEL FUNCTION (+)
 <SET> : Shifting to the next nested layer

		1	5	10	15	20	25	30	32
1		PANEL	FACT.			IN1-30602-RGB-JHB			
	AREA 1					[TBL1/60VS]			
	2								
5	3								
	4								
	5								
	6								
	7								
10	8								
	9								
B	A								
	B								
	C								
15	D ETC. (+)								
16	E								

■ Key operation

- <DOWN> : Shifting to the next item
 <UP> : Shifting to the previous item
 <RIGHT> : Adding by one to the adjustment/setting value
 <LEFT> : Subtracting by one from the adjustment/setting value
 <SET> : Determining the adjustment/setting value and shifting to the upper layer

		1	5	10	15	20	25	30	32
1		PANEL	FACT.			IN1-30602-RGB-JHB			
	AREA 1	ETC.				[TBL1/60VS]			
	2								
5	3								
	4								
	5								
	6								
	7								
10	8								
	9								
	A								
	B								
	C								
15	D BACKUP DATA <=> : NO OPRT								
16	E								

6.2.2.9 RASTER MASK SETUP (+)

- This menu set the RASTER MASK and the drive sequence at RASTER MASK state. Pressing the SET key shifts the screen to the next nested layer below for item selection.

		1	5	10	15	20	25	30	32																							
1			P	A	N	E	L	F	A	C	T	.			I	N	1	-	3	0	6	0	2	-	R	G	B	-	J	H	B	
		A	R	E	A	1																										
		2																														
5		3																														
		4																														
		5																														
		6																														
		7																														
10		8																														
		9																														
		A																														
		B																														
		C																														
15		D	R	A	S	T	E	R		M	A	S	K		S	E	T	U	P		(+)									
16		E																														

■ Key operation

- <DOWN> : Shifting to PATTERN MASK SETUP (+)
- <UP> : Shifting to ETC. (+)
- <SET> : Shifting to the next nested layer

		1	5	10	15	20	25	30	32																							
1			P	A	N	E	L	F	A	C	T	.			I	N	1	-	3	0	6	0	2	-	R	G	B	-	J	H	B	
		A	R	E	A	1																										
		2																														
5		3																														
		4																														
		5																														
		6																														
		7																														
10		8																														
		9																														
		A																														
		B																														
		C																														
15		D	R	S	T						M	A	S	K		0	1															
16		E																														

■ Key operation

- <DOWN> : Shifting to the next MASK
- <UP> : Shifting to the previous MASK
- <RIGHT> : Changing MASK sequence (+)
- <LEFT> : Changing MASK sequence (-)
- <SET> : Determining the adjustment/setting value and shifting to the upper layer

- The MASK indication sequence can be changed among 48V, 50V, 60V, 72V, 75V and 60P, using the Right or Left key. The selected sequence and the ABL/WB table are retained until the mask is turned off.

6.2.2.10 PATTERN MASK SETUP (+)

- This menu set the PATTERN MASK and the drive sequence at PATTERN MASK state. Pressing the SET key shifts the screen to the next nested layer below for item selection.

			1		5		10		15		20		25		30	32																	
1				PANEL FACT .												IN1-30602-RGB-JHB																	
	AREA 1															[TBL1 / 60VS]																	
		2																															
5		3																															
		4																															
		5																															
		6																															
		7																															
10		8																															
		9																															
		A																															
		B																															
		C																															
15		D PATTERN MASK SETUP (+)																															
16		E																															

■ Key operation

- <DOWN> : Shifting to COMBI MASK SETUP (+)
- <UP> : Shifting to RASTER MASK SETUP (+)
- <SET> : Shifting to the next nested layer

			1		5		10		15		20		25		30	32																					
1				P	A	N	E	L	F	A	C	T	.			I	N	1	-	3	0	6	0	2	-	R	G	B	-	J	H	B					
			A	R	E	A	1	P	A	T	T	E	R	N	M	A	S	K	S	E	T	U	P			[T	B	L	1	/	6	0	V	S]	
			2																																		
5			3																																		
			4																																		
			5																																		
			6																																		
			7																																		
10			8																																		
			9																																		
			A																																		
			B																																		
			C																																		
15			D	P	T	N	M	A	S	K	0	1																									
16			E																																		

■ Key operation

- <DOWN> : Shifting to the next MASK
- <UP> : Shifting to the previous MASK
- <RIGHT> : Changing MASK sequence (+)
- <LEFT> : Changing MASK sequence (-)
- <SET> : Determining the adjustment/setting value and shifting to the upper layer

- The MASK indication sequence can be changed among 48V, 50V, 60V, 72V, 75V and 60P, using the Right or Left key. The selected sequence and the ABL/WB table are retained until the mask is turned off.

6.2.2.11 COMBI MASK SETUP (+)

- This menu set the COMBI MASK and the drive sequence at COMBI MASK state. Pressing the SET key shifts the screen to the next nested layer below for item selection.

[illegible]

■ Key operation

<DOWN> : Shifting to PANEL INFORMATION
<UP> : Shifting to PATTERN MASK SETUP
(+)
<SET> : Shifting to the next nested layer

[illegible]

■ Key operation

<DOWN> : Shifting to the next MASK
 <UP> : Shifting to the previous MASK
 <RIGHT> : Changing MASK sequence (+)
 <LEFT> : Changing MASK sequence (-)
 <SET> : Determining the adjustment/setting
 value and shifting to the upper layer

- The MASK indication sequence can be changed among 48V, 50V, 60V, 72V, 75V and 60P, using the Right or Left key. The selected sequence and the ABL/WB table are retained until the mask is turned off.

6.2.3 OPTION

Operation item

No.	Function	Content	RS-232C
6.2.3.1	EDID WRITE MODE <=>	DISABLE <=> ENABLE	----
6.2.3.2	ANTENNA MODE <=>	CABLE <=> AIR	----
6.2.3.3	AFT <=>	OFF <=> ON (Controls AFT action)	----
6.2.3.4	SYNC DET (+)	Exclusively used for technical analysis	----
6.2.3.5	CC (+)	Exclusively used for technical analysis	----

6.2.3.1 EDID WRITE MODE <=>

Exclusively used for production line.

6.2.3.2 ANTENNA MODE <=>

Exclusively used for production line.

6.2.3.3 AFT <=>

Exclusively used for production line.

6.2.3.4 SYNC DET (+)

Exclusively used for technical analysis (details omitted).

6.2.3.5 CC (+)

Exclusively used for technical analysis (details omitted).

6.2.4 INITIALIZE

Operation item

No.	Function	Content	RS-232C
6.2.4.1	SIDE MASK LEVEL (+)	Configure the color of the side mask.	SML
6.2.4.2	FINAL SETUP (+)	Initialize flash memorys on virgin product status	FST
6.2.4.3	HMG/HG SERVICE MODE	Enter HMG/HG SERVICE MODE	----
6.2.4.4	Wide XGA AUTO <=>	Exclusively used for technical analysis.	----

Note: When there is an altered history due to an open TRAP SW, if the "DISPLAY" key is held for at least 5 seconds on the above menu, the altered history will be cleared and the unit will be back to normal.

6.2.4.1 SIDE MASK LEVEL (+)

	1	5	10	15	20	25	30	35	40																															
1			INITIALIZE												VD1-30601-NTV-AHB																									
5																																								
10																																								
15			SIDE MASK LEVEL (+)																																					
16																																								

To configure sidemask level (To adjust the values, input signal is required).

Display	Content	RS-232C
SIDE MASK LEVEL <=>	Adjust Side Mask level (Initial value: 80, Adjustable range: 000 to 255)	SML

6.2.4.2 FINAL SETUP (+)

	1	5	10	15	20	25	30	35	40																														
1			INITIALIZE													VD1-30601-NTV-AHB																							
		FINAL SETUP																																					
5																																							
10																																							
15		DATA RESET <=>																																	: NO				
16																																							

- To reset each memory values to factory default values. Factory command is "FST".
- When the configuration is set to <NO> and the [ENTER/SET] key is pressed, no action is taken and the menu returns to previous screen.
- When the configuration is set to <YES> and the [ENTER/SET] key is pressed for 5 seconds, the reset action executes.

Be sure to disconnect and connect the AC cable after FINAL SETUP.

When replacing the MAIN Assy, the FINAL SETUP is required.

6.2.4.3 HMG/HG SERVICE MODE


A		1	5	10	15	20	25	30	35	40
	1									
B	15									
	16									

The value of all memorized data are set to shipment status.
If the [ENTER] key is kept on pressing for 5 second when the status of this menu is <YES>, HMG/HG SERVICE mode will be done.


For ELITE model
Be sure to do above procedure at input fuction except HMG.
For details, refer to the service manual for the ELITE model.

HG (Home Gallery) SERVICE MODE (Regular model)

- 1. Home Gallery Screen
- (1) When the USB device is connected



- (2) When the USB device is not connected



(3) Each item explanation (Example)

```

① ① PTP Support : Disabled
② ② T: Bus=03 Lev=01 Prnt=01 Port=00 Cnt=01 Dev#= 2 Spd=480 MxCh= 0
③ ③ D: Ver= 2.00 Cls=00(>ifc ) Sub=00 Prot=00 MxPS=64 #Cfgs= 1
④ ④ P: Vendor=0dda ProdID=2026 Rev= 1.4f
⑤ ⑤ S: Manufacturer=ICSI
⑥ ⑥ S: Product=USB2.0 Card Reader
⑦ ⑦ S: SerialNumber=0000001
⑧ ⑧ C:* #Ifs= 1 Cfg#= 1 Atr=80 MxPwr=500mA
⑨ ⑨ I: If#= 0 Alt= 0 #EPs= 2 Cls=08(stor.) Sub=06 Prot=50 Driver=usb-storage
⑩ ⑩ E: Ad=82(I) Atr=02(Bulk) MxPS= 512 Ivl=0ms
⑪ ⑪ E: Ad=01(O) Atr=02(Bulk) MxPS= 512 Ivl=0ms

```

① PTP Support

Disable	PTP Non-Support	String
Enable	PTP Support	String

② T (Topology info)

Bus	Bus Number	Decimal
Lev	Level in topology for this bus	Decimal
Prnt	Parent Device Number	Decimal
Port	Connector/Port on Parent for this device	Decimal

Cnt	Count of devices at this level	Decimal
Dev#	Device Number	Decimal
Spd	Device Speed in Mbps	Decimal
MxCh	Max Children	Decimal

③ D (Device descriptor info)

Ver	Device USB version	Hexadecimal
Cls	Device Class	Hexadecimal
Sub	Device Sub Class	Hexadecimal
Prot	Device Protocol	Hexadecimal
MxPS	Max Packet Size of Default Endpoint	Decimal
#Cfgs	Number Configurations	Decimal

④ P (Product ID info)

Vendor	Vendor ID code	Hexadecimal
ProdID	Product ID code	Hexadecimal
Rev	Product revision number	Hexadecimal

⑤ S (String descriptor info - 1)

Manufacturer	String
--------------	--------

⑥ S (String descriptor info - 2)

Product	String
---------	--------

⑦ S (String descriptor info - 3)

SerialNumber	String
--------------	--------

⑧ C (Configuration descriptor info)

#Ifs	Number of Interfaces	Decimal
#Cfg	Configuration Number	Decimal
Atr	Attributes	Hexadecimal
MxPwr	MaxPower in mA	Decimal

⑨ I (Interface descriptor info)

If#	Interface Number	Decimal
Alt	Alternate Setting Number	Decimal
#Eps	Number of Endpoints	Decimal
Cls	Interface Class	Hexadecimal(String)
Sub	Interface Sub Class	Hexadecimal
Prot	Interface Protocol	Hexadecimal
Driver	Driver name	String

⑩ E (Endpoint descriptor info)

⑪ E (Endpoint descriptor info)

Ad	Endpoint Address (I=In, O=Out)	Hexadecimal(String)
Atr	Attributes	Hexadecimal(String)
MxPS	Endpoint Max Packet Size	Decimal
Ivl	Interval (max) between transfers	Decimal

2. End method

It is the same as the case that Home Gallery displays.

6.2.4.4 Wide XGA AUTO <=>

Exclusively used for technical analysis (details omitted).


7. DISASSEMBLY

7.1 CHART OF REMOVAL ORDER FOR THE MAIN PARTS AND BOARDS

Note: Even if the unit shown in the photos and illustrations in this manual may differ from your product, the procedures described here are common.

Chart of removal order for the main parts and boards


It is efficient to proceed with removal of the main parts and boards in the order shown in the chart below:



Disassembly

Speaker System

- ① Disconnect the speaker cables.
- ② Remove the three screws.
- ③ Remove the speaker system.
- ④ Remove the three brackets by removing the six screws.



A

Disassembly



1 Rear Case (508)

● Function button panel

- ① Remove the two screws.
- ② Remove the function button panel.

● Side input cover


- ③ Remove the two screws.
- ④ Remove the side input cover.



Rear case (508)

● Rear case (508)

- ① Remove the 17 screws. (AMZ30P060FTB)
- ② Remove the 12 screws. (TBZ40P080FTB)
- ③ Remove the two screws. (ABA1332)
- ④ Remove the one screw. (ABA1341)
- ⑤ Remove the rear case (508).



Tightening sequence for the screws when assembling

When assembling the Rear Case (508), tighten the screws in the following sequence:

1. Tighten the screw (②-1).
2. Tighten the screw (②-2).
3. Tighten the eight screws in that order (②-3 to 6).
4. Tighten other screws.



2 Access to PCB Assys

● SIDE IO Assy

- ① Remove the four screws.
- ② Remove the two screws.
- ③ Remove the four screws.
- ④ Remove the side input panel (8U).

● 50 X DRIVE Assy

- ① Remove the two screws.
- ② Remove the side input shield with PCB.
- ③ Diagnose the 50 X DRIVE Assy.

● 50 Y DRIVE Assy

- ① Remove the two screws.
- ② Remove the function button shield with PCB.
- ③ Diagnose the 50 Y DRIVE Assy.

● MAIN Assy


- ① Disconnect cables, connectors, as required.
- ② Remove the two screws.
- ③ Remove the two screws.
- ④ Remove the POD cover.
- ⑤ Remove the POD stay A with PCB.

■ How to remove the bridge connector connecting between the MAIN and TANSI Assys


- (1) Grip the two short edges of the connector with longnose pliers.
- (2) Insert a finger between the longnose pliers and the board to protect the board and the mounted parts on the board from accidental damage by the pliers then, using your finger as a fulcrum and the pliers as a lever, pry the connector upward to remove it.



• For 50 X DRIVE Assy








• For SIDE IO Assy



• For 50 Y DRIVE Assy

Function button shield SIDE KEY Assy




3 Terminal Panel B (50U)

- ① Remove the four screws.
- ② Remove the two screws.
- ③ Remove the 10 screws.
- ④ Remove the four screws.

Note:

To remove the screws ④ with the unit attached to the side-speaker-type stand, remove the bolt for fixing the stand and lift the unit up a little.


- ⑤ Remove the terminal panel B (50U).



Terminal panel B (50U)


Note:

The wiring shown in the photo is different from the actual wiring, because the product in the photo is a prototype. Upon servicing, be sure to restore the original wiring of the unit after repair work.




4 Front Case Assy (508PU)


- ① Remove the four rivets.
- ② Pull the lower part of the Front case Assy (508PU) toward you and out.
- ③ Remove the Front case Assy (508PU), by pulling it upward.



Front case Assy (508PU)




Turn it not to press the rivet.
(Because when the rivet presses, fit in once again.)





5 Access to 50 DIGITAL Assy

① Remove the two screws.

② Remove the four screws.



③ Lift the Multi base section to the direction of the arrow.





PDP-5080HD


A

6 Exchange of SCAN IC


- ① Loosen the jumper wire.
- ② Remove the 50LED&IR Assy by removing the one nylon rivet.
- ③ Remove the two screws.
- ④ Unhook the six hooks.
- ⑤ Remove the panel holders V1 (50) and V2 (50).



- ⑥ Remove the three screws.
- ⑦ Remove the one screw.
- ⑧ Remove the front chassis VL (50).



Exchange



7.3 DISASSEMBLY AND REASSEMBLY PRECAUTIONS FOR SPEAKER SYSTEM

SERVICE PRECAUTIONS


Be careful in handling this product, because scratches on cabinet coating are easily noticeable.
When working on this unit, be sure to place the cabinet on a piece of soft cloth for protection.

(1) Grille Assy


The Grille Assy is secured to the baffle plate with two-sided tape and bosses. When removing the Grille Assy, it is necessary to wear cotton gloves.

● Disassembly


1. Insert the tip of your gloved finger into the gap between the Grille Assy in front and the corner of the baffle plate so that the Grille Assy is slightly lifted.



2. Insert the gloved finger to the extent of the second joint into the gap between the cabinet and the Grille Assy.



3. Alternately and gradually lift the left and right sides of the Grille Assy by about 5 cm, sliding gloved fingers along the cabinet. When lifting the Grille Assy, be sure to lift the left and right sides alternately, but not both sides simultaneously.




Note: Be careful not to bend the Grille Assy too far. Otherwise, it may be damaged.

OK: Good example **NG:** Bad example

OK



NG



● Reassembly

Remove the old two-sided tape attached to the rear side of the Grille Assy and the front side of the baffle, and adhere new two-sided tape. Press the bosses into the baffle plate and press the entire grill into position.
(Press the bosses from the woofer frame.)

(2) Woofer (Disassembly)

The woofer is secured to the baffle plate with four screws from the inside. To remove the woofer, first remove the baffle plate.

● Reassembly

When reassembling the woofer, place it so that its ⊕ terminal is suitable for the inside. Tighten the screws to the baffle.

(3) Tweeter (Disassembly)


The tweeter is secured to the baffle plate with two screws from the inside. To remove the tweeter, first remove the baffle plate.

● Reassembly

When reassembling the tweeter, ⊕ terminal is in the topside.


Network Assy (Caution)

When removing the Network Assy, pull it out a little at a time from alternate sides, because it is seated tightly.



Baffle Assy (Caution)

When reassembling the cabinet and the baffle plate, secure the screws in the order shown in the figure below:



120


1

2

3

4

8. EACH SETTING AND ADJUSTMENT

- A
- 
1. At shipment, the unit is adjusted to its best conditions. Normally, it is not necessary to readjust even if an assembly is replaced. If the adjustment is shifted or if it becomes necessary to readjust because of part replacement, etc., perform the adjustment as described below.
 2. Any value changed in Service/Factory mode will be stored in memory as soon as it is changed. Before readjustment, take note of the original values for reference in case you need to restore the original settings.
 3. Use a stable AC power supply.

B

8.1 ADJUSTMENT REQUIRED WHEN THE UNIT IS REPAIRED OR REPLACED

■

When any of the following assemblies is replaced

POWER SUPPLY Unit	➡	Refer to “8.3 HOW TO CLEAR HISTORY DATA” and “8.6 PRECAUTION ON REPLACEMENT OF THE POWER SUPPLY UNIT”.
DIGITAL Assy	➡	Writing of backup data is required. Refer to the “8.2 BACKUP OF THE EEPROM (DIGITAL ASSY)”.
X DRIVE Assy	➡	No adjustment required
Y DRIVE Assy	➡	No adjustment required
Service Panel Assy	➡	Refer to “8.3 HOW TO CLEAR HISTORY DATA” and “8.4 ADJUSTMENTS WHEN THE SERVICE PANEL ASSY IS REPLACED”.
MAIN Assy (*)	➡	No adjustment required
SENSOR Assy	➡	Writing of backup data is required. Refer to the “8.2 BACKUP OF THE EEPROM (DIGITAL ASSY)”.
Other assemblies	➡	No adjustment required

E

■

Note: Checking the Cable Card ID

- The PDP has a slot for a cable card that is used for managing your information by the cable TV company. The following procedure allows you to check your Cable Card ID and the Host ID.
1. Press HOME MENU.
 2. Select “Tuner Setup”. (▲/▼ then ENTER)
 3. Select “Channel Setup”. (◀/▶ then ENTER)
 4. Select “POD ID”. (▲/▼)
 - The Host ID and Cable Card ID appear.
 5. Press HOME MENU to exit the menu.

F

(*) : When replacing the MAIN Assy, be sure to perform the FINAL SETUP.

Notes on replacing parts

For the parts described in the list below, replacement is required for the whole Assy, not only the defective part.

If any part listed below is identified as defective and needs replacement, replace the whole Assy, and make necessary adjustments after replacement.

Reason: The whole Assy must be replaced, because adjustments and data rewriting for the Assy at the level of production line are required.

PCB Assy No.	Assy Name	Parts that Require Whole-Assy Replacement		
		Ref No.	Function Name	Part No.
AWV2455	MAIN Assy	IC4601	AV switch	R2S11006FT
		IC4701	RGB switch	R2S11001FT
		IC4703	EEPROM	BR24L01AFJ-W
		IC4801	MAIN VDEC	CM0048BF
		IC5001	A/D Converter	AD9985KSTZ-110
		IC5102	EEPROM	BR24L02FV-W
		IC5103	EEPROM	BR24L02FV-W
		IC5203	EEPROM	BR24L02FV-W
		IC8204	Flash ROM	AGC1049
		IC8301	Flash UCOM	AGC1037
		IC8602	Flash ROM	AGC1039
AWV2452, AWV2447	X DRIVE Assy	• Parts of X D-D CON BLOCK		
AWV1262, AWV1260	Y DRIVE Assy	<ul style="list-style-type: none"> • Parts of Y VF D-D CON BLOCK • Parts of Y MAIN D-D CON BLOCK 1 • Parts of Y MAIN D-D CON BLOCK 2 		

POWER SUPPLY Unit	➡	The assembly must be replaced as a unit, and no part replacement is allowed.
MAIN Assy	➡	No adjustment is required after replacement of parts other than those mentioned above.
DIGITAL Assy	➡	No adjustment is required after replacement of parts other than those mentioned above.
X DRIVE Assy	➡	No adjustment is required after replacement of parts other than those shown in “8.5 ADJUSTMENTS WHEN THE DRIVE ASSYS ARE REPLACED.
Y DRIVE Assy	➡	No adjustment is required after replacement of parts other than those shown in “8.5 ADJUSTMENTS WHEN THE DRIVE ASSYS ARE REPLACED.
ADDRESS Assy	➡	No adjustment required
SENSOR Assy	➡	No adjustment is required after replacement of parts other than those mentioned above.
TANSHI Assy	➡	No adjustment required

1 2 3 4

8.2 BACKUP OF THE EEPROM (DIGITAL ASSY)

A

■ Outline

Adjustment data are stored in the EEPROM (IC3156/4K) on the DIGITAL Assy in the production process. Those adjustment data are also automatically stored in the EEPROM (for backup: IC3652) on the SENSOR Assy.
If the DIGITAL Assy is replaced, those adjustment data for backup can be copied from the EEPROM on the SENSOR Assy to a new DIGITAL Assy.

B

■ Backed up data

- Drive voltage adjustment value
- Hour-meter count
- Pulse-meter count
- Panel white balance adjustment value
- Serial No.
- Drive waveform adjustment value
- P-ON counter value
- PD/SD histories

■ How to copy backup data


1. When the DIGITAL Assy is replaced with one for service (usual service)

Adjustment data can be restored by copying the data backed up in the SENSOR Assy to the EEPROM on a new DIGITAL Assy.
The EEPROM on the new DIGITAL Assy has no adjustment data, and the EEPROM for backup in the SENSOR Assy has adjustment data. After replacing the DIGITAL Assy, enter PANEL FACT. mode, display the PANEL INFORMATION page, then check if "NO DATA!" is set for "DIG. EEP" and "ADJUSTED" is set for "BACKUP". Then, proceed in the following steps:

C

(1) Copying, using the Factory menu

- ① Plug in the AC cord, press the Power switch on the unit to set it to ON, then enter Standby mode.
- ② Turn on the power, using the remote control unit, then enter Panel Factory mode.
Copy the backup data, as shown in the figure below.



- ③ Turn the power off.
- After the DIGITAL Assy is replaced with one for service, be sure to check if "NO DATA!" is set for "DIG. EEP" on the PANEL INFORMATION page of the PANEL FACT. mode.
 - If copying of the backup data fails in the above procedure, the red LED lights, and the blue LED flashes, as a warning that no backup data were copied.
 - If both the DIGITAL and SENSOR Assys are to be replaced, first replace the SENSOR Assy, turn the unit on and back off again, then replace the DIGITAL Assy.

E

(2) Copying, using the RS-232C commands


- ① Turn on the unit, using the remote control unit or by issuing the PON command. Then issue the FAY command.
- ② Issue the BCP command to transfer the data stored in the EEPROM for backup.
- ③ Turn the power off.

2. When a secondhand DIGITAL Assy that had been mounted in another product is to be reused

As adjustment data for another product are already stored in the secondhand DIGITAL Assy, first delete those data then copy the backup data stored in the EEPROM on the SENSOR Assy.

(1) Copying, using the Factory menu

- ① Plug in the AC cord, press the Power switch on the unit to set it to ON, then enter Standby mode.
- ② Turn on the power, using the remote control unit, then enter Panel Factory mode.
Copy the backup data, as shown in the figure below.



- ③ Turn the power off.

Note:

If the secondhand DIGITAL Assy is mounted in the product then the unit is turned on then back off again, the data in the EEPROM on the DIGITAL Assy are copied over the EEPROM in the SENSOR Assy. Thus the backup data can never be restored. During the first power-on after the DIGITAL Assy is replaced, be sure to enter Factory mode to copy the backup data. Or, before removing the secondhand DIGITAL Assy from the original product, delete the adjustment data on it, using the Factory mode (DIGITAL EEPROM: DELETE), mount it to the product to be repaired, then copy the data from the backup EEPROM.

(2) Copying, using the RS-232C commands


- ① Turn on the unit, using the remote control unit or by issuing the PON command. Then issue the FAY command.
- ② Issue the UAJ command to delete data stored in the EEPROM on the DIGITAL Assy.
- ③ Issue the BCP command to transfer the data stored in the EEPROM for backup.
- ④ Turn the power off.

3. In a case where normal backup data are not stored in the backup EEPROM because the EEPROM on the DIGITAL Assy is defective, etc., and where manually adjusted values are to be applied to the product

Note: In this section, it is assumed that settings for various items have been completed, using Factory menu or RS-232C commands.

(1) Method using the Factory menu

- ① Set various setting/adjustment values.
- ② Proceed in the following steps.



- ③ Turn the power off.

Note:

When a DIGITAL Assy with an EEPROM in which adjustment data are stored is mounted, this step is not required after manual adjustment. ("DIGITAL EEPROM: REPAIR" is not indicated.)

(2) Method using the RS-232C commands

Issue the FAJ command.

8.3 HOW TO CLEAR HISTORY DATA

■ Clearance of various logs after the Assys are replaced

Besides adjustment data, data on accumulated power-on time and logs on defective parts of the product are backed up. Some of those data must be cleared after the Assys are replaced for service.

(1) Clearance of logs, using the RS-232C commands

Item	Content	When the Panel is replaced	When the POWER SUPPLY Unit is replaced	When the Other parts is replaced	RS-232C Commands
Hour-meter	Accumulated power-on time	Must be cleared	No need to be cleared	No need to be cleared	CHM
Pulse-meter	Accumulated number of pulses emitted	Must be cleared (mandatory)	No need to be cleared	No need to be cleared	CPM
Shutdown history	Cause of an SD and hour-meter count	Must be cleared	No need to be cleared	No need to be cleared	CSD
Power-down history	Cause of an PD and hour-meter count	Must be cleared	No need to be cleared	No need to be cleared	CPD
Power-on counter	Relay-on count	No need to be cleared	Must be cleared (mandatory)	No need to be cleared	CPC
MAX TEMP	Historical max. temperature	Must be cleared	Must be cleared	Must be cleared	CMT

Notes:


- As the pulse-meter count is used for each correction function, it must be cleared when an Assy relevant to correction functions is replaced.
- When clearing logs, using the RS-232C commands, first enter Factory mode (by issuing FAY or PFY), then issue the corresponding command.

(2) Clearance of logs, using the Factory menu

① Plug in the AC cord, press the Power switch on the unit to set it to ON, then enter Standby mode.

② Turn on the power, using the remote control unit, then enter Panel Factory mode.

Delete various logs, as shown in the figure below.



③ Turn the power off.


8.4 ADJUSTMENT WHEN THE SERVICE PANEL ASSY IS REPLACED

After the panel is replaced with one for service, voltage margin adjustment is required.

[Preparation]

Basically, voltage margin adjustment is performed using the Panel Factory menu.
After the panel is replaced and the unit is turned on, clear the pulse meter first.
For details on how to clear the pulse meter, see "8.3 HOW TO CLEAR HISTORY DATA".

- *1: As various corrections are made referring to the pulse-meter count to calculate how long the panel has been used, if adjustment of the panel for service is performed without clearing the pulse-meter count, proper adjustments will not be performed.
- *2: The drive sequence for 60-Hz video is used for adjustment. When adjustment is made using the Panel Factory menu, the current drive sequence is displayed on the screen, as shown in the figure below. Make sure that 60VS is always indicated during adjustment.



Example of the On-Screen display during Panel Factory mode

[Supplement]


In the "PANEL-1ADJ" layer, the Panel White Balance value is reset to default, Panel Gamma is set to Straight, and Noise is set to OFF.
In this case, "- - - /****" (**** represents the current drive sequence) is displayed on the third line of the On-Screen display during Panel Factory mode.

If adjustment is performed using RS-232C commands, the following commands must be transmitted for preparation:

- [PAV S00]: To set panel drive mode to Factory
- [VFQ S03]: To set Drive Sequence to Video 60 Hz
- [WBI S01]: To temporarily reset the Panel WB adjustment value to default (WBI S00 cancels this setting.)
- [PGR S00]: To set the gamma R value to that for Factory mode
- [PGG S00]: To set the gamma G value to that for Factory mode
- [PGB S00]: To set the gamma B value to that for Factory mode
- [DIZ S03]: Dither ON, L dither ON, noise OFF.

*: If the unit is shut down during the above adjustment flow, resend the above commands from the beginning.

Overview




Note on voltage calculation

When calculating the setting voltage, round off to get rid of the fractional part.

Range of margin measuring

Read the voltage within the hysteresis (stricter value).



Definition of limits for the voltage margins (abnormal lit/dead cells)

Abnormal lit cells:

- Five or fewer abnormal cells on the whole screen
- Two or fewer abnormal cells within a radius of 1 cm

Abnormal dead cells

- Fifteen or fewer abnormal cells on the whole screen
- Two or fewer abnormal cells within a radius of 1 cm

*: Abnormal cells visually recognizable at a distance of 1 meter from the panel must be counted.

*: Cells displayed abnormally for less than one second are not counted as abnormal cells.


Definition of tones for the measuring signals

WIDE-XGA signal (1365*768)/Video 60-Hz sequence/Dither: ON, L dither: ON, noise: OFF

White	RST MASK 01 (R 1023 /G 1023 /B 1023)
Red 2	RST MASK 09 (R 648 /G 115 /B 115)
Green 2	RST MASK 10 (R 115 /G 1023 /B 115)
Blue 3	RST MASK 18 (R 152 /G 152 /B 482)
Light purple	RST MASK 20 (R 1023 /G 648 /B 1023)
Magenta 70	RST MASK 23 (R 70 /G 0 /B 70)

A ■ Preparation before adjustment

[Replacement with the panel for service is completed.]



Note: If you perform the adjustment by RS-232C commands, the following commands must be added before going to the main flowchart (1):

[PAV S00]: To set panel drive mode to Factory

[WBI S01]: To temporarily reset the Panel WB adjustment value to default (WBI S00 cancels this setting.)


[PGR S00]: To set the gamma R value to that for Factory mode

[PGG S00]: To set the gamma G value to that for Factory mode

[PGB S00]: To set the gamma B value to that for Factory mode

[DIZ S03]: Dither ON, L dither ON, noise OFF

■ Main flowchart (1)...Checking VOL OFFSET



A

■ Main flowchart (2)...Checking VOL YNOFS3

[From the main flowchart (1)]

■

Display RST MASK 23 (magenta 70). / [MKS S73]

B

Set VOL YNOFS3 to the tentative setting value plus 13. / [VY3 ***]

■

Set VOL YNOFS4 to the tentative setting value plus 13. / [VY4 ***]

■

Is there erroneous discharge (abnormal lit cell)?
(Check on the PANEL 1-ADJ menu.)

Yes

To the Recovery flowchart (2-1)

No

C

Return the VOL YNOFS4 to the tentative setting value. / [VY4 ***]

■

Return the VOL YNOFS3 to the tentative setting value. / [VY3 ***]

Determine the tentative setting value for VOL YNOFS4 as the final value.
Determine the tentative setting value for VOL YNOFS3 as the final value.
Determine the tentative setting value for VOL YNOFS1 as the final value.

D



From the Recovery flowchart (2-1)

[Adjustment completed]

■


Note: Make sure that the values for VOL SUS(*1), VOL OFFSET, VOL RST P(*1), VOL XPOFS1, 2(*1) and VOL YNOFS1, 3, 4 are the final setting values.

E

*1: The tentative setting value becomes the final value.

F

Recovery flowchart (1-1)...Changing the Vol Offset setting voltage



A ■ Recovery flowchart (1-2) [From the Recovery flowchart (1-1)]

Note: Disregard the discharge that may appear during voltage-change setting.

Display RST MASK 09 (red 2). / [MKS S59]

Set VOL OFFSET to the setting value 240. / [VOF 240]

Gradually decrease the VOL OFFSET value until disappear the discharge (dead cell).

* This setting becomes VOL OFFSET_max1.

VOL OFFSET_max1

Note:

Make a note of this VOL OFFSET_max1 value.

VOL OFFSET_max1 \geq 107?

No

Replacement of abnormal circuits or re-replacement of the panel required

Yes

Display RST MASK 10 (green 2). / [MKS S60]

Set VOL OFFSET to the setting value 240. / [VOF 240]

Gradually decrease the VOL OFFSET value until disappear the discharge (dead cell).

* This setting becomes VOL OFFSET_max2.

VOL OFFSET_max2

Note:

Make a note of this VOL OFFSET_max2 value.

VOL OFFSET_max2 \geq 107?

No

Replacement of abnormal circuits or re-replacement of the panel required

Yes

Choose the lower value between VOL_OFFSET_max1 and VOL_OFFSET_max2, and set it as VOL_OFFSET_max.

VOL OFFSET_max

[To the Recovery flowchart (1-3)]

■ Recovery flowchart (1-3) [From the Recovery flowchart (1-2)]

Is the VOL OFFSET_max value minus the VOL OFFSET_min value greater than 96?

No

Replacement of abnormal circuits or re-replacement of the panel required

Yes

Are the VOL OFFSET_max value 165 or greater and the VOL OFFSET_min value 069 or less?

No

VOL OFFSET_max < 165?

No

Yes

Set VOL OFFSET to the setting value 117. / [VOF 117]

Set VOL OFFSET to the setting value VOL OFFSET_max minus 48.

Set VOL OFFSET to the setting value VOL OFFSET_min plus 48.


+

+

Determine the current VOL OFFSET setting value as the final value.

[To the main flowchart (1)]

■ Recovery flowchart (2-1)...Changing the VOL YNOFS3 setting voltage



A

Setting Voltages

B

C

D

E

F

VOF		VRP						VY1				VY3				VY4			
Vysnofs (V)	Value	Vyprst (V)	Value	Vyprst (V)	Value	Vyprst (V)	Value	Vyknofs1,2 (V)	Value	Vyknofs1,2 (V)	Value	Vyknofs3 (V)	Value	Vyknofs3 (V)	Value	Vyknofs4 (V)	Value	Vyknofs4 (V)	Value
14	000	130	001	190	109	250	217	151	001	211	129	151	001	211	129	151	001	211	129
15	005	131	003	191	111	251	219	152	003	212	131	152	003	212	131	152	003	212	131
16	011	132	004	192	113	252	221	153	005	213	133	153	005	213	133	153	005	213	133
17	016	133	006	193	114	253	223	154	008	214	136	154	008	214	136	154	008	214	136
18	021	134	008	194	116	254	224	155	010	215	138	155	010	215	138	155	010	215	138
19	027	135	010	195	118	255	226	156	012	216	140	156	012	216	140	156	012	216	140
20	032	136	012	196	120	256	228	157	014	217	142	157	014	217	142	157	014	217	142
21	037	137	013	197	122	257	230	158	016	218	144	158	016	218	144	158	016	218	144
22	043	138	015	198	123	258	232	159	018	219	146	159	018	219	146	159	018	219	146
23	048	139	017	199	125	259	233	160	020	220	148	160	020	220	148	160	020	220	148
24	053	140	019	200	127	260	235	161	022	221	150	161	022	221	150	161	022	221	150
25	059	141	021	201	129	261	237	162	025	222	153	162	025	222	153	162	025	222	153
26	064	142	022	202	131	262	239	163	027	223	155	163	027	223	155	163	027	223	155
27	069	143	024	203	133	263	241	164	029	224	157	164	029	224	157	164	029	224	157
28	075	144	026	204	134	264	242	165	031	225	159	165	031	225	159	165	031	225	159
29	080	145	028	205	136	265	244	166	033	226	161	166	033	226	161	166	033	226	161
30	085	146	030	206	138	266	246	167	035	227	163	167	035	227	163	167	035	227	163
31	091	147	031	207	140	267	248	168	037	228	165	168	037	228	165	168	037	228	165
32	096	148	033	208	142	268	250	169	040	229	168	169	040	229	168	169	040	229	168
33	101	149	035	209	143	269	251	170	042	230	170	170	042	230	170	170	042	230	170
34	107	150	037	210	145	270	253	171	044	231	172	171	044	231	172	171	044	231	172
35	112	151	039	211	147	271	255	172	046	232	174	172	046	232	174	172	046	232	174
36	117	152	041	212	149			173	048	233	176	173	048	233	176	173	048	233	176
37	123	153	042	213	150			174	050	234	178	174	050	234	178	174	050	234	178
38	128	154	044	214	152			175	052	235	180	175	052	235	180	175	052	235	180
39	133	155	046	215	154			176	054	236	182	176	054	236	182	176	054	236	182
40	139	156	048	216	156			177	057	237	185	177	057	237	185	177	057	237	185
41	144	157	050	217	158			178	059	238	187	178	059	238	187	178	059	238	187
42	149	158	051	218	159			179	061	239	189	179	061	239	189	179	061	239	189
43	155	159	053	219	161			180	063	240	191	180	063	240	191	180	063	240	191
44	160	160	055	220	163			181	065	241	193	181	065	241	193	181	065	241	193
45	165	161	057	221	165			182	067	242	195	182	067	242	195	182	067	242	195
46	171	162	059	222	167			183	069	243	197	183	069	243	197	183	069	243	197
47	176	163	060	223	169			184	072	244	200	184	072	244	200	184	072	244	200
48	181	164	062	224	170			185	074	245	202	185	074	245	202	185	074	245	202
49	187	165	064	225	172			186	076	246	204	186	076	246	204	186	076	246	204
50	192	166	066	226	174			187	078	247	206	187	078	247	206	187	078	247	206
51	197	167	068	227	176			188	080	248	208	188	080	248	208	188	080	248	208
52	203	168	069	228	178			189	082	249	210	189	082	249	210	189	082	249	210
53	208	169	071	229	179			190	084	250	212	190	084	250	212	190	084	250	212
54	213	170	073	230	181			191	086	251	214	191	086	251	214	191	086	251	214
55	219	171	075	231	183			192	089	252	217	192	089	252	217	192	089	252	217
56	224	172	076	232	185			193	091	253	219	193	091	253	219	193	091	253	219
57	229	173	078	233	187			194	093	254	221	194	093	254	221	194	093	254	221
58	235	174	080	234	188			195	095	255	223	195	095	255	223	195	095	255	223
59	240	175	082	235	190			196	097	256	225	196	097	256	225	196	097	256	225
60	245	176	084	236	192			197	099	257	227	197	099	257	227	197	099	257	227
61	251	177	086	237	194			198	101	258	229	198	101	258	229	198	101	258	229
		178	087	238	196			199	104	259	232	199	104	259	232	199	104	259	232
		179	089	239	197			200	106	260	234	200	106	260	234	200	106	260	234
		180	091	240	199			201	108	261	236	201	108	261	236	201	108	261	236
		181	093	241	201			202	110	262	238	202	110	262	238	202	110	262	238
		182	095	242	203			203	112	263	240	203	112	263	240	203	112	263	240
		183	096	243	205			204	114	264	242	204	114	264	242	204	114	264	242
		184	098	244	206			205	116	265	244	205	116	265	244	205	116	265	244
		185	100	245	208			206	118	266	246	206	118	266	246	206	118	266	246
		186	102	246	210			207	121	267	249	207	121	267	249	207	121	267	249
		187	104	247	212			208	123	268	251	208	123	268	251	208	123	268	251
		188	105	248	214			209	125	269	253	209	125	269	253	209	125	269	253
		189	107	249	215			210	127	270	255	210	127	270	255	210	127	270	255

8.5 ADJUSTMENT WHEN THE DRIVE ASSYS ARE REPLACED


■ Waveform adjustments required when replacing the following parts of the X DRIVE and Y DRIVE Assys.

Assy Name	Ref No.	Part Name	Part Category	Remarks
X DRIVE Assy	IC1101	PS9117AP	Photo Coupler	
	IC1104	TND307TD	FET Driver	
	IC1204	PS9117AP	Photo Coupler	
	IC1209	TND307TD	FET Driver	
Y DRIVE Assy	IC2101	PS9117AP	Photo Coupler	
	IC2103	TND307TD	FET Driver	
	IC2201	PS9117AP	Photo Coupler	
	IC2203	TND307TD	FET Driver	

■ TIME LAG ADJUSTMENT OF THE CONTROL SIGNAL (SUS-B)

- ① Measure the time lag for the SUS-U signal to the SUS-B signal.
- ② Check the time lag for the SUS-B GATE signal to the SUS-U GATE signal.
Adjust the variable control so that the time lag of GATE becomes "time lag of input signal + $\alpha \pm 5$ nsec."

Note: For details on measuring points of waveform, see the figure below.



Time lag of SUS-U Gate and SUS-B Gate : $\Delta Tsus-gub$

Adjust so that " $\Delta Tsus-gub = \Delta Tsus-iub + \alpha \pm 5$ nsec," using the variable controls shown in the table below:

Assy	VR	Value of α
X DRIVE Assy	VR1002	70 nsec
Y DRIVE Assy	VR2002	50 nsec


A

■ DELAY ADJUSTMENT OF THE CONTROL SIGNAL (SUS-D)


- ① Measure the pulse width of the SUS-D signal.
- ② Check the pulse width of the SUS-D input signal (gate terminal of Q2112).
Adjust the variable control so that the pulse width of the SUS-D input signal (gate terminal of Q2112) becomes the same pulse width ± 5 nsec as the SUS-D signal.

Note: For details on measuring points of waveform, see the figure below.

B



C



D

SUS-D pulse width: $T_{sus - Dg}$

Adjust so that " $T_{sus - Dg} = T_{sus - D} \pm 5$ nsec," using the variable control shown in the table below:


Assy	VR
Y DRIVE Assy	VR2001

E


F

SUS-B ADJUSTMENT

X DRIVE Assy




Y DRIVE Assy



SUS-D ADJUSTMENT

Y DRIVE Assy



1 2 3 4

8.6 PRECAUTION ON REPLACEMENT OF THE POWER SUPPLY UNIT

A

■ Attachment of the housing wire

The housing wire (J126) is attached to the P11 terminal of the POWER SUPPLY unit. As the housing wire is not provided with the POWER SUPPLY unit for service, when replacing the POWER SUPPLY unit, remove the housing wire (J126) from the old one and attach it to the new one.


NEVER turn on the unit before replacement, as doing so may damage the PC boards or the product.

B

Note:


The wiring shown in the photo is different from the actual power supply unit, because the product in the photo is a prototype.

POWER SUPPLY unit




1 Disconnect the housing wire (J126) from the P11 terminal on the old POWER SUPPLY Unit.

2 Connect the housing wire (J126) to the P11 terminal on the new POWER SUPPLY Unit.



POWER SUPPLY unit (old)



POWER SUPPLY unit (new)

9. RS-232C

9.1 OUTLINE OF RS-232C COMMAND

9.1.1 PREPARED TOOLS

It is necessary to prepare the following one to use 232C command.

- PC
 - Application for control
 - 232C cable (straight)
- * The setting of the Com port cannot be communicated if it doesn't do correctly.
(Please follow a set explanation of PC in the Com port)

9.1.2 USING RS-232C COMMANDS

Individual ports are provided for RS-232C and SR+ connectors with this model. Therefore, unlike the case of previous models, which required switching of exclusive operation between these connectors on the Integrator menu, switching is no longer required.

9.2 LIST OF RS-232C COMMANDS

RS-232C commands can be used in Service Factory mode. Before using RS-232C commands, it is necessary to change the factory presetting. See "9.1 OUTLINE OF RS-232C COMMAND".
[Note ; If you want to see version information (ex. QS1, QSE, Factory, Menu), Please see 10 seconds after starting.]

RS-232C command list

Command Name			Function	Active U-com		Last Memory	Effective only in Factory mode	Remarks
				MDU	MTB			
A								
ABL	***		Adjusting the upper limit of the power	●		Mod	●	
AMT	S00		Audio mute OFF		●			
	S01		Audio mute ON		●			
AP0	S**		ADDRESS L1, L2 setting	●		Mod	●	UP*/DN* is not effective
AP1	S**		ADDRESS L3, L4 setting	●		Mod	●	UP*/DN* is not effective
APN	***		1V average pulse number setting	●		Mod	●	UP*/DN* is not effective
APW	S00		APL interlocked function: OFF	●			●	
	S01		APL interlocked function: ON	●			●	
	S02		APL interlocked WB: ON / APL interlocked γ : OFF	●			●	
	S03		APL interlocked WB: OFF / APL interlocked γ : ON	●			●	
B								
BCP			Copying the backup data in the EEPROM	●			●	
BHI	***		User white balance : BLUE highlight	●				
BLW	***		User white balance : BLUE lowlight	●				
BRT	***		User brightness	●				
BSM	S00		After image/Burning safe mode: OFF	●				
	S01		After image/Burning safe mode: ON	●				
C								
CBU			Clearing backup data of EEPROM	●			●	
CHM			Clearing data of the hour meter	●			●	
CHN	FWD		Changing tuner preset channel (1 step forward)		●			
	REV		Changing tuner preset channel (1 step reverse)		●			
CHR			Clearing data of the hour meter of MTB side		●		●	
CNT	***		User contrast	●				
CMT			Clearing data of the maximum temperature	●			●	
CPC			Clearing power-on count data	●			●	
CPD			Clearing power-down history	●			●	
CPM			Clearing data of the pulse meter	●			●	
CSD			Clearing shutdown history	●			●	
CTM			Releasing the TRAP SW		●			
D								
DIZ	S00		Dither/L dither OFF & noise OFF	●			●	
	S01		Dither/L dither ON & noise ON	●			●	
	S02		Dither/L dither OFF & noise ON	●			●	
	S03		Dither/L dither ON & noise OFF	●			●	
DRV	S00		Panel drive-power OFF	●				
	S01		Panel drive-power ON	●				
DW*			To subtract *** to the adjustment value (*** = 000 to 999, designated by a function command)		●			
F								
FAJ			Determining the flag of the DIGITAL Assy adjustment in "adjustment is completed"	●			●	
FAN			Factory mode off	●	●		●	
FAY			Factory mode on	●	●			
FST			Set each memory setting of MTB side to the shipment state.		●		●	

Command Name	Function		Active U-com		Last Memory	Effective only in Factory mode	Remarks
			MDU	MTB			
G							
GHI	***	User white balance : GREEN highlight	●				
GLW	***	User white balance : GREEN low light	●				
I							
INA	***	Switching the terrestrial analog signal (ANTENNA A) (***: channel number)		●	Main		
	***** ****	Switching the terrestrial digital signal (ANTENNA A) (*****: channel number)		●	Main		
		Switching to the ANTENNA A		●	Main		
INB	***	Switching the terrestrial analog signal (ANTENNA B) (***:channel number)		●	Main		
		Switching to the ANTENNA B		●	Main		
INH		Switching the HomeGallery (Home Media Gallery for the ELITE model)		●			
INP	S01	Input switch: INPUT 1		●	Main		
	S02	Input switch: INPUT 2		●	Main		
	S03	Input switch: INPUT 3		●	Main		
	S04	Input switch: INPUT 4		●	Main		
	S05	Input switch: INPUT 5		●	Main		
	S06	Input switch: INPUT 6		●	Main		
	S07	Input switch: INPUT 7		●	Main		
	S08	Input switch: INPUT 8 (PC)		●	Main		
M							
MKC	S00	Panel mask indication off	●		Mod		
	S01	H ramp (slant 1) M	●		Mod	●	
	S02	H ramp (slant 4) M	●		Mod	●	
	S03	Slanting ramp M	●		Mod	●	
	S04	30 for aging	●		Mod	●	
	S05	05 for aging	●		Mod	●	
	S06	Erasing afterimage 1	●		Mod	●	
	S07	Erasing afterimage 2 (RGB: zigzag, V: reverse)	●		Mod	●	
	S08	White (change in luminance level)	●		Mod	●	
	S09	PEAK SEEK RASTER	●		Mod	●	
	S10	For engineering use	●		Mod	●	
	S11	Green vertical line scroll	●		Mod	●	
	S12	Green horizontal line scroll	●		Mod	●	
	S13	Vertical ramp vertical scroll (white)	●		Mod	●	
	S14	Vertical ramp vertical scroll (green)	●		Mod	●	
	S15	Horizontal ramp horizontal scroll (white)	●		Mod	●	
	S16	Horizontal ramp horizontal scroll (green)	●		Mod	●	
S17	Cross hatch + window	●		Mod	●		
MKS	S00	MASK off	●		Mod		
	S01	H ramp (slant 1)	●		Mod	●	
	S02	H ramp (slant 4)	●		Mod	●	
	S03	V ramp (slant 1)	●		Mod	●	
	S04	Slanting ramp	●		Mod	●	
	S05	Window (Hi= 870, Lo= 102)	●		Mod	●	

A

B

C

D

E

F

Command Name		Function	Active U-com		Last Memory	Effective only in Factory mode	Remarks
			MDU	MTB			
M							
MKS	S06	Window (Hi= 1023, Lo= 102)	●		Mod	●	
	S07	Window (Hi= 1023, Lo=000)	●		Mod	●	
	S08	Window (Hi= 1023) 4 %	●		Mod	●	
	S09	Window (Hi= 1023) 1.25 %	●		Mod	●	
	S10	Window (1/7 LINE)	●		Mod	●	
	S11	STRIPE (MGT/GRN)	●		Mod	●	
	S12	STRIPE (GRN/MGT)	●		Mod	●	
	S13	B & W, checker (1 line)	●		Mod	●	
	S14	B & W, checker (2 lines)	●		Mod	●	
	S15	B & W, checker (4 lines)	●		Mod	●	
	S16	B & W, checker (8 lines)	●		Mod	●	
	S17	COLOR BAR	●		Mod	●	
	S18	Slanting lines	●		Mod	●	
	S19	Red & black, checker (1 line)	●		Mod	●	
	S20	Red & black, checker (2 lines)	●		Mod	●	
	S21	Red & black, checker (4 lines)	●		Mod	●	
	S22	Red & black, checker (8 lines)	●		Mod	●	
	S23	Erasing afterimage (RGB: zigzag, V: reverse)	●		Mod	●	
	S24	SUS 2000 pulses (black raster)	●		Mod	●	
	S25	1 for perfect linear	●		Mod	●	
	S26	2 for perfect linear	●		Mod	●	
	S27	3 for perfect linear	●		Mod	●	
	S28	4 for perfect linear	●		Mod	●	
	S29	RGB checker 1	●		Mod	●	
	S30	RGB checker 2	●		Mod	●	
	S31	Window RED (RED=1023)	●		Mod	●	
	S32	Window GREEN (GREEN=1023)	●		Mod	●	
	S33	Window BLUE (BLUE=1023)	●		Mod	●	
	S34	Even line horizontal stripes	●		Mod	●	
	S35	Odd line horizontal stripes	●		Mod	●	
	S36	Afterimage check 1	●		Mod	●	
	S37	Afterimage check 2	●		Mod	●	
	S38	Afterimage check 3	●		Mod	●	
	S39	Afterimage check 4	●		Mod	●	
	S40	Red single-color slanting ramp	●		Mod	●	
	S41	GREEN single-color slanting ramp	●		Mod	●	
	S42	BLUE single-color slanting ramp	●		Mod	●	
	S43	Black back acnode	●		Mod	●	
	S44	Horizontal stripes every eight white lines	●		Mod	●	
	S45	5 for perfect linear	●		Mod	●	
	S46	6 for perfect linear	●		Mod	●	
	S47	7 for perfect linear	●		Mod	●	
	S48	8 for perfect linear	●		Mod	●	
	S49	Mask for ABL adjustment	●		Mod	●	
	S51	Raster - White	●		Mod	●	
	S52	Raster - Red	●		Mod	●	
	S53	Raster - Green	●		Mod	●	
	S54	Raster - Blue	●		Mod	●	
	S55	Raster - Black	●		Mod	●	

Command Name		Function	Active U-com		Last Memory	Effective only in Factory mode	Remarks
			MDU	MTB			
MKS	S56	Raster - Cyan	●		Mod	●	
	S57	Raster - Magenta	●		Mod	●	
	S58	Raster - Yellow	●		Mod	●	
	S59	Raster - Red 2	●		Mod	●	
	S60	Raster - Green 2	●		Mod	●	
	S61	Raster - Blue 2	●		Mod	●	
	S62	Raster - Magenta 2	●		Mod	●	
	S63	Raster - Red 624	●		Mod	●	
	S64	Raster - Green 624	●		Mod	●	
	S65	Raster - Blue 624	●		Mod	●	
	S66	Raster - Gray 624	●		Mod	●	
	S67	Raster - Beige	●		Mod	●	
	S68	Raster - Blue 3	●		Mod	●	
	S69	Raster - Light blue	●		Mod	●	
	S70	Raster - Pale purple	●		Mod	●	
	S71	Raster - Yellow egg color	●		Mod	●	
	S72	Raster - Pale purple 2	●		Mod	●	
	S73	Raster - Magenta 70	●		Mod	●	
	S74	Raster - Gray 70	●		Mod	●	
	S75	Raster - Gray 307	●		Mod	●	
MST	S00	Display one screen		●			
	S01	PsideP (Main size: normal)		●			
	S02	PinP (Right down)		●			
	S03	PinP (Right up)		●			
	S04	PinP (Left up)		●			
	S05	PinP (Left down)		●			
	S08	SWAP (Exchanging sub-screen)		●			
N							
NGP	S00	Negative positive inversion: OFF	●			●	
	S01	Negative positive inversion: ON	●			●	
O							
OSD	S00	Turning OSD setting to off		●	Main		
	S01	Turning OSD setting to on		●	Main		
P							
PAV	S**	Switching panel functions interlocked with the AV selection	●				
PBH	***	Panel white balance adjustment - Blue highlight	●		Mod	●	
PBL	***	Panel white balance adjustment - Blue low light	●		Mod	●	
PDM	S00	Passing PD signals to the POWER SUPPLY Unit => Power-down	●				
	S01	Not passing PD signals to the POWER SUPPLY Unit => No power-down	●				
PFL	S00	Peripheral luminance correction: OFF	●			●	
	S01	Peripheral luminance correction: ON fixed	●			●	
	S02	Peripheral luminance correction: APL interlocked ON	●			●	
PES	S00	Set the power consumption setting of the panel side to OFF	●				
	S01	Set the power consumption setting of the panel side to Energy saving 1	●				
	S02	Set the power consumption setting of the panel side to Energy saving 2	●				
PFN		Factory mode: off	●			●	
PFS		Setup at shipment	●			●	
PFY		Factory mode: on	●			●	
PGB	S**	Independent gamma Blue	●				
PGG	S**	Independent gamma Green	●				

A

B

C

D

E

F

Command Name		Function	Active U-com		Last Memory	Effective only in Factory mode	Remarks
			MDU	MTB			
P							
PGR	S**	Independent gamma Red	●				
PGH	***	Panel white balance adjustment - Green highlight	●		Mod	●	
PGL	***	Panel white balance adjustment - Green low light	●		Mod	●	
PMT	S00	Canceling panel muting	●				
	S01	Panel muting	●				
PKD	S00	Peak luminance detection: OFF	●			●	
	S01	Peak luminance detection: ON	●			●	
PKL	S**	Panel brightness setting	●				
POF		Power OFF	●	●	Main		
PON		Power on	●	●	Main		
PPT	S00	Panel protection: off	●			●	
	S01	Panel protection: on	●			●	
PRH	***	Panel white balance adjustment - Red highlight	●		Mod	●	
PRL	***	Panel white balance adjustment - Red low light	●		Mod	●	
PUC	S00	Pure cinema: off		●	Main	●	
	S01	Pure cinema: Standard		●	Main	●	
	S02	Pure cinema: Advance		●	Main	●	
	S03	Pure cinema: Smooth		●	Main	●	
Q							
QAJ		Acquiring various adjustment values	●				
QMT		Acquiring temperature of MTB side and Fan speed		●			
QNG		Acquiring shutdown information of MTB side		●			
QPD		Acquiring logs of power-down points	●				
QPM		Acquiring data of the pulse meter	●				
QPW		Acquiring panel white balance adjustment values	●				
QS1		Acquiring unit data, such as the software version common to all models, regardless of destination	●	●			
QS2		Acquiring data on the status of the unit, such as temperature	●				
QS3		Each information output for panel	●				
QSE		Acquiring unit data, such as the software version common to all models, regardless of destination		●			
QSD		Acquiring data on shutdown	●				
QSI		Acquiring data related with signals	●				
QSP		Acquiring the software sub-version of the microcomputer at panel side	●				
R							
RBL	S**	Setting of blue level for panel degradation correction	●		Mod	●	
RGL	S**	Setting of green level for panel degradation correction	●		Mod	●	
RHI	***	User white balance - Red highlight	●				
RLS	S**	Room light sensor operation at panel side	●				
RLW	***	User white balance - Red low light	●				
RRL	S**	Setting of red level for panel degradation correction	●		Mod	●	
R1K	***	RESET1ST_KSB adjustment	●		Mod	●	UP*/DN* is not effective
R2K	***	RESET2ND_KSB adjustment	●		Mod	●	UP*/DN* is not effective

Command Name		Function	Active U-com		Last Memory	Effective only in Factory mode	Remarks
			MDU	MTB			
S							
SDM	S00	Shutdown enabled	●				
	S01	Shutdown prohibited	●				
SFR	S01	Measures against AM radio noise - Pattern 1	●		Mod	●	
	S02	Measures against AM radio noise - Pattern 2	●		Mod	●	
	S03	Measures against AM radio noise - Pattern 3	●		Mod	●	
	S04	Measures against AM radio noise - Pattern 4	●		Mod	●	
	S05	Measures against AM radio noise - Pattern 5	●		Mod	●	
	S06	Measures against AM radio noise - Pattern 6	●		Mod	●	
	S07	Measures against AM radio noise - Pattern 7	●		Mod	●	
	S08	Measures against AM radio noise - Pattern 8	●		Mod	●	
SKM	S00	STREAKING correction OFF	●		Mod	●	
	S01	STREAKING correction mode 1	●		Mod	●	
	S02	STREAKING correction mode 2	●		Mod	●	
	S03	STREAKING correction mode 3	●		Mod	●	
	S04	STREAKING correction mode 4	●		Mod	●	
	S05	STREAKING correction mode 5	●		Mod	●	
	S06	STREAKING correction mode 6	●		Mod	●	
	S07	STREAKING correction mode 7	●		Mod	●	
SMC	S01	Smooth clear drive OFF	●			●	
	S02	Smooth clear drive ON	●			●	
SML	***	Adjustment of the side mask level		●	Main	●	
SMM	S**	Setting of the effective area during streaking correction	●			●	
SN0	***	Setting of the serial No. 0 (panel)	●		Mod	●	
SN1	***	Setting of the serial No. 1 (panel)	●		Mod	●	
SN2	***	Setting of the serial No. 2 (panel)	●		Mod	●	
SN3	***	Setting of the serial No. 3 (panel)	●		Mod	●	
SN4	***	Setting of the serial No. 4 (panel)	●		Mod	●	
SQM	S01	VIDEO sequence setting	●				
	S02	PC sequence setting	●				
SSM	S01	SSCG OFF	●			●	
	S02	SSCG ON	●			●	
SZM	S00	Setting the screen size to Dot by Dot		●	Main		
	S01	Setting the screen size to 4 :3		●	Main		
	S02	Setting the screen size to FULL		●	Main		
	S03	Setting the screen size to ZOOM		●	Main		
	S04	Setting the screen size to CINEMA		●	Main		
	S05	Setting the screen size to WIDE		●	Main		
T							
THS	S00	Theater port interlock operation OFF	●				
	S01	Theater port interlock operation ON	●				
U							
UAJ		Determining the flag for the DIGITAL Assy adjustment in "not adjusted"	●				
UP*		To add *** to the adjustment value (*** = 000 to 999, designated by a function command)		●			

A

B

C

D

E

F

Command Name	Function		Active U-com		Last Memory	Effective only in Factory mode	Remarks
			MDU	MTB			
V							
VFQ	S01	Setting the frequency in Mask mode to VD-48 Hz	●		Mod	●	
	S02	Setting the frequency in Mask mode to VD-50 Hz	●		Mod	●	
	S03	Setting the frequency in Mask mode to VD-60 Hz	●		Mod	●	
	S05	Setting the frequency in Mask mode to VD-72 Hz	●		Mod	●	
	S06	Setting the frequency in Mask mode to VD-75 Hz	●		Mod	●	
	S13	Setting the frequency in Mask mode to PC-60 Hz	●		Mod	●	
	S22	Setting the frequency in Mask mode to VD-50 Hz (nonstandard)	●		Mod	●	
	S23	Setting the frequency in Mask mode to VD-60 Hz (nonstandard)	●		Mod	●	
	S25	Setting the frequency in Mask mode to VD-72 Hz (nonstandard)	●		Mod	●	
	S26	Setting the frequency in Mask mode to VD-75 Hz (nonstandard)	●		Mod	●	
VOF	***	Adjustment of the reference value of Vofs voltage	●			●	
VOL	UP*, DW*, ***	To adjust the volume (to be used in combination with UP*/DW*)		●			
VRP	***	Adjustment of the reference value of Vrst-p voltage	●			●	
VSU	***	Adjustment of the reference value of Vsus voltage	●			●	
VX1	***	Adjustment of the reference value of Vxpofs1 voltage	●		Mod	●	UP*/DN* is not effective
VX2	***	Adjustment of the reference value of Vxpofs2 voltage	●		Mod	●	UP*/DN* is not effective
VY1	***	Adjustment of the reference value of Vyknofs1, 2 voltage	●		Mod	●	UP*/DN* is not effective
VY3	***	Adjustment of the reference value of Vyknofs3 voltage	●		Mod	●	UP*/DN* is not effective
VY4	***	Adjustment of the reference value of Vyknofs4 voltage	●		Mod	●	UP*/DN* is not effective
W							
WBI	S00	Panel WB standard output mode: off	●			●	
	S01	Panel WB standard output mode: on	●			●	
X							
X1B	***	XSUS_1ST_B adjustment	●		Mod	●	UP*/DN* is not effective
X3B	***	XSUS_3RD_B adjustment	●		Mod	●	UP*/DN* is not effective
XSB	***	XSUS_B adjustment	●		Mod	●	UP*/DN* is not effective
Y							
Y1K	***	YSTL_1SF_KSB adjustment	●		Mod	●	UP*/DN* is not effective
Y1Z	***	YSTL_1SF_HZ adjustment	●		Mod	●	UP*/DN* is not effective
Y2B	***	YSUS_2ND_B adjustment	●		Mod	●	UP*/DN* is not effective
Y2K	***	YSTL_2SF_KSB adjustment	●		Mod	●	UP*/DN* is not effective
Y2Z	***	YSTL_2SF_HZ adjustment	●		Mod	●	UP*/DN* is not effective
YNK	***	YSTL_FMR_KSB adjustment	●		Mod	●	UP*/DN* is not effective
YNZ	***	YSTL_FMR_HZ adjustment	●		Mod	●	UP*/DN* is not effective
YTK	***	YSTL_KSB adjustment	●		Mod	●	UP*/DN* is not effective
YTZ	***	YSTL_HZ adjustment	●		Mod	●	UP*/DN* is not effective
YSB	***	Y-SUS-B adjustment	●		Mod	●	UP*/DN* is not effective
Z							
ZME		Initializing the video EEPROM data		●		●	
ZPR		Initializing the setting data to which no adjustment command is provided	●			●	

9.3 DETAILS OF EACH COMMANDS

9.3.1 QS1 (PANEL STATUS)

Model information and version information are returned.

Command Format	Effective Operation Modes	Function	Remarks
[QS1]	Every Time	Output of status	Return data: 3 (ECO) + 84 (DATA) + 2 (CS) = 89 Byte

Data Arrangement		Data Length	Output Example
ECO		3 byte	QS1 (Fixed)
1	Display information 1 (Resolution/inch size)	1 byte	3
2	Display information 2 (Panel Generation)	1 byte	8
3	Display information 3 (Destination)	1 byte	*
4	Display information 4 (Grade)	1 byte	*
5	Display information 5 (Panel Product Form)	1 byte	B
6	Boot version of Module microcomputer	3 byte	01A
7	Program version of Module microcomputer	8 byte	001H_M
8	Boot version of Sequence processor	3 byte	01H
9	Program version of Sequence processor	8 byte	001Y
10	Panel information	8 byte	G8_50X_6
11	Reserved (*)	8 byte	*****
12	, (comma)	1 byte	
13	MTB information 1 (Generation)	1 byte	8
14	MTB information 2 (Regional model)	1 byte	A
15	MTB information 3 (Grade)	1 byte	H
16	MTB information 4 (System Type)	1 byte	B
17	Common version for IF microcomputer	8 byte	010AE
18	Boot version of IF microcomputer	4 byte	01A
19	Common version for Main microcomputer	8 byte	-01A
20	Boot version of Main microcomputer	4 byte	01A
21	Common version for Multi-processor	8 byte	-01A
22	Boot version of Multi-processor	4 byte	01A
23	Check Sum	2 byte	FF

13: MTB/MB Generation	
6	G6
7	G7
8	G8
9	G9
0	G10

14: Regional Model	
J	JP
A	US
E	EU
G	GE
C	CH
U	AU

15: MTB/MB Grade	
H	Elite/XDA/Step-upD
T	Step-upA/XG/XC/Regular (US)
B	Not used (For Future)
S	RegularD
R	RegularA

16: MTB/MB Product Form	
S	System model
B	One body model (SX)

1: Resolution/Inch Size	
3	1024*768-42
4	1024*768-43
5	1280*768-50
6	1365*768-50
7	1365*768-60
E	1920*1080-42
F	1920*1080-50
G	1920*1080-60

2: Panel Generation	
6	G6
7	G7
8	G8
9	G9
0	G10

3: Destination	
*	Commonness
A	US (Reserved)
E	EU (Reserved)
J	Japan (Reserved)

4: Grade	
*	Commonness
Z	Evaluation

5: Panel Product Form	
S	System model
B	All-in-one design TV
M	Monitor
D	Standard module
E	Simple module

10: Panel Information		
1 to 3rd byte	G8_	Generation information (+ under bar)
4 to 5th byte	42	42 inch
	50	50 inch
	60	60 inch
6th byte	**	PSIZE information and SQ_LSI version mismatching (version mismatching at SD)
	F	FHD
	X	XGA
7th byte	*	Model information and SQ_LSI version mismatching (version mismatching at SD)
	—	Under bar
	6	2nd PLANT
8th byte	4	1st PLANT
	*	PLANT information and SQ_LSI version mismatching (version mismatching at SD)
	‘	Others

9.3.2 QS2 (PANEL OPERATION DATA)

The command QS2 is for acquiring data on the panel's operational information.

Command Format	Effective Operation Modes	Function	Remarks
[QS2]	All operations	To acquire data on operations of the panel	Return data: 3 (ECO) + 34 (DATA) + 2 (CS) = 39 Byte

Data Arrangement		Data Length	Output Example
ECO		3 byte	QS2
1	Notification of mode shifting to STB	1 byte	1
2	Flag for adjustment of the main unit	1 byte	0
3	Flag for adjustment-data backup	1 byte	0
4	"1st PD" data	1 byte	0
5	"2nd PD" data	1 byte	0
6	Reserved	3 byte	***
7	Temperature data (TEMP 1)	3 byte	128
8	SD main data	1 byte	0
9	SD sub data	1 byte	0
10	Operation status induced by SD	1 byte	0
11	Reserved	3 byte	***
12	HOUR METER	8 byte	00000259
13	MASK indication	1 byte	0
14	Still picture detection	1 byte	0
15	SCAN protection detection	1 byte	0
16	Panel crack detection	1 byte	0
17	Address emergency detection	1 byte	0
18	Reserved	4 byte	****
CS		2 byte	4A

8: SD main data	
0	No SD
1	SQ_LSI
2	MDU-IIC
3	RST2
4	TEMP

9-1: SD-Sub (SQ_LSI)	
0	No SD-Sub data
1	Communication error
2	Drive stop
3	BUSY
4	Version mismatching (H/S)
5	Version mismatching (M/S)

9-2: SD-Sub (IIC)	
0	No SD-Sub data
1	EEPROM
2	BACKUP
3	DAC1
4	DAC2

9-3: SD-Sub (TEMP)	
0	No SD-Sub data
1	TEMP1 high temperature
2	TEMP1 low temperature

10: Operation status induced by SD	
0	Normal
1	Relay-off completed
2	During warning indication

13: MASK indication	
0	MASK-OFF
1	MASK-ON

14 to 17: Detection of Panel Protection function	
0	Normal
1	At detection

1: Notification of mode shifting to Standby	
P	During power ON
0	Entering Standby mode failed
1	Entering Standby mode succeeded

2: Adjustment of the main unit	
0	Adjustment completed
1	Adjustment not completed

3: Adjustment-data backup	
0	With backup data
1	No data (default)

4, 5: PD data	
0	No PD data
1	Not used
2	POWER
3	SCAN
4	SCN-5V
5	Y-DRV
6	Y-DCDC
7	Y-SUS
8	ADRS
9	X-DRV
A	X-DCDC
B	X-SUS
C	DIG-DCDC
D	Not used
E	Not used
F	UNKNOWN

9.3.3 QS3 (OTHER DATA ON THE PANEL)

The command QS3 is for acquiring data on operational information of the panel.

Command Format	Effective Operation Modes	Function	Remarks
[QS3]	All operations	To acquire data on operations of the panel	Return data: 3 (ECO) + 58 (DATA) + 2 (CS) = 63 Byte

Data Arrangement		Data Length	Output Example
ECO		3 byte	QS3
1	SERIAL	15 byte	-----
2	HOUR METER	8 byte	00000000
3	TOTAL HR METER	8 byte	00000000
4	PON COUNTER	8 byte	00000000
5	TEMP1 acquisition (Temperature value)	5 byte	+23.5 (*1)
6	TEMP0 acquisition (Temperature value)	5 byte	+28.7 (*1)
7	MAX-TEMP1 acquisition (Temperature value)	5 byte	+78.3 (*1)
8	Reserved	4 byte	****
CS		2 byte	94

Note
(*1) : Centigrade scale

9.3.4 QAJ (PANEL ADJUSTMENT DATA)

The command QAJ is for acquiring the panel's factory-preset data.

Command Format	Effective Operation Modes	Function	Remarks
[QAJ]	All operations	To acquire data on operations of the panel	Return data: 3 (ECO) + 84 (DATA) + 2 (CS) = 89 Byte

Data Arrangement		Data Length	Output Example
ECO		3 byte	QAJ
1	V-SUS adjustment value	3 byte	128
2	Vysnofs adjustment value	3 byte	128
3	Vyprst adjustment value	3 byte	128
4	Vxpofs1 adjustment value	3 byte	128
5	Vxpofs2 adjustment value	3 byte	128
6	Vyknofs1,2 adjustment value	3 byte	128
7	Vyknofs3 adjustment value	3 byte	128
8	Vyknofs4 adjustment value	3 byte	128
9	R1K adjustment value	3 byte	128
10	R2K adjustment value	3 byte	128
11	Y1K adjustment value	3 byte	128
12	Y1Z adjustment value	3 byte	128
13	X1B adjustment value	3 byte	128
14	Y2B adjustment value	3 byte	128
15	X3B adjustment value	3 byte	128
16	YSB adjustment value	3 byte	128
17	XSB adjustment value	3 byte	128
18	YTK adjustment value	3 byte	128
19	YTZ adjustment value	3 byte	128
20	Y2K adjustment value	3 byte	128
21	Y2Z adjustment value	3 byte	128
22	YNK adjustment value	3 byte	128
23	YNZ adjustment value	3 byte	128
24	R-REVISE setting value	1 byte	0
25	G-REVISE setting value	1 byte	0
26	B-REVISE setting value	1 byte	0
27	ADDRESS 1, 2 setting value	2 byte	01
28	ADDRESS 3, 4 setting value	2 byte	13
29	ADDRESS 5, 6 setting value	2 byte	32
30	ADDRESS 7, 8 setting value	2 byte	30
31	Streaking correction	1 byte	1
32	AM radio countermeasure	1 byte	1
33	Reserved	2 byte	**
CS		2 byte	B7

31: Streaking correction	
0	OFF
n	n: 1 to 8 (Mode n)

32: AM radio countermeasure	
n	n: 1 to 8 (SUS frequency n)

9.3.5 QPW (VIDEO ADJUSTMENT DATA OF THE PANEL)

The command QPW is for acquiring the factory-preset data about the video of the panel.

Command Format	Effective Operation Modes	Function	Remarks
[QPW]	All operations	To acquire data on operations of the panel	Return data: 3 (ECO) + 40 (DATA) + 2 (CS) = 45 Byte

Data Arrangement	Data Length	Output Example	1: Drive sequence	3: Type of ABL/WB tables
ECO	3 byte	QPW	50V Video 50 Hz	Tn n: 1 to 4
1 Drive sequence	3 byte	60V	60V Video 60 Hz	11, 12, 13: RGB Gamma setting
2 Standard/nonstandard	1 byte	S	72V Video 72 Hz	n 00 to 31
3 Type of ABL/WB tables	2 byte	T2	75V Video 75 Hz	15: Center luminance correction
4 ABL adjustment value	3 byte	128	60P PC 60 Hz	0 OFF
5 R-HIGH adjustment value	3 byte	256	2: Standard/nonstandard	1 ON
6 G-HIGH adjustment value	3 byte	256	S Standard	2 ON (interlocked with APL)
7 B-HIGH adjustment value	3 byte	256	N Nonstandard	17: WB interlocked with APL
8 R-LOW adjustment value	3 byte	512		0 OFF
9 G-LOW adjustment value	3 byte	512		1 ON
10 B-LOW adjustment value	3 byte	512		2 WB interlocked ON/γ OFF
11 R gamma setting	2 byte	31		3 WB interlocked OFF/γ ON
12 G gamma setting	2 byte	10		18: Transition of brightness by protective operations
13 B gamma setting	2 byte	10		0 Upper limit state for brightness
14 Streaking correction	1 byte	1		1 Brightness being reduced
15 Center luminance correction	1 byte	0		2 Lower limit state for brightness
16 Reserved	1 byte	*		3 Brightness being increased
17 WB interlocked with APL	1 byte	0		
18 Transition of protective operations	1 byte	0		
19 Reserved	2 byte	**		
CS	2 byte	37		

9.3.6 QPM (PULSE METER VALUE)

The command QPM is for acquiring the accumulated number of pulses of the panel.

Command Format	Effective Operation Modes	Function	Remarks
[QPM]	All operations	To acquire data on operations of the panel	Return data: 3 (ECO) + 40 (DATA) + 2 (CS) = 45 Byte

Data Arrangement	Data Length	Output Example
ECO	3 byte	QPM
1 Pulse meter B 1	8 byte	00000000
2 Pulse meter B 2	8 byte	00000000
3 Pulse meter B 3	8 byte	00000000
4 Pulse meter B 4	8 byte	00000000
5 Pulse meter B 5	8 byte	00000000
CS	2 byte	E7

The command QPD is for acquiring data from the 8 latest power-down (PD) logs.

Command Format	Effective Operation Modes	Function	Remarks
[QPD]	All operations	To acquire data on the power-down logs	Return data: 3 (ECO) + 80 (DATA) + 2 (CS) = 85 Byte

Data Arrangement		Data Length	Output Example
ECO		3 byte	QPD
1	Latest "1st PD" data	1 byte	A
2	Latest "2nd PD" data	1 byte	2
3	Data from the hour meter for the latest PD	8 byte	00010020
4	Second latest "1st PD" data	1 byte	E
5	Second latest "2nd PD" data	1 byte	9
6	Data from the hour meter for the second latest PD	8 byte	00008523
7	Third latest "1st PD" data	1 byte	4
8	Third latest "2nd PD" data	1 byte	3
9	Data from the hour meter for the third latest PD	8 byte	00004335
10	Fourth latest "1st PD" data	1 byte	2
11	Fourth latest "2nd PD" data	1 byte	0
12	Data from the hour meter for the fourth latest PD	8 byte	00000945
13	Fifth latest "1st PD" data	1 byte	4
14	Fifth latest "2nd PD" data	1 byte	0
15	Data from the hour meter for the fifth latest PD	8 byte	00000715
16	Sixth latest "1st PD" data	1 byte	A
17	Sixth latest "2nd PD" data	1 byte	2
18	Data from the hour meter for the sixth latest PD	8 byte	00000552
19	Seventh latest "1st PD" data	1 byte	A
20	Seventh latest "2nd PD" data	1 byte	0
21	Data from the hour meter for the seventh latest PD	8 byte	00000213
22	Eighth latest "1st PD" data	1 byte	D
23	Eighth latest "2nd PD" data	1 byte	0
24	Data from the hour meter for the eighth latest PD	8 byte	000001A7
CS		2 byte	27

1, 2, 4, 5: PD data	
0	No PD
1	Not used
2	P-POWER
3	SCAN
4	SCN-5V
5	Y-DRIVE
6	Y-DCDC
7	Y-SUS
8	Address
9	X-DRIVE
A	X-DCDC
B	X-SUS
C	DIG-DCDC
D	Not used
E	Not used
F	UNKNOWN

9.3.8 QSD (SD LOGS)

The command QSD is for acquiring the data from the 8 latest shutdown (SD) logs.

Command Format	Effective Operation Modes	Function	Remarks
[QSD]	All operations	To acquire data on the shutdown logs	Return data: 3 (ECO) + 80 (DATA) + 2 (CS) = 85 Byte

Data Arrangement		Data Length	Output Example
ECO		3 byte	QSD
1	Latest SD data	1 byte	1
2	Latest SD subcategory data	1 byte	0
3	Data from the hour meter for the latest SD	8 byte	00752013
4	Second latest SD data	1 byte	5
5	Second latest SD subcategory data	1 byte	0
6	Data from the hour meter for the second latest SD	8 byte	00495204
7	Third latest SD data	1 byte	2
8	Third latest SD subcategory data	1 byte	3
9	Data from the hour meter for the third latest SD	8 byte	00100355
10	Fourth latest SD data	1 byte	2
11	Fourth latest SD subcategory data	1 byte	5
12	Data from the hour meter for the fourth latest SD	8 byte	00075620
13	Fifth latest SD data	1 byte	1
14	Fifth latest SD subcategory data	1 byte	0
15	Data from the hour meter for the fifth latest SD	8 byte	00000852
16	Sixth latest SD data	1 byte	2
17	Sixth latest SD subcategory data	1 byte	5
18	Data from the hour meter for the sixth latest SD	8 byte	000000451
19	Seventh latest SD data	1 byte	0
20	Seventh latest SD subcategory data	1 byte	0
21	Data from the hour meter for the seventh latest SD	8 byte	00000000
22	Eighth latest SD data	1 byte	0
23	Eighth latest SD subcategory data	1 byte	0
24	Data from the hour meter for the eighth latest SD	8 byte	00000000
CS		2 Byte	7D

• SD data	
0	No SD
1	SQ_LSI
2	MDU-IIC
3	RST2
4	TEMP

• SD subcategory (SQ_LSI)	
0	No SD-Sub data
1	Communication error
2	Drive stop
3	BUSY
4	Version mismatching (H/S)
5	Version mismatching (M/S)

• SD subcategory (MDU-IIC)	
0	No SD-Sub data
1	EEPROM
2	BACKUP
3	DAC1
4	DAC2

• SD subcategory (TEMP)	
0	No SD-Sub data
1	TEMP1 (high temperature)
2	TEMP1 (low temperature)

9.3.9 QSE (DESTINATION PECULIAR INFORMATION)

Induce it peculiar, individual information is acquired.

Command Format	Effective Operation Modes	Function	Remarks
[QSE]	Every time	Output of status	

Order	Part	Data Arrangement	Data Length	Output Example
0	—	Received Command name	3 byte	QSE
1		DTV Hardware Version	8 byte	07080200
2		DTV Hardware Serial	8 byte	16777215
3		DTV RUNTIME Version	8 byte	= 00K.22p
4		CFE Version	8 byte	07.00d
5		KERNEL Version	8 byte	2.4.2527
6		ROOTS Version	8 byte	04.13d
7		FLAGS Information 1	1 byte	Y
8		FLAGS Information 2	1 byte	*
9		FLAGS Information 3	1 byte	N
10		FLAGS Information 4	1 byte	Y
11		FLAGS Information 5	1 byte	N
12		FLAGS Information 6	1 byte	N
13		HMG/HG Model Version	10 byte	1.0.126
14		User Password	4 byte	1234
15	—	Check Sum	2 byte	13

9.3.10 QMT (TEMPERATURE / FAN ROTATION / ROOM LIGHT SENSOR)

Temperature information / FAN rotation state / Room light sensor information on the MTB side is returned.

Command Format	Effective Operation Modes	Function	Remarks
[QMT]	Every time	Output of status	A/D value of MTB-side's temperature/FAN rotating status

Order	Part	Data Arrangement	Data Length	Output Example
0	—	Received Command name	3 byte	QMT
1	MTB	A/D value of MTB-side Temperature	3 byte	267
2		MTB-side FAN rotating speed (0: STOP, 1: LOW, 2: HIGH)	1 byte	1
3		A/D value of room light sensor	3 byte	009
4		Level of room light sensor (Value: 1 to 5)	1 byte	5

9.3.11 QNG (SHUTDOWN INFORMATION OF MTB)

MTB side's shutdown information is acquired.

Command Format	Effective Operation Modes	Function	Remarks
[QNG]	Every time	Output of status	

Order	Part	Data Arrangement	Data Length	Output Example
0	—	Received Command name	3 byte	QNG
1	MTB	1st latest NG No.	1 byte	0
2		Subcategory No. for the 1st latest NG.	1 byte	0
3		MTB hour meter for the 1st latest NG.	7 byte	0000000
4		Reserved	3 byte	fixed on 000
5		2nd latest NG No.	1 byte	0
6		Subcategory No. for the 2nd latest NG.	1 byte	0
7		MTB hour meter for the 2nd latest NG.	7 byte	0000000
8		Reserved	3 byte	fixed on 000
9		3rd latest NG No.	1 byte	0
10		Subcategory No. for the 3rd latest NG.	1 byte	0
11		MTB hour meter for the 3rd latest NG.	7 byte	0000000
12		Reserved	3 byte	fixed on 000
:		:	:	
29		8th latest NG No.	1 byte	0
30		Subcategory No. for the 8th latest NG.	1 byte	0
31		MTB hour meter for the 8th latest NG.	7 byte	0000000
32		Reserved	3 byte	fixed on 000
33	—	Check Sum	2 byte	00

< SD Information No. >

Frequency *	Part	Part	Remarks (Operation)
5	MTB part	Shutdown signal from audio amp. / short-circuit of speaker terminal	Shutdown after 30 seconds warning
6		Failure of communication with Module microcomputer	Immediately Shutdown
7		3-wire serial communication of Main microcomputer	Go to No. 7 Subcategory Information
8		IIC communication failure of MTB side	Go to No. 8 Subcategory Information
9		Communication failure of Main microcomputer	Immediately Shutdown
10(A)		Failure of FAN	Go to No. 10 Subcategory Information
11(B)		Abnormally in high temperature	Shutdown after 30 seconds warning
12(C)		Failure of Digital Tuner	Go to No. 12 Subcategory Information
13(D)		Failure of Power Supply at MTB side	Go to No. 13 Subcategory Information
14(E)		Startup failure of Home Media Gallery	-
15(F)		Failure of Main EEPROM	Immediately Shutdown

*: Indicates the frequency of Blue LED flashing when the shutdown is occurred.

< No. 7 Subcategory Information on "Failure in 3-wire serial communication of Main microcomputer" >

Value	Shutdown Factor	Remarks (Operation)
1	Communication error of IF microcomputer	Shutdown
2	Communication error of sequence processor	Shutdown

< No. 8 Subcategory Information on "Failure in IIC communication of MTB side" >

Value	Shutdown Factor	Remarks (Operation)
1	Tuner 1	Shutdown
2	MSP/MAP	Shutdown
3	AV Switch	Shutdown
4	RGB Switch	Shutdown
5	VDEC	Shutdown
6	VDEC-SDRAM	Shutdown
7	AD/PLL	Shutdown
8	HDMI	Shutdown
A	Tuner 2	Shutdown
B	US-MSP	Shutdown

< No. 10 Subcategory Information on "Abnormally in FAN" >

Value	Shutdown Factor	Remarks (Operation)
1	FAN 1	Shutdown
2	FAN 2 (FHD only)	Shutdown

< No. 12 Subcategory Information on "Failure in Digital Tuner" >

Value	Shutdown Factor	Remarks (Operation)
1	DTV starting failure	Turn off the screen, then reset the device.
2	DTV communication error	
4	Abnormmaly in BCM7038	
7	Tuner 1 or 2	
8	Card I/F IC	
9	VBI Slicer	
C	EEPROM	
E	TV Guide	
G	Home Gallery	
H	Middleware	
I	Application	

< No. 13 Subcategory Information on "Failure in Power supply at MTB side" >

Value	Shutdown Factor	Remarks (Operation)
1	RST 2	Shutdown
2	RST 4	Shutdown

9.3.12 QSI (INPUT SIGNAL DATA)

The command QSI is for acquiring all data on input video signals.

Command Format	Effective Operation Modes	Function	Remarks
[QSI]	All operations	To acquire all data on input video signals	Return data: 3 (ECO) + 66 (DATA) + 2 (CS) = 71 Byte

Data Arrangement		Data Length	Output Example
ECO		3 Byte	QSI
1	Type of drive sequence	3 Byte	60V
2	Standard/nonstandard	1 Byte	S
3	Type of ABL/WB tables	2 Byte	T1
4	Total value of PCN	4 Byte	0256
5	Total value of PRH	4 Byte	0256
6	Total value of PGH	4 Byte	0256
7	Total value of PBH	4 Byte	0256
8	Total value of PBR	4 Byte	0512
9	Total value of PRL	4 Byte	0512
10	Total value of PGL	4 Byte	0512
11	Total value of PBL	4 Byte	0512
12	Total value of ABL	3 Byte	128
13	Detection of V frequency	4 Byte	6002
14	Reserved	1 Byte	*
15	Reserved	3 Byte	***
16	Obtained APL data	4 Byte	1023
17	Number of SUS pulses	4 Byte	0457
18	Result of detection of still picture	1 Byte	1
19	Result of detection of cracking in the panel	1 Byte	1
20	Result of detection for scanning protection	1 Byte	1
21	Result of detection for external protection	1 Byte	1
22	Transition of protection operation	1 Byte	0
23	Reserved	4 Byte	****
CS		2 Byte	27

9.3.13 DRV (PANEL DRIVE-POWER ON / OFF)

Drive ON/OFF: ON/OFF control of panel drive-power system

Command Format	Effective Operation Modes	Function	Remarks
[DRV+S00]	Every time	DRIVE OFF	
[DRV+S01]	Every time	DRIVE ON (default)	

Once the DRIVE OFF command is accepted, DRIVE OFF cannot be canceled by pressing the DRIVE OFF key again or by turning the unit off then back on with the STANDBY OFF/ON key.

To cancel DRIVE OFF, restart the unit by unplugging then again plugging in the power cord.

9.3.14 FAY / FAN (ADJ. COMMANDS PERMISSION / PROHIBITION)

The commands FAY/FAN are for prohibiting/permitting panel/MTB-adjustment commands.

Command Format	Operation		Remarks
	Effective Operation Modes	Control	
[FAY]	Normal operation mode while the power is on	Adjustment command is valid.	For details, refer to the section “6.1.3 FUNCTIONS WHEN ENTERING THE SERVICE FACTORY MODE”.
[FAN]	During FAY	Adjustment command is invalid.	

9.3.15 FAJ / UAJ / CBU / BCP (BACKUP FUNCTION FOR ADJUSTMENT VALUE)

When the DIGITAL Assy is to be replaced, adjustment values can be copied from the backup EEPROM to the EEPROM of the Assy for service.

Command Format	Operation			Remarks
	Effective Operation Modes	Control		
[FAJ]	During FAY	To make the flag setting that indicating that adjustment of the panel unit has been completed	Writing 00 to the 4 k byte ROM and copying to the 2 k byte ROM	This takes at least 350 mS.
[UAJ]		To make the flag setting that indicating that adjustment of the main unit has not been completed	Writing F0 to the 4 k byte ROM	
[CBU]		To make the flag setting that indicating that backup data have not been copied	Writing F0 to the 2 k byte ROM	The backup ROM is initialized.
[BCP]		To copy Digital backup data to EEPROM	Copying backup data	

■

5

■

6

■

7

■

8

■

A

■

B

■

C

■

D

■

E

■

F

■

5

■

6

■


7

■


8

■

10. EXPLODED VIEWS AND PARTS LIST

- NOTES:
- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
 - The  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
 - Screws adjacent to ▼ mark on product are used for disassembly.
 - For the applying amount of lubricants or glue, follow the instructions in this manual. (In the case of no amount instructions, apply as you think it appropriate.)


10.1 PACKING SECTION



PACKING SECTION PARTS LIST


<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
⚠ 1	Power Cord (2 m)	ADG1215
2	Remote Control Unit	AXD1550
3	Battery Cover	AZN2681 ²
NSP 4	Alkaline Dry Cell Battery (LR6, AA)	VEM1023
5	Binder Assy	AEC1908
6	Cleaning Cloth	AED1285
7	Operating Instructions (English, French, Spanish)	ARE1471
8	Caution Card	ARM1239
9	Cleaning Caution (U)	ARM1303
10	Accessory Caution	ARM1304
NSP 11	Warranty Card	ARY1196
NSP 12	Card (Register)	ARY1156
13	Polyethylene Bag	AHG1394
14	Vinyl Bag	AHG1347
15	After Image Caution	ARM1351
16	Pad (508REG B-L)	AHA2654
17	Pad (508REG B-R)	AHA2655
18	Pad (508REG T-L)	AHA2656
19	Pad (508REG T-R)	AHA2657
20	Pad (508REG ACC)	AHA2658
21	Under Carton (508)	AHD3588
22	Upper Carton (5080HD)	AHD3600
23	Packing Sheet L	AHG1389
24	Band Assy	AXY1192
25	Speaket System	SMW1975

10.2 REAR SECTION



Refer to
"10.3 FRONT SECTION".

REAR SECTION PARTS LIST

Mark No.	Description	Part No.
1	SIDE IO Assy	AWW1274
2	SIDE KEY Assy	AWW1275
3	USB Cable (J301)	ADF1034
4	Side Input Panel (8U)	ANC2457
5	Function Button Base	ANG3066
6	Side Input Shield	ANK1938
7	Function Button Shield	ANK1939
8	Spacer	AEC1288
9	PCB Spacer	AEC1570
10	Re-use Wire Saddle	AEC1945
11	Locking Card Spacer	AEC2019
12	Re-use Wire Saddle	AEC2118
13	Side Spacer 507	AED1311
14	USB Spacer A	AED1317
15	Inner Grip Assy	AMR3693
 16	Gasket (USB)	ANK1846
NSP 17	Name Label (5080HD)	AAL2948
NSP 18	Serial Seal	AAX3182
19	Bolt Caution Label (U)	AAX3534
20	Label A (U)	AAX3478
21	Label B50 (U)	AAX3540
22	Label C (U)	AAX3501
23	Terminal Panel B (50U)	ANC2452
24	Function Button Panel	AMB2906
25	Side Input Cover	AMB2911
26	Function Button	AAC1562
27	Function Button Sheet (8U)	AAK2919
28	Input Cover Label 8U	AAX3509
29	Rear Case (508)	ANE1663
30	•••••	
31	Screw	BPZ30P100FTB
32	Screw (3 x 40P)	ABA1332
33	Screw	ABA1341
34	Screw	BBZ30P060FTB
35	Screw	AMZ30P060FTB
36	Screw	AMZ30P080FTC
37	Screw	APZ30P080FTB
38	Screw	BPZ30P080FTB
39	Screw	TBZ40P080FTB

10.3 FRONT SECTION

A


B

C

D

E

F



FRONT SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
1	50XGA LED Assy	AWW1280
2	50LED&IR Assy	AWW1281
3	3P Housing Wire (J116)	ADX3529
4	IR Reducer	AAX3552
5	Coil Spring	ABH1128
6	Blind Cushion	AEB1415
7	IR Block Cushion	AEB1465
8	Nylon Rivet	AEC1671
9	Rivet	AEC1877
10	Insulation Sheet A	AED1283
11	Insulation Sheet B	AED1325
12	Front Case Assy (508PU)	AMB3028
13	Corner Cushion	AEB1416
14	Pioneer Name Plate (50)	AAM1116
15	Power Button (E)	AAD4153
16	Sensor Cushion (508)	AEB1487
17	Sensor Filter	AAK2926
NSP 18	Panel Cushion H (50)	AED1320
NSP 19	Panel Cushion V (50)	AED1321

10.4 CHASSIS SECTION (1/2)

A


B

C

D

E

F




CHASSIS SECTION (1/2) PARTS LIST

Mark	No.	Description	Part No.
	1	XGA POWER SW Assy	AWW1261
	2	Ferrite Core (L1)	ATX1044
	3	Ferrite Core (F10)	ATX1060
	4	Housing Wire (J103)	ADX3521
⚠	5	Fan Motor 80 x 25L	AXM1058
	6	Front Chassis VL (50)	AMA1014
	7	Front Chassis VR 508	AMA1029
	8	Sub Frame L Assy 507	ANA2080
	9	Sub Frame R Assy 507	ANA2081
	10	Front Chassis H (508)	ANA2105
⚠	11	Panel Holder V1 (50)	ANG2770
⚠	12	Panel Holder V2 (50)	ANG2771
	13	Fan Holder	ANG2833
	14	Multi Base Holder	ANG2937
⚠	15	Panel Holder H (508)	ANG3087
	16	Waterproof Cushion	AEB1424
	17	Floating Rubber 80	AEB1427
	18	PCB Spacer	AEC1570
	19	Ferrite Core Holder	AEC1818
	20	Re-use Wire Saddle	AEC1945
	21	Re-use Wire Saddle	AEC2118
⚠	22	Address Gasket (42)	ANK1877
	23	Front Gasket (508)	ANK1952
	24	•••••	
	25	•••••	
	26	Screw	ABA1313
	27	Screw	ABA1370
	28	Screw	ABZ30P080FTC
	29	Screw	AMZ30P060FTB
	30	Screw	APZ30P080FTB
	31	Screw	BBZ30P060FTC
	32	Screw	TBZ40P080FTB
	33	Screw	ABA1364

10.5 CHASSIS SECTION (2/2)

Note:
Once the ferrite core is detached,
it cannot be reattached.
Attach a new ferrite core.



CHASSIS SECTION (2/2) PARTS LIST

Mark	No.	Description	Part No.
	1	50 X DRIVE Assy	AWV2447
	2	50 Y DRIVE Assy	AWW1260
	3	50 DIGITAL Assy	AWW1270
	4	SENSOR Assy	AWW1272
⚠	5	POWER SUPPLY Unit	AXY1157
	6	Ferrite Core (F1 - F4)	ATX1048
⚠	7	Ferrite Core (F11)	ATX1068
	8	Flexible Cable (J201)	ADD1476
	9	Flexible Cable (J202)	ADD1477
	10	Flexible Cable (J203)	ADD1478
	11	Flexible Cable (J204)	ADD1479
	12	Flexible Cable (J205)	ADD1480
	13	Flexible Cable (J206)	ADD1481
	14	Flexible Cable (J211)	ADD1482
	15	9P&6/5P Housing Wire (J101)	ADX3519
	16	8P&5P Housing Wire (J102)	ADX3520
	17	14P&5P Housing Wire (J104)	ADX3522
	18	8P/4P Housing Wire (J108)	ADX3525
	19	4P Housing Wire (J109)	ADX3526
	20	4P Housing Wire (J110)	ADX3527
	21	Housing Wire (J126)	ADX3545
	22	Conductive Plate Y (508)	ANG3083
	23	Nylon Rivet	AEC1671
	24	Flat Clamp	AEC1879
	25	Locking Wire Saddle	AEC1948
	26	Card Spacer	AEC1957
	27	PCB Spacer (Re-use)	AEC1941
	28	Re-use Card Spacer	AEC2117
	29	Re-use Wire Saddle	AEC2118
	30	Re-use HL 28	AEC2119
⚠	31	Power Sheet (8G)	AMR3708
	32	FFC Sheet	AMR3740
	33	•••••	
	34	Screw	ABA1313
	35	Screw	ABA1364

10.6 PANEL CHASSIS SECTION

A


B

C

D

E

F



PANEL CHASSIS SECTION PARTS LIST


<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
NSP 1	Panel Chassis (508) Assy	AWU1248
NSP 2	50 ADDRESS L Assy	AWW1264
NSP 3	50 ADDRESS S Assy	AWW1265
NSP 4	50 SCAN A Assy	AWW1268
NSP 5	50 SCAN B Assy	AWW1269
NSP 6	Plasma Panel (508) Assy	AWU1249
7	Insulation Bushing 1.5	AEB1482
8	PCB Spacer	AEC1944
9	Conductive Plate Holder	AMR3446
10	Address Holder Assy A (508)	AMR3716
11	Address Holder Assy B (508)	AMR3717
12	Address Plate A (508)	ANG3085
13	Address Plate B (508)	ANG3086
14	Address Silicone A (508)	AEH1146
15	Address Silicone A	AEH1093
16	Screw	ABA1351
⚠ 17	Gasket AD	ANK1948
18	Conductive Plate X	ANG3081
19	PCB Spacer	AEC1941
20	Screw	ABA1364

MULTI BASE SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
⚠ 1	MAIN Assy	AWV2455
2	TANSHI Assy	AWW1279
3	POD Assy	AWW1295
⚠ 4	Power Switch (S1 : TRAP)	ASG1089
⚠ 5	AC Inlet (CN1)	AKP1314
6	Flexible Cable (J212)	ADD1441
7	Flexible Cable (J213)	ADD1491
8	Flexible Cable (J214, J215)	ADD1519
9	12P&15P Housing Wire (J106)	ADX3523
10	5P Housing Wire (J107)	ADX3524
11	6/11/3/8/4P Housing Wire (J114)	ADX3528
12	Ferrite Core	ATX1064
13	11P Housing Wire (J118)	ADX3530
14	8P/4P Housing Wire (J119)	ADX3531
15	7P Housing Wire (J125)	ADX3532
16	3P Housing Wire (J127)	ADX3546
17	Ferrite Stopper	AEC1981
18	Locking Card Spacer	AEC1429
19	Wire Saddle	AEC1745
20	Re-use Wire Saddle	AEC1945
21	Silicone Sheet Audio	AEH1143
22	POD Cover	AMR3542
23	Multi Base Assy (U)	ANA2102
24	Terminal Panel A (U)	ANC2440
25	POD Stay A	ANG2933
⚠ 26	Housing Wire (J120)	ADX3322
27	Gasket UD	ANK1883
28	Hex. Head Screw	BBA1051
29	Nut	BBN1005
30	Screw	BMZ30P060FTB
31	Screw	PMB30P080FNI


10.8 PDP SERVICE ASSY 508

● Exterior Section



PDP-5080HD

● Packing Section



Refer to the "● Exterior Section"
for the mounting position.

PDP SERVICE ASSY 508 PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
NSP 1	Panel Chassis (508) Assy	AWU1248	26	Caution Label	AAX3031
2	Front Chassis VL (50)	AMA1014	27	•••••	
3	Front Chassis VR (508)	AMA1029	28	Inner Grip Assy	AMR3434
4	Sub Frame L Assy 507	ANA1945	29	Polyethylene Bag S	AHG1338
5	Sub Frame R Assy 507	ANA1946	30	Catalogue Bag	AHG1340
6	Front Chassis H Assy (508)	ANA2106	31	Pad (507 T-L)	AHA2538
7	Conductive Plate X (508)	ANG3081	32	Pad (507 T-R)	AHA2539
8	Address Plate A (508)	ANG3085	33	Pad (507 B-L)	AHA2540
9	Address Plate B (508)	ANG3086	34	Pad (507 B-R)	AHA2541
10	Waterproof Cushion	AEB1424	35	Under Carton (507)	AHD3473
11	Rivet	AEC1877	36	Upper Carton (507 service)	AHD3550
12	PCB Spacer	AEC1941	37	Protect Sheet	AHG1331
13	Locking Wire Saddle	AEC1948	38	PCB Spacer	AEC1570
⚠ 14	Power Sheet (8G)	AMR3708	39	Address Silicone A	AEH1093
⚠ 15	Address Gasket (42)	ANK1877	40	Address Silicone A (508)	AEH1146
NSP 16	Drive Voltage Label	ARW1097	41	Caution Sheet (8G service)	ARM1369
NSP 17	Front Case Assy (507 service)	AMB2977			
18	Rear Case (508)	ANE1666			
19	Screw	ABA1351			
20	Screw	ABA1364			
21	Screw	ABZ30P080FTC			
22	Screw	APZ30P080FTB			
23	Screw	TBZ40P080FTB			
24	Screw (3 x 40P)	ABA1332			
25	Screw	AMZ30P060FTB			

10.9 TABLE TOP STAND





TABLE TOP STAND PARTS LIST

Mark No.	Description	Part No.
1	Base Cover Assy	AXY1176
2	Stand Pipe L Assy	AXY1182
3	Stand Pipe R Assy	AXY1183
4	Screw	ABA1357
5	Screw (M8 x 23)	ABA1371
6	Screw (M8 x 40)	ABA1373

10.10 SPEAKER SYSTEM (PACKING)



SPEAKER SYSTEM (PACKING) PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
NSP 1	1..Accessory Set	SME3775	18	Form Pad (Side)	SHA2544
2	2..Speaker Wire	SDS1202	19	Form Pad (C-T)	SHA2545
3	2..Polyethylene Bag S1	SHL1439	20	Form Pad (C-M)	SHA2546
NSP 4	2..Screws Set	SME3696	21	Form Pad (C-B)	SHA2547
5	3..Screw	BMZ50P100FTB	22	Protection Sheet S3	SHC1846
6	3..Polyethylene Bag S0	SHL1438			
7	1..Bracket Assy (S)	SXG1125	23	Protection Sheet S1	SHC1847
8	2..Gasket	SEC2040	24	Packing Case	SHG2779
9	2..Gasket	SED1136	25	Packing Bag S2	SHL1450
10	2..Spacer	SEP1377	26	Polyethylene Bag S0	SHL1451
11	2..Gasket	SED1138	NSP 27	CS Assy	SMW1978
NSP 12	2..Bracket (S)	SNA1475	NSP 28	Label	SRW1112
13	1..Bracket Assy (C)	SXG1126			
14	2..Gasket	SED1140			
15	2..Gasket	SED1141			
16	2..Gasket	SED1142			
NSP 17	2..Bracket (C)	SNA1476			

10.11 CS ASSY

A


B

C


D

E

F



● Baffle Section



CS ASSY PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
NSP 1	Baffle	SNK2967	NSP 21	Gasket	SEC2093
NSP 2	1..Cabinet Assy L	SXG1123	NSP 22	Gasket	SEC2094
NSP	2..Insert Nut M5	SBN1073	NSP 23	Felt	SED1127
NSP	2..Cabinet L	SNK2968	NSP 24	Felt	SED1130
			25	Tape	SEH1113
NSP 3	1..Cabinet Assy R	SXG1124			
NSP	2..Insert Nut M5	SBN1073	26	1..Input Terminal	SKX1098
NSP	2..Cabinet R	SNK2969	NSP	2..Spring	SBH1003
			NSP	2..Terminal	SKF1064
NSP 4	1..Cabinet Assy C	SXG1122	NSP	2..Terminal	SKF1065
NSP	2..Insert Nut M5	SBN1073	NSP	2..Case	SNK2909
NSP	2..Cabinet C	SNK2970	NSP	2..Lever (Black)	SNK2910
			NSP	2..Lever (Red)	SNK2911
5	1..Grille Assy	SMG1885			
NSP	2..Grille Cloth	SAS1623	27	
NSP	2..Felt	SED1179	28	
	2..Tape	SEH1100	29	
	2..Tape	SEH1089	30	
	2..Tape	SEH1090	31	
NSP	2..Grille Frame	SMH1121	NSP 32	Acoustic Absorbent	SMT1358
NSP	2..Cosmetic Frame	SNK2971	NSP 33	MDF Bar	SLX1165
			NSP 34	Paper Tube 26	SMR1403
6		NSP 35	Acoustic Absorbent	SMT1331
7				
8	Network Assy	SWN1787	NSP 36	Acoustic Absorbent	SMT1333
NSP 9	Model Label	SAN3954	NSP 37	Acoustic Absorbent	SMT1359
NSP 10	Gasket	SEB1299	NSP 38	Acoustic Absorbent	SMT1335
			NSP 39	Acoustic Absorbent	SMT1336
NSP 11	Gasket	SEB1300	NSP 40	Acoustic Absorbent	SMT1357
12	Gasket	SEC2073			
NSP 13	Gasket	SEC2074	NSP 41	Caution Label	SRR1024
14	Gasket	SEC2076	NSP 42	Label Serial	SRW1111
NSP 15	Gasket	SEC2078	43	Speaker	H132DC65-51D
			44	Speaker	FK26AP32-55H
16	Gasket	SEC2083	45	Screw	BPZ30P080FTC
NSP 17	Gasket	SEC2134			
NSP 18	Gasket	SEC2113	46	Screw	BPZ35P080FTC
NSP 19	Gasket	SEC2114	47	Screw	BPZ35P120FTB
NSP 20	Gasket	SEC2092	48	Screw	BPZ35P120FTC
			49	Screw	BPZ35P140FTC
			50	Screw	BPZ40P350FTC

- 1 - 2 - 3 - 4 -

A

■

B

■

C

■

D

■

E

■

F

180

■ 1 ■ 2 ■ 3 ■ 4 ■

PDP-5080HD

Changed contents

Mark	Date	Rev. No.	SM Correction No.	Revision	Page
1	22-Jan-07	002	-----	Delete the description of the reference service manual.	Coversheet
2	20-Jan-09	003	SCH08025	Correct numbers of the following parts. EXPLODED VIEWS/PACKING SECTION/3 Battery Cover	161